



VX-HDMI-POE-MTX
VX-HDMI-POE-MRX

MediaCento™ IPX with PoE

Extend audio and video signals via an existing LAN.

Distribute HDMI video to an unlimited number of displays using IP multicast, or make eye-catching video walls of up to 8 x 8 displays.



Contact Information

Order toll-free or for FREE 24/7 technical support in the U.S.:
Call 877-877-BBOX (outside U.S. call 724-746-5500)
www.blackbox.com • info@blackbox.com

Trademarks Used in this Manual

Trademarks Used in this Manual

Black Box and the Double Diamond logo are registered trademarks, and MediaCento is a trademark, of BB Technologies, Inc.

Bonjour and Apple are registered trademarks of Apple, Inc.

Windows is a registered trademark of Microsoft Corporation.

UL is a registered trademark of Underwriters' Laboratories.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

FEDERAL COMMUNICATIONS COMMISSION AND INDUSTRY CANADA RADIO FREQUENCY INTERFERENCE STATEMENTS

This equipment generates, uses, and can radiate radio-frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par Industrie Canada.

Normas Oficiales Mexicanas (NOM) Electrical Safety Statement INSTRUCCIONES DE SEGURIDAD

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.

4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc.
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico debe ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.
11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.
12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equipo eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.

16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

Table of Contents

Table of Contents

1.	Specifications	8
2.	Overview	10
2.1	Introduction	10
2.2	Features	10
2.3	What's Included	11
2.4	Additional Items You Will Need	11
2.5	Hardware Description.....	12
2.5.1	Transmitter.....	12
2.5.2	Receiver	14
2.5.3	Indicators	16
2.5.4	Function Buttons (F1 and F2)	16
2.5.5	EDID Copy	17
3.	Installation	18
4.	Configuration	21
4.1	Connecting to the Devices	21
4.2	Connect to Web GUI Using the IP Address	21
4.3	Connect to Web GUI Using the Host Name	22
4.4	Network Information for Transmitter and Receiver	24
4.4.1	Transmitter.....	25
4.4.2	Receiver	27
5.	Video Wall	29
5.1	Application Diagram	29
5.2	Video Wall Setup.....	30
5.3	Bezel Compensation.....	31
6	Accessing through Serial or Telnet.....	32
6.1	Accessing through Serial	32
6.2	Accessing through Telnet	33
7.	Command-Line Interface	34
7.1	Advanced IP Commands	35
7.2	Advanced Multicast IP Configuration	36
7.2.1	Transmitter.....	36
7.2.2	Receiver	37
7.3	Serial Extension	39
7.4	Telnet Extension	40

Table of Contents

8. Troubleshooting	42
8.1 Problems/Solutions.....	42
8.2 Contacting Black Box	43
8.3 Shipping and Packaging.....	43
Appendix: Connector Pinouts.....	44

Chapter 1: Specifications

1. Specifications

Technical Specifications

Approvals	FCC, TUV, CE, UL®, CSA, RoHS, WEEE
Bandwidth	120 Mbps maximum
Default IP Address	169.254.x.x (with no DHCP address) <i>NOTE: To find the IP address of any receiver, simply connect to monitor and power up to get IP address. To find the IP address of any other receiver or transmitter, use Telnet to connect to any device in the system and use a "node_list" command or connect with the serial interface.</i>
Distance	From CPU to TX: 16 ft. (5 m) maximum, HDMI; Between TX and RX: 328 ft. (100 m)* maximum <i>*NOTE: Use a network switch to get greater distances.</i>
Efficiency Level	Level IV
Heat Dissipation	3.41 BTU/hr.
HDCP	Supported
Latency	2 frames (33 ms) maximum
Leads Supported	HDMI video and RS-232
MTBF	90,000 hours
User Controls	(1) 16-position rotary selection switch, (2) Function buttons: (1) F1, (1) F2

Technical Specifications (continued)

Connectors	(1) HDMI female, (1) RJ-45 interconnect/LAN connection, (1) 2.1-mm barrel connector for power, (2) RJ-12 6P6C† <i>†NOTE: Only 4 center pins are used at this time.</i>
Indicators	(1) LED for Link and Power; (1) LED for Network Activity
Environmental	Temperature Tolerance: Operating: 32 to 104° F (0 to 40° C); Storage: -4 to +140° F (-20 to +60° C) Humidity Tolerance: Operating: 80%, noncondensing; Altitude: 10,000 ft. (3048 m) maximum
Power	Input: 100–240 VAC, 50/60 Hz, 0.6 A; Output: 12 VDC; Consumption: 6 W; Power Supply Cord Length: 6 ft. (1.8 m)
Power over Ethernet (PoE)	Complies with IEEE 802.3af standard; Power: Nominal Input: 48 VDC; Input Range: 36–57 VDC
Size	0.98"H x 3.77"W x 5.11"D (2.5 x 9.6 x 12.9 cm)
Weight	1.1 lb. (0.5 kg)

Chapter 2: Overview

2. Overview

2.1 Introduction

The MediaCento IPX with PoE is a perfect solution for audio and video signal extension via an existing Local Area Network (LAN) system. With multicast technology, one local unit can drive multiple remote units with no extra network load. There are 16 selectable channels that can be used to transmit to multiple receivers. In a network that supports IGMP (Layer 2 or Layer 3 switches), each channel can connect to unlimited displays in video wall applications and unlimited displays in a multicast application using a standard IT Ethernet structure on a LAN system.

The MediaCento IPX with PoE supports Full HD 1080p, is HDCP compliant, is Blu-ray ready, and supports Power over Ethernet (PoE). It can handle applications that require greater distance, high speed transmission, real-time high video resolution, security, and noise immunity. It is ideal for situations that need live presentation, such as public broadcasting, education centers, boardrooms, etc.

2.2 Features

- Extend high definition video signal over LAN (dependent on network performance).
- Power over Ethernet:
 - Fully support IEEE Std. 802.3af-2003
 - Input Voltage Range 36V to 57V
- Choose from 16 selections on the DIP rotary switch for pairing.
- Provide automatic EDID configuration.
- Use well-developed Ethernet technology and TCP/IP communication protocol.
- Transmitters and Receivers are HDCP-compliant and Blu-ray ready.
- HDTV compatible; support 1080p, 1080i, 720p, 720i.
- Compatible with popular screen resolutions: XGA, SXGA, UXGA, WSXGA.
- Each transmitter can be multicast to up to an unlimited number of displays in video wall applications or unlimited displays in multicast applications.
- Use an IGMP network to prevent network flooding.

2.3 What's Included

- MediaCento IPX Multicast Transmitter (VX-HDMI-POE-MTX) or MediaCento IPX Multicast Receiver (VX-HDMI-POE-MRX)
- (1) U.S. power supply
- (1) U.S. power cord
- (4) foot pads
- This user manual

VX-HDMI-POE-MTX also has:

- (1) MediaCento IPX Multicast Transmitter
- (1) DB9 F to RJ-11 adapter
- (1) RJ-11 to RJ-11 cable

VX-HDMI-POE-MRX also has:

- (1) MediaCento IPX Multicast Receiver

2.4 Additional Items You Will Need

- HDCP-compliant monitors with HDMI interface for the HDCP video source
- CAT5/5e/6 UTP cable (EIA/TIA 568B industry-standard compliant)
- Layer 2 or 3 switches with IGMP and optional Power over Ethernet (PoE)

Chapter 2: Overview

2.5 Hardware Description

2.5.1 Transmitter



Figure 2-1. Transmitter front panel.




Figure 2-2. Transmitter back panel.




Figure 2-3. Transmitter top panel.

Table 2-1. Components of the Transmitters.

Number	Component	Description
1	F2 button	See Section 2.6.4.
2	F1 button	See Section 2.6.4.
3	Rotary switch	Set up an identical position for all units
4	RJ-12 connector	Serial port 1: For system control
5	RJ-12 connector	Serial port 2: For data transfer
6	Locking barrel connector for power	Links to power supply (not required with PoE switch)
7	Network Status LED	Flashing: Connected to network Goes off once: Abnormal
8	RJ-45 jack	Connects to the 10-/100-/1000-Mbps network switch and supplies PoE
9	Video connector	HDMI source
10	Power/Link LED	Green: Power on Interlaced flashing Blue + Green: Link w/o video Blue: Link OK

Chapter 2: Overview

2.5.2 Receiver



Figure 2-4. Receiver front panel.




Figure 2-5. Receiver back panel.




Figure 2-6. Receiver top panel.

Table 2-2. Components of the Receivers.

Number	Component	Description
1	F2 button	See Section 2.6.4.
2	F1 button	See Section 2.6.4.
3	Rotary switch	Set up an identical position for all units
4	RJ-12 connector	Serial port 1: For system control
5	RJ-12 connector	Serial port 2: For data transfer
6	Locking barrel connector for power	Links to power supply (not required with PoE switch)
7	Network Status LED	Flashing: Connected to network Goes off once: Abnormal
8	RJ-45 jack	Connects to the 10-/100-/1000-Mbps network switch and supplies PoE
9	Video connector	Connects to the HDMI monitor
10	Power/Link LED	Red: Power on Interlaced flashing Blue + Red: Link without video Blue: Link OK

Chapter 2: Overview

2.5.3 Indicators

The LEDs on the extender units show the real-time status indicating the linking and communication between the Transmitter/Sender unit and the Receiver unit. Users can identify the current status through the LED indicators on the unit.

NOTE: The system will disable the video output signal when it detects non-HDCP-compliant display(s) trying to play on the HDCP video source. All the connected output displays MUST be HDCP compliant when the video source is HDCP compliant.

2.5.4 Function Buttons (F1 and F2) and Reset Button

The Function buttons (F1 and F2) on the extender units operate as described in Table 2-3.

Table 2-3. Function buttons.

Button	Action	Description
F2	Press for 1 second.	Toggle between graphics and video mode.
F2	1. Press and hold the F2 button. 2. Apply power to the receiver unit. 3. Release right after the Network Status LED starts blinking.	EDID copy (Receiver unit only!)
F2	Press for 5 seconds.	Change anti-dithering mode
F1	Press for 1 second.	Link/Unlink connection

Table 2-3. Function buttons (continued).

Button	Action	Description
F1	1. Press and hold the F1 button. 2. Apply power to the unit. 3. Release right after the Network Status LED starts blinking. 4. Power cycle the unit.	Resets the box to factory defaults.
Reset	Press and hold the Reset button.	Reboot the system

2.5.5 EDID Copy (on Receiver Unit only)

Copying the EDID will enable the source to send correct resolutions to your display. Although the default EDID will work in most cases, some monitors will not work with it.

NOTE: EDID copy is recommended for use with DVI monitors.

To copy EDID:

1. To copy EDID from a specific receiver to a specific transmitter, both receiver and transmitter must be configured to the same channel.
2. Hold down the function button on the receiver and plug in the power.
3. Continue to hold down the function button until the network LED starts blinking. EDID is now copied to the receiver.

Chapter 3: Installation

3. Installation

WARNINGS:

Make sure that all devices are powered off before connecting to the unit.

Make sure all devices you will connect are properly grounded.

Place cables away from fluorescent lights, air conditioners, and machines.

Allow adequate space around the unit for air circulation.

System Requirements for PoE

1. Make sure that a PSE device supports PoE function.
2. Make sure that a PSE device can provide sufficient power on the Ethernet cable.
3. We recommend that you use STP and FTP cabling.

3.1 Installation Steps

NOTE: The extenders are configured as multicast units by default. To use the extenders in a plug-and-play unicast configuration, you must change the default configuration. See Chapter 4, Configuration, for details.

1. Connect the video source to the transmitter unit.
2. Connect the monitor to the receiver unit.
3. Use CAT5 cables to connect transmitter/receiver to LAN hub.
4. Set an identical ID number on the rotary DIP switch for both transmitter and receiver.
5. Apply the power to all connected devices (if you are not using a PoE switch).

NOTES:

- A. *We recommend that you use a Gigabit switch for optimum transmission quality.*
- B. *If users cannot see the screen display on their computer connection, see Section 7.1 of this manual.*




Figure 3-1. Connection pattern for unicast configuration with an Ethernet switch.




Figure 3-2. Multicast configuration.

Chapter 3: Installation




Figure 3-3. Video Wall configuration.

4. Configuration

4.1 Connecting to the Devices

You can access devices through the Web GUI, serial interface, or Telnet for advanced configuration of network and video settings. See Chapter 6 for telnet and serial connection.

4.2 Connect to Web GUI Using the IP Address

To see the IP address of a receiver:

Connect receiver and transmitter to a network switch or directly with a cable. Make sure they are set to the same channel. Next, connect a receiver to a monitor and power on. Device information, including the IP address, will be in the lower right corner. After booting, the receiver will briefly show the status screen before connecting to the transmitter.

Push the F1 button on the receiver and the video will stop and you can see the IP of both the transmitter and receiver.



Figure 4-1. IP if transmitter and receiver shown on screen.

1. Configure the control PC's network setting as 169.254.xxx.xxx IP domain with netmask 255.255.0.0.
2. Open a Web browser, click on the Network tab, and insert the IP address of the device.

Chapter 4: Configuration

4.3 Connect to Web GUI Using the Host name

Bonjour® is needed to access the Web interface by the hostname. Apple® products usually have this installed. If needed, you can download the free version from apple.com.

1. Run Bonjour.
2. Configure the control PC's network setting as 169.254.xxx.xxx IP domain with netmask 255.255.0.0. Default gateway and DNS can be left blank.
3. Open a Web browser and insert the address: `http://ast-gatewayXXXX.local`. The four digits after `ast-gateway` depend on the position of the Rotary Switch you've set. Please refer to Table 4-1. For example, if the position is set up as 7, then the address should be `http://ast-gateway1110.local`

Table 4-1. Channel listing for unicast address.

Rotary Switch	Four Digits	Domain Name
0	0000	http://ast-gateway0000.local
1	1000	http://ast-gateway1000.local
2	0100	http://ast-gateway0100.local
3	1100	http://ast-gateway1100.local
4	0010	http://ast-gateway0010.local
5	1010	http://ast-gateway1010.local
6	0110	http://ast-gateway0110.local
7	1110	http://ast-gateway1110.local
8	0001	http://ast-gateway0001.local
9	1001	http://ast-gateway1001.local
A	0101	http://ast-gateway0101.local
B	1101	http://ast-gateway1101.local
C	0011	http://ast-gateway0011.local
D	1011	http://ast-gateway1011.local
E	0111	http://ast-gateway0111.local
F	1111	http://ast-gateway1111.local

Chapter 4: Configuration

4.4 Network Information for Transmitter and Receiver

- IP Mode – Auto IP, DHCP, Static
- Auto IP (default) – Uses Zero Conf to find an open IP address in the 169.254.x.x range.
- DHCP – Assign an IP address through DHCP.
- Static – Specify an IP address, netmask, and gateway.
- Subnet mask — Default value: 255.255.0.0
- Default Gateway – Default value: 169.254.0.254

Casting mode – Multicast/Unicast

- Multicast (default) – Uses Multicasting technology to transport one video stream to multiple receivers
- Unicast – Does not use multicasting, only a single receiver will be connected to a transmitter for point to point over IP

The screenshot shows a configuration window with a blue header bar containing four tabs: "System", "Video Wall", "Network", and "Functions". The "Network" tab is selected and highlighted in green. Below the tabs, the "IP Setup" section is visible. It features three radio buttons for "IP Mode": "Auto IP" (selected and highlighted in green), "DHCP", and "Static". Below these are three text input fields: "IP Address" with the value "169.254.42.110", "Subnet Mask" with the value "255.255.0.0", and "Default Gateway" with the value "169.254.0.254". An "Apply" button is located at the bottom right of this section. Below the IP Setup section is the "Casting Mode" section, which has two radio buttons: "Multicast" (selected and highlighted in green) and "Unicast". An "Apply" button is also present at the bottom right of this section.

Figure 4-2. IP setup screen for transmitter and receiver.

4.4.1 Transmitter

Video over IP:




Figure 4-3. Video over IP screen for transmitter.

1. Click on the Functions tab.
2. Check the box next to Enable Video over IP.
3. Check the box next to Enable Video Wall.

Chapter 4: Configuration

Serial over IP:



The screenshot shows a configuration window titled "Serial over IP". Inside the window, there is a checkbox labeled "Enable Serial over IP" which is checked. Below this is a section titled "Operation Mode:" containing four radio buttons: "Type 1 (Need extra control instruction. For advanced usage.)", "Type 2 (Recommended. Dumb redirection.)", "Type 1 guest mode", and "Type 2 guest mode". The "Type 2 (Recommended. Dumb redirection.)" option is selected. Below the radio buttons is a section titled "Baudrate Setting for Type 2:". This section contains four dropdown menus: "Baudrate:" (set to 9600), "Data bits:" (set to 8), "Parity:" (set to None), and "Stop bits:" (set to 1). At the bottom right of the configuration window is a blue button labeled "Apply".

Figure 4-4. Serial over IP for transmitter.

1. Check the box next to Enable Serial over IP.
2. Select the Operation Mode from the four radio buttons:
 - Type 1 (Need extra control instructions. For advanced usage.)
 - Type 2 (Recommended. Dumb redirection.)
 - Type 1 guest mode
 - Type 2 guest mode

NOTE: See Sections 6.1 for telnet extension and 6.2 for serial extension details.

3. Select the Baudrate setting from the drop-down box:

Here, we chose Baudrate Setting for Type 2.

Select the serial parameters from the drop-down boxes.

- Baudrate
- Data Bits
- Parity
- Stop Bits

4.4.2 Receiver

Video Over IP:





Figure 4-5. Video over IP for receiver.

1. Click on the Functions tab.
2. Check the box next to Enable Video over IP.
3. Check the box next to Enable Video Wall.
4. For multicast mode, leave the box unchecked next to Copy EDID from this Video Output (Default disabled under multicast mode).

Chapter 4: Configuration

Serial over IP:



The screenshot shows a configuration window titled "Serial over IP". It contains a checkbox labeled "Enable Serial over IP" which is checked. Below this is a section titled "Operation Mode:" with four radio button options: "Type 1 (Need extra control instruction. For advanced usage.)", "Type 2 (Recommended. Dumb redirection.)", "Type 1 guest mode", and "Type 2 guest mode". The "Type 2 (Recommended. Dumb redirection.)" option is selected. Below the radio buttons is a section titled "Baudrate Setting for Type 2:" with four dropdown menus: "Baudrate:" (set to 9600), "Data bits:" (set to 8), "Parity:" (set to None), and "Stop bits:" (set to 1). An "Apply" button is located at the bottom right of the configuration area.

Figure 4-6. Serial over IP for receiver.

1. Check the box next to Enable Serial over IP.
2. Select the Operation Mode from the four radio buttons:
 - Type 1 (Need extra control instructions. For advanced usage.)
 - Type 2 (Recommended. Dumb redirection.)
 - Type 1 guest mode
 - Type 2 guest mode

NOTE: See Sections 6.1 for telnet extension and 6.2 for serial extension details.

3. Select the serial parameters from the drop-down boxes:

Here, we show Baudrate Setting for Type 2.

- Baudrate
- Data Bits
- Parity
- Stop Bits

5. Video Wall

5.1 Application Diagram

Using the Video Wall features, you can send video and audio to unlimited outputs through IP. Format the video wall so that separate sections of the video can be sent to different outputs. Basic settings allow for bezel compensation and different arrays of screens. Advanced settings allow for video manipulation to specific outputs. Figure 7-1 shows a typical application:




Figure 5-1. Sample installation.

Chapter 5: Video Wall

5.2 Video Wall Setup

Step 1: Use the show OSD button to display the IP/Name of your receiver units. Select "All" from the Apply To drop down box and check the Show OSD check box. Click Apply to display the OSD on the displays connected to receivers. This information will be used in determining position of each receiver in the video wall.

Step 2: Select each individual receiver one at a time that will be in the video wall. You can do this by using the drop-down box under Apply To.

Step 3: Select the dimensions of your video wall using the Vertical Monitor Count and Horizontal Monitor Count drop-down boxes.

Wall Size and Position Layout

Vertical Monitor Count:
1

Horizontal Monitor Count:
1

Row Position:
0

Column Position:
0

☐ Single Host Mode

UNIT: Panel

Apply To: "All" device(s) in the list
All

☐ Show OSD

Apply

Figure 5-2. Wall size and position layout screen.

Step 4: Using information gained from the OSD, adjust the Row Position and Column Position of your receiver. Position (0,0) is the top left corner of the video wall.

Step 5: Repeat this process for each receiver in the video wall

5.3 Bezel Compensation

Measurements of the display will need to be taken to set up bezel compensation. Measuring units (inch, cm, mm) do not matter, but the same unit should be used for all measurements.




Figure 5-3. Wall size and position layout screen.

Step 1: Measure the outer dimensions of the display (edge to edge including bezel). Enter the width of the display in the OW textbox. Enter the height of the display in the OH textbox.

Step 2: Measure the inner dimensions of the display (This is actual screen size, not including the bezel). Enter the width of the screen in the VW textbox. Enter the height of the screen in the VH textbox.

Chapter 6: Accessing through Serial or Telnet

6. Accessing through Serial or Telnet

6.1 Accessing through Serial

1. Using the client, select “serial” and enter “115200” for the speed (baud rate).




Figure 6-1. PuTTY configuration screen using serial.

2. No username or password is required. Just press enter.

6.2 Accessing through Telnet

1. Using the client, enter in the IP address of the device.
2. Change the port to 24.




Figure 6-2. PuTTY configuration screen using Telnet.

3. The default password is root.


Chapter 7: Command-Line Interface

7. Command-Line Interface (CLI)

These are advanced configurations and require knowledge of IP networking protocols and multicasting. Do not attempt to run any commands, modify files, or change any other settings apart from the specific configurations noted here.

All commands are case-sensitive.

To list names and IP information of all connected MediaCento IPX devices, type in:
node_list



```
COM1 - PuTTY

starting pid 131, tty '/dev/ttyS1': '-/bin/sh'


BusyBox v1.10.3 (2012-02-01 15:39:39 CST) built-in shell (ash)
Enter 'help' for a list of built-in commands.

/ # node_list
IP      Hostname      Status
>>>>>
169.254.100.2  ast-client008414A0B022  s_srv_on
169.254.100.1  ast-gateway1100  s_attaching
<<<<<
/ #
```

Figure 7-1. Names and IP information list.

To view all current configured parameters, type in:

astparam dump



```
COM1 - PuTTY

/ # astparam dump
CRC = 0x725FB2E0
ethaddr=02:B1:1C:4E:6A:ED
ip_mode=static
ipaddr=169.254.100.1
netmask=255.255.0.0
/ #
```

Figure 7-2. Current configured parameters list.

To reset to factory default, setting the IP mode to autoip and removing any overrides, type in:

```
reset_to_default.sh
```

To change the baud rate of the serial extension interface, type in:

```
stty X -F /dev/ttyS0
```

(replace X with desired baud rate)

To disable/enable the link for a specific device, type in:

```
ast_send_event -1 e_stop_link
```

```
ast_send_event -1 e_reconnect
```

7.1 Advanced IP Commands

Each device has three possible modes of establishing an IP address: autoip, dhcp, and static.

1. AutoIP is the default mode and it will always automatically assign available IP addresses in the private IP domain 169.254.xxx.xxx

NOTE: The MediaCentO IPX uses the Avahi zeroconf protocol to find an available IP in the 169.254.xxx.xxx range.

Chapter 7: Command-Line Interface

2. DHCP client gets an address from the local DHCP server.

CAUTION: Make sure a DHCP client is connected or problems will occur.

3. Static allows you to manually change the IP address and netmask of the device.
This requires further input before reboot.

To change the IP mode, type in:

astparam s ip_mode <mode> (where <mode> is autoip, dhcp, or static)

astparam save (saves changes)

reboot (reboots the device)

If static is selected, the following commands are needed before reboot. Type in:

astparam s ipaddr xxx.xxx.xxx.xxx (enter IP address for x's)

astparam s netmask xxx.xxx.xxx.xxx (enter netmask for x's)

astparam save (saves changes)

reboot




Figure 7-3. COM1 PuTTY screen.

7.2 Advanced Multicast IP Configuration

Predefined multicast addresses can be selected by using the rotary switch buttons on the devices (recommended). See Table 7-1 for listing of channels.

7.2.1 Transmitter

To change the multicast group IP, type in:

astparam s multicast_ip 225.0.B0.B1B2B3

To change the hostname ID of the transmitter, type in:

```
astparam s hostname_id B0B1B2B3
```

```
ast_send_event -1 e_chg_hostname
```

To override DIP rotary switch setting on bootup:

```
astparam s reset_ch_on_boot n      (space between boot and the n)
```

```
astparam save
```

```
reboot
```

7.2.2 Receiver

To change the multicast group IP, type in:

```
astparam s multicast_ip 225.0.B0.B1B2B3
```

To change the transmitter channel read:

```
astparam s ch_select B0B1B2B3
```

To override DIP rotary switch setting on bootup, type in:

```
astparam s reset_ch_on_boot n      (space between boot and the n)
```

```
astparam save
```

```
reboot
```

Table 7-1. Channel listing for multicast address.

Channel IDs	Multicast Address
0	225.0.100.0
1	225.0.100.1
2	225.0.100.8
3	225.0.100.9
4	225.0.100.100
5	225.0.100.101
6	225.0.100.110
7	225.0.100.111
8	225.0.101.0
9	225.0.101.1
A	225.0.101.8
B	225.0.101.9
C	225.0.101.100
D	225.0.101.101
E	225.0.101.110
F	225.0.101.111

7.3 Serial Extension

Serial extension can be done from one transmitter to all linked receivers. Telnet serial extension is also available as a replacement of serial. Serial extension information:

Default baud rate: 9600 (unless changed manually)

Data bits: 8

Parity: Even

Stop bits: 1

Flow control: None

NOTE: This is a two-way communication. The transmitter will receive any data sent from the serial devices connected to the receivers.




Figure 7-4. Options controlling local serial lines.

Chapter 7: Command-Line Interface

For both transmitter and receiver units, the added RJ-11 to DB9 serial cable needs to be connected to the second serial port on the devices.

7.4 Telnet Extension

Telnet serial extension allows for serial output from a receiver through a Telnet connection. This disables serial input coming from a transmitter but allows for 2-way communication to specific devices.

NOTE: Telnet extension needs serial extension setting changed to "Type 2 guest mode" in the Web interface. For details, contact Black Box Technical Support at 724-746-5500 or info@blackbox.com.

To set up a Telnet extension:

1. Using a Telnet protocol, use Port 6752.




Figure 7-5. Setting up Telnet extension using a Telnet protocol.

2. Turn off line echo and local line editing.




Figure 7-6. Turning off line echo and local line editing.

Chapter 8: Troubleshooting

8. Troubleshooting

8.1 Problem/Solutions

Problem: No video on monitor at bootup.

Solutions:

1. Check the device power using the Link/Power LED.
2. Check the network connection using the Network LED.
3. Check the video connection using the Link/Power LED.
4. Make sure that the DIP rotary switch is set to the correct ID.

NOTE: If manually changed, make sure the IDs match.

5. If you're using a mix of multicast and unicast units, make sure they match up correctly.
6. Set your display device's (TV, monitor, etc.) input source as HDMI.
7. Check the PC BIOS configuration for the video output setting.
8. Connect your computer to the HDMI Display DIRECTLY to check if the video signal gets through.
9. Make sure the DVI monitor is using the correct EDID. See Section 2.6.5 for details.
10. Verify that displays are HDCP compliant if copy protected content is being transmitted.

Problem: Video is of lower quality than input video.

Solutions:

1. Check that network settings are configured correctly.
2. Check if anti-dithering is turned off.

8.2 Contacting Black Box

If you determine that your MediaCento IPX with PoE is malfunctioning, do not attempt to alter or repair the unit. It contains no user-serviceable parts. Contact Black Box Technical Support at 877-877-2269 or info@blackbox.com.

Before you do, make a record of the history of the problem. We will be able to provide more efficient and accurate assistance if you have a complete description, including:

- the nature and duration of the problem.
- when the problem occurs.
- the components involved in the problem.
- any particular application that, when used, appears to create the problem or make it worse.

8.3 Shipping and Packaging

If you need to transport or ship your MediaCento IPX with PoE:

- Package it carefully. We recommend that you use the original container.
- If you are returning the unit, make sure you include everything you received with it. Before you ship for return or repair, contact Black Box to get a Return Authorization (RA) number.

Appendix: Connector Pinouts

Appendix. Connector Pinouts

Figure A-1 shows the DB9 to RJ-12 or RJ-11 connector pinouts.




Figure A-1. DB9 to RJ-12 6P6C or RJ-11 (4P4C) cable pinout.

NOTES

Black Box Tech Support: FREE! Live. 24/7.

Tech support the
way it should be.



Great tech support is just 60 seconds away
at 877-877-2269 or BlackBox.com.



About Black Box

Black Box provides an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live 24/7 Tech Support available in 60 seconds or less.

© Copyright 2016. Black Box Corporation. All rights reserved..

VX-HDMI-POE-MTX_version 3

877-877-BBOX (2269) | BlackBox.com