

KanexPro®

SW-HDSC51HDBT

USER MANUAL



**HDBaseT™ Seamless Presentation Switcher & Scaler w/ 5
inputs**

All Rights Reserved

Version: SW-HDSC51HDBT_2017V1.2

Preface

Read this user manual carefully before using this product. Pictures displayed in this manual are for reference only. Different models and specifications are subject to the actual product.

This manual is only for operational instruction, not for any maintenance usage. The functions described in this version are updated till Dec 2017. Any changes of functions and parameters since then will be informed separately. Please refer to the dealers for the latest details.

Trademarks

Product model and logo are trademarks. Any other trademarks mentioned in this manual are acknowledged as the properties of the trademark owner. No part of this publication may be copied or reproduced without the prior written consent.

FCC Statement

This equipment can generate, use, and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. It has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation.

Operation of this equipment in a residential area is likely to cause interference, in which case the user at their own expense will be required to take whatever measures may be necessary to correct the interference

Any changes or modifications not expressly approved by the manufacture would void the user's authority to operate the equipment.



SAFETY PRECAUTIONS

To ensure the best from the product, please read all instructions carefully before using the device. Save this manual for further reference.

- Unpack the equipment carefully and save the original box and packing material for possible future shipment.
- Follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- Do not dismantle the housing or modify the module. It may result in electrical shock or burn.
- Using supplies or parts not meeting the products' specifications may cause damage, deterioration or malfunction.
- Refer all servicing to qualified service personnel.
- To prevent fire or shock hazard, do not expose the unit to rain or moisture. Do not install this product near water.
- Do not place any heavy items on the extension cable in case of extrusion.
- Do not remove the housing of the device as opening or removing housing may expose you to dangerous voltage or other hazards.
- Install the device in a place with fine ventilation to avoid damage caused by overheating.
- Keep the module away from liquids.
- Spillage into the housing may result in fire, electrical shock, or equipment damage. If an object or liquid falls or spills on to the housing, unplug the module immediately.
- Do not twist/pull by force the ends of the optical cable. It can cause malfunction.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power cord to the device before cleaning.
- Unplug the power cord when left unused for a long period.
- Information on disposal for scrapped devices: Do not burn or mix with general household waste; please treat the devices as normal electrical waste.

Table of Contents

1. Introduction.....	6
1.1 Introduction to the Scaler Switcher	6
1.2 Features	6
1.3 Package List.....	7
2. Panel Description	8
2.1 Front Panel	8
2.2 Rear Panel.....	9
3. System Connection	11
3.1 Usage Precautions	11
3.2 System Diagram	11
3.3 Connection Procedure	12
3.4 Connection of Microphone.....	13
3.5 System Application	15
4. System Operations	16
4.1 Front Panel Buttons	16
4.1.1 Manual-Switching.....	16
4.1.2 Auto-Switching	16
4.1.3 Volume Adjusting	17
4.2 IR Control	17
4.2.1 IR Remote.....	17
4.2.2 Control far-end device from local	18
4.2.3 Control local device from remote	18
4.2.4 CEC Function.....	19
4.3 RS232 Control	20
4.3.1 Installation/uninstallation of RS232 Control Software	20
4.3.2 Basic Settings	21
4.3.3 RS232 Communication Commands.....	23
4.3.4 Control Compact Scaler Switcher or 3rd Party Device from Local	30
4.3.5 Control Compact Scaler Switcher or 3rd party device form Remote ..	31
4.4 OSD Menu Control	32

4.4.1 Options.....	33
4.4.2 Picture.....	34
4.4.3 Setup.....	35
4.5 Web-based GUI Control	36
4.5.1 Control Menu	36
4.5.2 Configuration Menu.....	38
4.5.3 RS232 Control Menu	40
4.5.4 Password Menu	41
4.5.5 Web-based GUI Update.....	41
5. Specifications	42
6. Panel Drawing	44
7. Troubleshooting & Maintenance	45
8. After-sales Service.....	47
9. Warranty.....	48

1. Introduction

1.1 Introduction to SW-HDSC51HDBT

The KanexPro SW-HDSC51HDBT is a seamless switcher with 5-inputs (3 HDMI, 1 DP & 1 VGA), with one local HDMI output and one HDBaseT™ output designed to switch and scale up to 5 devices to one or more displays (mirrored). It supports instant seamless switching from one device to another with zero latency no matter what its connected to. Fully compliant with the latest HDCP 2.2 specs, this switcher supports CEC commands and EDID management. The output of the switcher can be extended with via PoH (power over HDBaseT) to up to 230 feet. (70m) with the receiver included in the system.

The switcher can be controlled using one IR input, one IR output & one RS-232 port, the IR & RS-232 signals can be broadcasted bi-directionally between the seamless scaler-switcher and the HDBaseT receiver. In addition, the switcher can also be controlled via web-based GUI, front panel buttons, RS232 commands and through IR remote.

1.2 Features

- Seamlessly switch & scale 5-video inputs to 2-outputs using HDBaseT & HDMI
- Auto-switching enabled
- HDBaseT output extends CAT5e/6 distance up to 230 feet (70 meters)
- Includes HDBaseT receiver w/ PoH support
- Built-in Audio De-embedder for HDMI & VGA inputs
- Selectable output resolutions supported: 1920x1200, 1920x1080, 1600x1200, 1360x768, 1280x800, 1280x720, 1024x768
- HDCP 2.2 compliant & CEC
- VGA video supports C-video, YPbPr and VGA.
- 48V phantom power to support condenser microphone.
- MIC port supports balance/unbalance signal, suppress the external noise effectively.

- 3-level MIC input for use with: condenser, dynamic & wireless microphones
- Bi-directional IR & RS232 control.
- Controllable via buttons, IR remote, RS232 & Web-based GUI
- Includes IR remote
- Powerful OSD function

1.3 Package List

- 1 x Compact Scaler Switcher
- 2 x Mounting Ears with 4 screws
- 2 x Long Mounting Ears with 6 screws (Optional)
- 1 x Power Adapter (24VDC,2.71A)
- 4 x Plastic Cushions
- 1 x IR Remote
- 1 x VGA converting cable (VGA to YPbPr)
- 1 x HDBaseT Receiver
- 2 x Mounting Ears with 4 screws for HDBaseT Receiver
- 4 x Plastic Cushions for HDBaseT Receiver
- 1 x RS232 cable (3-Pin phoenix connector to DB9)
- 2 x 3-Pin phoenix connectors
- 1 x 5-Pin phoenix connector
- 1 x IR Emitter
- 1 x IR Receiver (with carrier wave)
- 1 x User Manual

Notes: If there are defective parts or parts are missing, please contact your local dealer(s).

2. Panel Description

2.1 Front Panel




Figure 2- 1 Front Panel

- ① Built-in IR Receiver
- ② Power indicator
 - Off when there is no power to the device
 - Green when the device is in standby mode
 - Red when the device is powered on.
- ③ 1-HDMI/MHL input Selector & Activity LED; Left key
- ④ 2-HDMI input Selector & Activity LED; Right key
- ⑤ 3-HDMI input Selector & Activity LED; Up key
- ⑥ 4-DisplayPort input Selector & Activity LED; Down key
- ⑦ 5-VGA input Selector Activity LED; Enter key
- ⑧ Auto-Switching Mode Selector& Activity LED; OSD menu button
 - Press this button to enter or exit Auto-switching mode, in this mode, select input source via front panel button is not available, but RS232 command and IR remote are able to switch mode. The auto LED turn green and keep on.

Note: When you set any VGA port to C-video or YPbPr in Manual-switching mode, the system will not be able to enter Auto-switching mode.
 - Long-press this button more than 2 seconds to enter OSD menu, and then use ③~⑥ direction keys, ⑦confirm key to control.
- ⑨ Volume Knob

2.2 Rear Panel



Figure 2- 2 Rear Panel

① INPUTS

- Video input ports: 1 HDMI/MHL input, 2 HDMI inputs, 1 DP and 1 VGA
- Audio input ports: 1 DP external audio input and 1 VGA auxiliary audio input.

② OUTPUTS

- HDMI output: HDMI video output port
- HDBaseT output: Support PoH. Connect with an HDBaseT Receiver to transmit AV signal or IR/RS232 control signal.

HDBaseT output boasts green and yellow indicator. The green indicator will blink when power. If connect an HDBaseT receiver to this output successfully, the yellow indicator will light up, and the green indicator will keep blinking.

③ MIC INPUT

- MIC audio port: connect to Microphone.
- Dial switch: including 3 level
 - ✧ 48V phantom power mode (connect with condenser microphone);
 - ✧ MIC mode (connect with dynamic microphone);
 - ✧ LINE mode (connect with wireless microphone or line audio).

④ CONTROL

- RES RESET: press this button to reset the output resolution to 1280×720p, or activate HDMI and HDBT outputs when they are closed.
- IR IN: connect with IR receiver (with carrier wave only) to receive IR signal to control far-end device which was connected to HDBaseT Receiver via HDBaseT output port.
- IR OUT: connect with IR emitter to control local source devices from remote.
- IR EYE: connect with IR receiver (with carrier wave only) to receive IR signal send by IR remote to control this Scaler Switcher.
- FIRMWARE: Type-A USB port for updating system firmware or loading

customized EDID data.

- RS232: Serial port, 3-pin phoenix connector, connect with a control device (such as PC) to control the Scaler Switcher or other devices connected with HDBaseT Receiver.
- TCP/IP: Ethernet port, connect with PC to control the Scaler Switcher via Web-based GUI.

⑤ AUDIO OUTPUT

- Audio output port, the audio comes from the input audio corresponding to the selected video source and is mixed with MIC audio.

⑥ DC 24V

- Power port, connect with DC 24V power adapter.

 Pictures shown in this manual are only for reference.

3. System Connection

3.1 Usage Precautions

- 1) System should be installed in a clean environment, which should have a proper temperature and humidity.
- 2) All of the power switches, plugs, sockets and power cords should be insulated and safe.
- 3) All devices should be connected before powered on.
- 4) System Diagram shown in this manual is for reference only; more specific schemes depend on real-time applications.

3.2 System Diagram




Figure 3- 1 Connection diagram

3.3 Connection Procedure

- Step1.** Connect HDMI source devices (e.g. Blue-ray DVD) to 1~3 HDMI input ports with HDMI cable
- Step2.** Connect a DisplayPort source device (e.g. MAC MINI) to DP input port with DisplayPort cable and DP audio input port with audio cable.
- Step3.** Connect a VGA source device (e.g. Laptop) to VGA input port with VGA cable and VGA audio input port with audio cable.
- Step4.** Select MIC level and connect right microphone to MIC input port. MIC audio will be transmitted to AUDIO OUTPUT port and mixed with source audio.
- Step5.** Connect a HDMI display device to HDMI output port with HDMI cable.
- Step6.** Connect HDBaseT Receiver to HDBT output port with twisted pair.
- Step7.** Connect speaker, headphone or AV amplifier to AUDIO OUTPUT port.
- Step8.** Connect control device (e.g. PC, control system) to the TCP/IP port, the Scaler Switcher can be controlled via web-based GUI.
- Step9.** Connect control device (e.g. PC) to the RS232 port of the Scaler Switcher or the HDBaseT Receiver (bi-directional RS232 control, either end is available).
- Step10.** Connect IR receiver to the IR EYE port, the Scaler Switcher can be control via IR remote. For more details, please refer to **4.2.IR Control.**
- Step11.** Both the Scaler Switcher and the HDBaseT Receiver have IR IN and OUT. When one model is connected with IR receiver, the other model should connect with an IR transmitter.
- For example:** When “IR IN” of the Scaler Switcher connects with an IR receiver, the IR transmitter must connect to IR OUT of HDBaseT Receiver.
- The IR signal can be transmitted bi-directionally between the Scaler Switcher and the HDBaseT Receiver.**
- Step12.** Connect DC24V power adaptor to the power port (HDBaseT Receiver can be powered by the Scaler Switcher with PoH function).

Note: *If the power adapter is connecting with the HDBaseT Receiver, the Scaler Switcher can't be powered from HDBaseT Receiver.*

3.4 Connection of Microphone


The Scaler Switcher provides with one 3-level microphone input port, to accommodate different microphone input modes, including 48V phantom power mode, MIC mode & LINE mode.

➤ 48V phantom power Mode

48V phantom power input has a good frequency characteristic, high input impedance and high sensitivity.

When switching to “48V”, the MIC input will provide a 48V phantom power. This is only used for **condenser microphone**.

Connect the microphone in this way: “+” connects to positive, “-” connects to negative and “ ⏏ ” to ground.



➤ MIC Mode


MIC input has a low frequency characteristics, and wide frequency response.

When switch to “MIC”, the microphone input is used for connecting with **dynamic microphone**. There are two different connection methods:


1) Unbalanced connection:

“+” and “ ⏏ ” connect to ground, and “-” connects to signal.

“-” and “ ⏏ ” connect to ground, and “+” connects to signal.



- 2) Balanced connection: “+” connects to positive, “-” connects to negative and “ \perp ” connects to ground.



➤ **LINE Mode**


LINE input has a low frequency characteristics, and wide frequency response.

When switch to “LINE”, the microphone input is used for connecting with line audio or wireless microphone output. There are two different connection methods:


- 1) Unbalanced connection:

“+” and “ \perp ” connect to ground, and “-” connects to signal.

“-” and “ \perp ” connect to ground, and “+” connects to signal.



- 2) Balanced connection: “+” connects to positive, “-” connects to negative and “ \perp ” connects to ground.



3.5 System Application

The Scaler Switcher has an ideal use in lecture halls, boardrooms and conference room set-ups where DisplayPort and HDMI based laptops and other devices can be used for fast switching & scaling with legacy video formats such as VGA to one or more displays over HDBaseT up to 70 meters.

4. System Operations

4.1 Front Panel Buttons

Front panel buttons can be used for switching operations and volume adjusting.

4.1.1 Manual Switching

Press **1-HDMI/MHL**, **2-HDMI**, **3-HDMI**, **4-DP**, **5-VGA** on front panel to select the corresponding input source.

4.1.2 Auto-Switching

Press **AUTO** to enter in auto-switching mode.

The auto-switching mode abides by the following principles:

➤ **New input**

Once detecting a new input signal, the switcher would switch to this new signal automatically.

➤ **Rebooting device**

The Scaler Switcher can save the last configuration before losing power. If the last switching mode is auto-switching, once rebooted, the switcher will automatically enter auto-switching mode, then detect all inputs and memorize their connection status for future rebooting using. If the last displayed signal is still available, the unit will output the signal. If not, the unit will detect all the input signals with priority from 1-HDMI/MHL to 5-VGA. When detected the first signal, it will transfer to output.

➤ **Signal removing**

Once removing the current display signal, the Scaler Switcher will detect all input signals with priority from 1-HDMI/MHL to 5-VGA. It will transfer the signal firstly detected to be available to output devices.

Note:

- *When the DP signal is switched as input, the DP source device may not read the EDID data from display device, at this point re-plug the DP source device to solve this phenomenon.*

Auto-switching function works only when inputting new signal, removing a signal or power rebooting. With any VGA port set to C-video or YPbPr, the system will be not able to enter in Auto-switching mode.

4.1.3 Volume Adjusting


Press Volume Knob to choose MIC/Source audio needed to be adjusted, the corresponding LED will turn green and keep on.

- Adjusting the Volume Knob in clockwise direction to increase sound volume.
- Adjusting the Volume Knob in anti-clockwise direction to decrease sound volume.

4.2 IR Control

4.2.1 IR Remote


Connect IR receiver to IR EYE port, the Scaler Switcher can be controlled by using IR remote. As CEC function, it uses the IR remote to turn on/off the HDMI source or Display.



- ① Enter/ exit standby mode
- ② Input channel selection buttons (1~5): Select video source via pressing corresponding button (audio switched following the corresponding DP/VGA)
- ③ Auto button: Enter/Exit auto-switching mode.
- ④ Mute/ unmute audio
- ⑤ VOL: Volume adjusting button. After pressing this button, the volume adjusting menu will be showed on Display, and then press UP/DOWN button to increase/decrease volume.
- ⑥ OK: confirm button; Navigation buttons: UP/DWON/LEFT/ RIGHT button, for value setting or page-turn.
- ⑦ Exit button: Exit OSD menu or current operation.
- ⑧ Enter OSD menu or used to return to previous menu.


4.2.2 Control Far-End Device from Local

Connect an IR receiver to IR IN port on the Scaler Switcher and connect IR emitter to the IR OUT port on the HDBaseT Receiver, the far-end device can be control by its IR remote from local.



4.2.3 Control Local Device from Remote

Connect an IR emitter to IR OUT port on the Compact Scaler Switcher and connect IR receiver to the IR IN port on the HDBaseT Receiver, the source devices can be control by their IR remote from remote.



4.2.4 CEC Function

The Scaler Switcher supports CEC, it can be turned on/ off by sending RS232 commands or OSD menu operations. The default setting is ON.

Commands pertaining to CEC: “50686%” (enable CEC) and “50687%” (disable CEC)


HDMI INPUT ports 1~3 support CEC, if the connected source devices also support CEC and their CEC are on, users can control the source device and display via the IR remote of the Scaler Switcher.

The working status related to CEC and STANDBY is showed as below:

Situation	Working Status
CEC: on, Standby: on	Press STANDBY button on IR remote, the Scaler Switcher enters in standby mode, so do all HDMI source devices and display. Press STANDBY button again on IR remote, the Scaler Switcher exits standby mode, the previous selected HDMI input source device and display start working too.
CEC: on, Standby: off	Press STANDBY button on IR remote, the Scaler Switcher enters in standby mode, HDMI 1~3 source devices and display keep on.
CEC: on	Use and buttons on IR remote to control HDMI source device.

CEC: off

Unable to control HDMI source device and display through IR remote



4.3 RS232 Control

As RS232, can be transmitted bi-directionally between the Scaler Switcher and the HDBaseT Receiver, so it is able to control a third party RS232 device from local or control the Scaler Switcher from remote. The baud rate support 2400, 4800, 9600(default), 19200, 38400, 57600 or 115200.

4.3.1 Installation/uninstallation of RS232 Control Software

- **Installation** Copy the control software file to the computer connected with the Scaler Switcher.
- **Uninstallation** Delete all the control software files in corresponding file path.


4.3.2 Basic Settings

First to connect the Scaler Switcher with all input devices and output devices needed, then to connect it with a computer which is installed with RS232 control software. Double-click the software icon to run this software.

Here we take the software **CommWatch.exe** as example. The icon is showed as below:



The interface of the control software is showed as below:



Please set the parameters of COM number, bound rate, data bit, stop bit and the parity bit correctly, and then you can send command in Command Sending Area.

4.3.3 RS232 Communication Commands

Communication protocol: RS232 Communication Protocol

Baud rate: 9600

Data bit: 8

Stop bit: 1

Parity bit: none

Command	Function	Feedback Example
Switch Commands		
50701%	Switch to 1-HDMI/MHL input	Switch to HDMI 1
50702%	Switch to 2-HDMI input	Switch to HDMI 2
50703%	Switch to 3-HDMI input	Switch to HDMI 3
50704%	Switch to 4-DP input	Switch to DP
50705%	Switch to 5-VGA input	Switch to VGA 1/YPbPr/AV
50683%	Set the signal format to VGA for 5-VGA input	Input 5 Set & Switch to VGA
50684%	Set the signal format to YPbPr for 5-VGA input	Input 5 Set & Switch to YPbPr
50685%	Set the signal format to AV(C-video) for 5-VGA input	Input 5 Set & Switch to AV
50785%	Enable auto-switching	Auto Switching
50786%	Disable auto-switching	Manual Switching
Audio Commands		
50600%	MUTE Source audio	Source Mute
50601%	UnMute Source audio	Source Unmute
50602%	Increase the volume of source audio	Source Volume: xx (xx=00~60)
50603%	Decrease the volume of source audio	Source Volume: xx (xx=00~60)
50722%	Mute MIC audio	MIC Mute
50723%	Unmute MIC audio	MIC Unmute
50726%	Mute VGA audio	VGA audio Mute
50727%	Unmute VGA audio	VGA audio Unmute
50728%	Mute DP audio	DP audio Mute
50729%	Unmute DP audio	DP audio Unmute
50724%	Increase the volume of MIC audio	MIC Volume: xx (xx=00~60)
50725%	Decrease the volume of MIC audio	MIC Volume: xx (xx=00~60)

Command	Function	Feedback Example
508xx%	Set the volume of MIC audio	MIC Volume: xx (xx=00~60)
510xx%	Set the volume of source audio	Source Volume: xx (xx=00~60)
50706%	Select embedded audio as audio input for DP video signal	DP Audio from Embedded
50707%	Select external audio as audio input for DP video signal	DP Audio from External
Resolution Commands		
50619%	Set the output resolution to 1360X768 HD	Resolution: 1360x768
50626%	Set the output resolution to 1024X768 XGA	Resolution: 1024x768
50627%	Set the output resolution to 1280X720 720P	Resolution: 1280x720
50628%	Set the output resolution to 1280X800 WXGA	Resolution: 1280x800
50629%	Set the output resolution to 1920X1080 1080P	Resolution: 1920x1080
50620%	Set the output resolution to 1920X1200 WUXGA	Resolution: 1920x1200
50621%	Set the output resolution to 1600X1200 UXGA	Resolution: 1600x1200
50624%	Set the output resolution to 1600X900	Resolution: 1600x900
Setup Commands		
50604%	Lock the front panel buttons	Front Panel lock
50605%	Unlock the front panel buttons	Front Panel Unlock
502xx%	Set the brightness to xx.	Brightness: xx (xx=00~99)
503xx%	Set the contrast to xx.	Contrast: xx (xx=00~99)
504xx%	Set the saturation to xx.	Saturation: xx (xx=00~99)
505xx%	Set the sharpness to xx.	Sharpness: xx (xx=00~99)
50607%	Adjust the color temperature	Color Temperature: xx (xx=Cool/ Medium/ Warm/ User.)

Command	Function	Feedback Example
50608%	Set the aspect ratio	Aspect Ratio: xx (xx= 16:9/ 4:3/ auto)
50614%	Set the picture mode	Picture Mode: xx (xx= dynamic/ standard/ mild/ user)
50655%	Freeze output image	Freeze: enable
50656%	Cancel the freezing of output image	Freeze: disable
50646%	Enable MIC Volume Icon display	Volume Icon: enable
50647%	Disable MIC Volume Icon display	Volume Icon: disable
50761%	Disable the mute icon of Source audio display	Source Mute Icon: disable
50762%	Enable the mute icon of Source audio display	Source Mute Icon: enable
50763%	Disable the mute icon of MIC audio display	MIC Mute Icon: disable
50764%	Enable the mute icon of MIC audio display	MIC Mute Icon: enable
50765%	Enable the freeze icon display	Freeze Icon: enable
50766%	Disable freeze icon display	Freeze Icon: disable
50644%	Enable channel status display	Input Icon: enable
50645%	Disable channel status display	Input Icon: disable
50650%	Check the channel status	Input Icon: xx
50606%	Auto-adjust the input parameter (VGA only)	VGA Input Auto
50699%	Check the system version	Version Vx.x.x
50688%	Enable MIC noise detecting	MIC detect: enable
50689%	Disable MIC noise detecting	MIC detect: disable
50690%	Check MIC noise detecting statue	MIC detect: XXXX
50791%	HDCP Active mode	HDCP Active
50792%	HDCP Manual mode	HDCP Manual
50793%	Enable HDCP output	HDCP ON
50794%	Disable HDCP output	HDCP OFF

Command	Function	Feedback Example
50795%	Inquire HDCP/ Manual HDCP	HDCP Manual
		HDCP OFF/ON
50767%	Restore default EDID	EDID: initial
50768%	Bypass EDID data from output to input	EDID: bypass
50769%	Upload custom EDID data to the switcher	EDID: user
50770%	Inquire EDID status	EDID: initial
		EDID: bypass
		EDID: user
50782%	EDID management, copy the best resolution data of one output to HDMI input	EDID manage
		Resolution:1920x1080
50787%	Enable serial control mode 1: control Scaler & far-end from local RS232	RS232 Mode 1: RS232 Control Scaler & Remote
50788%	Enable serial control mode 2: control Scaler from local RS232 and far-end)	RS232 Mode 2: RS232 Control Scaler
50714%	Auto Switch Mode: Disable the automatic power off function	Auto Switch Mode: Set no input to power off function: Disable
50715%	Auto Switch Mode: Set the automatic power off time to 1 minute for No signal input	Auto Switch Mode: Set no input to power off time: 1 minute
50716%	Auto Switch Mode: Set the automatic power off time to 2 minutes for No signal input	Auto Switch Mode: Set no input to power off time: 2 minutes
50717%	Auto Switch Mode: Set the automatic power off time to 5 minutes for No signal input	Auto Switch Mode: Set no input to power off time: 5 minutes
50718%	Auto Switch Mode: Set the automatic power off time to 10 minutes for No signal input	Auto Switch Mode: Set no input to power off time: 10 minutes
50719%	Check the automatic power off time	Auto Switch Mode: Set no input to power off time: 1 minutes

Command	Function	Feedback Example
		Manual Switch Mode: Set no input to power off function: Disable
50740%	Manual Switch Mode: Disable automatic power off function	Manual Switch Mode: Set no input to power off time: 0 minutes
50741%	Manual Switch Mode: Set the power off time to 1 minute	Manual Switch Mode: Set no input to power off time: 1 minute
50742%	Manual Switch Mode: Set the power off time to 2 minute	Manual Switch Mode: Set no input to power off time: 2 minutes
50743%	Manual Switch Mode: Set the power off time to 5 minute	Manual Switch Mode: Set no input to power off time: 5 minutes
50744%	Manual Switch Mode: Set the power off time to 10 minute	Manual Switch Mode: Set no input to power off time: 10 minutes
50697%	Exit standby mode	Wake up!
50797%	Enter standby mode	Go to standby!
50698%	Software update	Software update
50617%	Reset to factory defaults	Factory Reset
Menu Commands		
50609%	OK for OSD selection	Key: ok
50610%	LEFT button	Key: left
50611%	RIGHT button	Key: right
50612%	UP button	Key: up
50613%	DOWN button	Key: down
50616%	MENU button (enter OSD)	OSD: Enter
50618%	EXIT button (exit OSD)	OSD: Exit
Inquire Commands		
50630%	Check the volume level	Source Volume: xx (xx=00~60)
		MIC Volume: xx (xx=00~60)

Command	Function	Feedback Example
50631%	Check the input source	Input: xx (xx= HDMI1/ HDMI2/ HDMI3/ DP/ VGA/ YPbPr/ AV)
50632%	Check the output resolution	Resolution: xx (xx=1920x1200/ 1920x1080/ 1600x1200/ 1360x768/ 1280x800/ 1280x720/ 1024x768/1600x900)
50633%	Check the image mode	Picture Mode: xx (xx= Dynamic/ Standard/ Mild/ User)
50635%	Check the image aspect ratio	Aspect Ratio: xx (xx= 16:9/ 4:3/ auto/)
50636%	Check the brightness	Brightness: xx (xx=00~99)
50637%	Check the contrast	Contrast: xx (xx=00~99)
50638%	Check the saturation	Saturation: xx (xx=00~99)
50639%	Check sharpness	Sharpness: xx (xx=00~99)
50640%	Check the color temperature	Color Temperature: xx (xx= Cool/ Medium/ Warm/ User.)
50651%	Check Volume Icon display status	Volume Icon: xxxx
50712%	Check the audio input sources for DP	DP Audio from Embedded
50751%	Check whether the Source audio is mute or not	Source Mute/Unmute
50752%	Check whether the MIC audio is mute or not	MIC Mute/Unmute
50753%	Check the freeze status	Freeze: enable/disable
50754%	Check the panel locked status	Front Panel Lock/UnLock
50783%	Display statues including MIC, Source audio, Resolution, Manual/ Auto-switching modes, VGA audio mute on/off, DP audio status	Source Volume: XX
		Mic Volume: XX
		Input: XXXX
		Resolution: XXXX
		LINE Mute/Unmute
		MIC Mute/Unmute

Command	Function	Feedback Example
		Switch status: XXXX
		VGA Mute/Unmute
		DP Mute/Unmute
		DP Audio from Embedded/External
50657%	Check IP address	192.168.0.178!
50712%	Check DP audio path	DP Audio from Embedded/External
Adjustment Commands		
50678%	Enable screen output adjusting	Enter Output Position Adjust
50679%	Disable screen output adjusting	Exit Output Position Adjust
50670%	Move the image to left	Output Position Adjust X xx
50671%	Move the image to right	Output Position Adjust X xx
50672%	Move the image up	Output Position Adjust Y XX
50673%	Move the image down	Output Position Adjust Y xx
50674%	Stretch left from left side (increase image width)	Output Width Adjust xx
50675%	Pull right from left side (decrease image width)	Output Width Adjust xx
50676%	Stretch upwards from bottom side (decrease image height)	Output Height Adjust xx
50677%	Stretch downwards from bottom side (increase image height)	Output Height Adjust xx
50730%	Turn off HDMI output	HDMI power off
50731%	Turn on HDMI output	HDMI power on
50732%	Turn off HDBT output	HDBT power off
50733%	Turn on HDBT output	HDBT power on
50734%	Turn on HDMI& HDBT output synchronously	HDMI HDBT power on
CEC Commands		

Command	Function	Feedback Example
50687%	Disable CEC	HDMI CEC OFF
50686%	Enable CEC	HDMI CEC ON
50901%	Play&pause	CEC cmd: play&pause
50902%	Stop	CEC cmd: stop
50903%	Menu	CEC cmd: menu
50904%	Retreat	CEC cmd: rev
50905%	Forward	CEC cmd: fwd
50906%	Up	CEC cmd: up
50907%	Down	CEC cmd: down
50908%	Left	CEC cmd: left
50909%	Right	CEC cmd: right
50910%	Confirm command	CEC cmd: select
50911%	Exit command	CEC cmd: exit
50913%	Source power on	Source power on
50914%	Source power off	Source power off
50920%	TV power on	Display power on
50921%	TV power off	Display power off

Note:


- Screen output adjusting avails only when the screen output adjusting is on. Send command 50678% to turn on.
- Under HDCP ON or HDCP OFF mode, the video signal can be switched to HDMI and HDBaseT output seamlessly, while sending 50791% to set as HDCP Active mode, the video signal can't support seamless switching.
- CEC commands with grey background avails only when CEC is on.

4.3.4 Control Compact Scaler Switcher or 3rd Party Device from Local

Firstly, according the following connection diagram to connect all devices as needed.

Secondly, send command **50787%** (serial control mode 1, factory default) via RS232 communication software.

Lastly, send the right command of the Scaler Switcher or other remote RS232 device connected in present system. Connect as below:




Control Compact Scaler Switcher or 3rd party device from local

4.3.5 Control Compact Scaler Switcher or 3rd Party Device from Remote

Firstly, according the following connection diagram to connect all devices as needed.

Secondly, send command **50788%** via RS232 communication software.

Lastly, send the right command to control the Scaler Switcher. Connect as below:



Control Compact Scaler Switcher or 3rd party device from Remote

4.4 OSD Menu Control

The Scaler Switcher provides a powerful OSD operation menu, contains 3 parts: optional settings, image settings, and system setting etc.

There are three ways to enter OSD menu:


- Long-press the button **MENU/2s** on front panel 2 seconds or more.
- Press MENU button  on IR remote.
- Send the command **50616%** on RS232 Control Software.

Operation way:

- Press direction buttons on front panel or IR remote to switch between menu options and menu pages.
- Press **ENTER** on front panel or **OK** on the IR remote to confirm the selection.

4.4.1 Options

Includes Output Adjust, Input 5 Select, Baud rate, User EDID Load (USB), Resolution, and Software Update (USB).



Output Adjust: Adjust output image position (X: horizontal direction and Y: vertical direction), ratio aspect (width and height), polarity adjustment (H Polarity and V Polarity) and output setting (HDMI on/off and HDBT on/off).

Input5 Select: Select video source format for VGA input, includes AV 1 (C-video signal), VGA 1 (VGA signal) and YPbPr 1 (Component video signal).

Baud rate: Set the baud rate for RS232 control, and it support 2400、4800、9600、19200、38400、57600、115200.

User EDID Load (USB): Insert the USB flash disk with EDID file to FIRMWARE port to load EDID data through this menu.

Resolution: Set the output resolutions, and it support 1920x1200, 1920x1080, 1600x1200, 1600x900, 1360x768, 1280x800, 1280x720, 1024x768.

Pw Off Time (Auto): Set the auto power off time when no signal input (1, 2, 5 or 10 minutes can be chosen).

Pw Off Time (Manual): Set the power off time when no signal input (1, 2, 5 or 10 minutes can be chosen).


IP: Show the IP address.

Software Update (USB): Insert the USB flash disk with updating file to USB port of the Scaler Switcher, to update the software through this menu.

4.4.2 Picture

Including Picture Mode, Color Temperature, Aspect Ratio, Noise Reduction, Screen and Color Range.

Please check the picture below:



- **Picture mode:** Include Dynamic, Standard, Mild, and User. Only in User mode, will it be able to set the image contrast, brightness, color and sharpness.
- **Color Temperature:** Include Cool, Medium, Warm and User. And only in User mode, it is able to set values for Red, Green and Blue (RGB).
- **Aspect Ratio:** Include Native, 4:3, 16:9, Zoom1, Zoom2, Just Scan, and Panorama. VGA format only supports 4:3, 16:9 and Panorama.
- **Noise Reduction** (not for VGA format): Includes Off, Low, Middle, High and Default.
- **Screen:** (not for HDMI source): Include Auto Adjust, Horizontal, Vertical, Size, and Phase.

4.4.3 Setup

Including OSD Language, Restore Factory Default, Blending, HDMI CEC, OSD Duration and version inquiry



- **OSD Language:** Supports 7 languages, including English (default), Chinese etc.
- **Restore Factory Default:** Restores to original system state
- **Blending:** Includes Low, Middle, High and Off.
- **HDMI CEC:** Enable/disable CEC and auto-standby function. Default: CEC on, STANDBY on. Only when CEC is on, will it be able to set auto-standby status.
- **OSD Duration:** Includes 5 Sec, 10 Sec, 15 Sec and Off.
- **VERSION:** Displays software version

4.5 Web-based GUI Control

In addition to control the Scaler Switcher via front panel button, IR remote and RS232 communication software. The Scaler Switcher can be controlled via web-based GUI. It allows users to interact with the Scaler Switcher through graphical icons and visual indicators.

Type **192.168.0.178** in your browser, it will enter the log-in interface shown as below:



4.5.1 Control Menu

Type user name: user and password: user (default setting) on the log-in interface, and then click **Login** to enter Control menu shown as below:



- **Sources:** Click the corresponding button (1-HDMI/MHL, 2-HDMI, 3-HDMI, 4-DP, and 5-VGA) to select video input source.
- **VGA:** Click **Adjust** to adjust the position of VGA video output image to make sure the best visual effect.
- **DP:** Click **Audio** to turn on/off the DP external audio input.
- **Volume:** Click the corresponding positive/negative button to increase/decrease the volume of microphone audio or source audio input. Click the corresponding **Mute** button to mute/unmute microphone audio or source audio input.
- Click **Source** to turn on/off input source device.
- Click **Display** to turn on/off output display device.
- Click **Local** to let the Scaler Switcher r into standby mode.

4.5.2 Configuration Menu

1. Click  on control menu to enter setting menu shown as below:



- **Output Resolution:** Select the output resolution that you need and then click **Confirm**.
- **Update:** Insert the USB flash disk with EDID file/software updating file to FIRMWARE port, and then click EDID/Firmware to start update procedure.
- **Shutdown Timer (NO Input):** Set the shutdown time under manual-switching mode or auto-switching mode, including none, 1 minute, 2minutes, 5minutes and 10 Minutes. If the Scaler Switcher can't detect video source input, it will automatically shut down after a preset interval.

2. Click **Network** to enter network setting menu shown as below:



In this interface, dynamic or static IP mode can be selected. Under static IP mode, IP address and subnet mask, gateway can be set and make sure the IP addresses are different to avoid IP conflict.

3. Click **Source Label** to enter source label setting menu shown as below:



In this interface, the name of source input selection button can be modified as you need.

4.5.3 RS232 Control Menu

Click **RS232 Control** on the top of interface to enter RS232 control menu shown as below:




The screenshot shows the RS232 Control menu interface. It features three tabs at the top: 'Configuration', 'RS232 Control' (which is the active tab), and 'Password'. The main content area is dark teal and contains three input fields: 'Port' with a dropdown menu showing 'Local', 'Baud Rate' with a dropdown menu showing '9600', and 'Command' with a text input field and a 'Hex' checkbox. A 'Send' button is located below the Command field.

- **Port:** Local port refers to the RS232 port of the Scaler Switcher, and the HDBT port refers to the RS232 port of HDBaseT Receiver.
- **Baud Rate:** The baud rate of local port is 9600 which can't be modified, but for HDBT port, it supports 2400、4800、9600、19200、38400、57600、115200.
- **Command:** Typing commands in this box to control the Scaler Switcher or the far-end device which is connected to HDBaseT Receiver. If checked the "Hex", you can enter hexadecimal value in the "Command" box.

4.5.4 Password Menu


Click **Password** on the top of interface to enter password menu shown as below:



In this interface, the user name and password can be modified as you need.

4.5.5 Web-based GUI Update

Web-based GUI for the Scaler Switcher supports online update in <http://192.168.0.178:100>. Type the username and password (the same as the GUI log-in settings, modified password will be available only after rebooting) to log in the configuration interface. After that, click **Administration** at the source menu to get to **Upload Program** as shown below:



Select the desired update file and press Apply, it will start upgrading then.

5. Specification

Video	
Video input	1 HDMI/MHL; 2 HDMI; 1 DP; 1 VGA
Video Input Connector	3 female HDMI; 1 DisplayPort; 1 female VGA (15-pin)
Input Video Signal	HDMI, DP, YPbPr, C-video, VGA
Video Output	1 HDMI; 1 HDBaseT
Video Output Connector	1 female HDMI; 1 RJ45
Output Video Signal	HDMI, HDBaseT
Output Resolution	1920x1200, 1920x1080, 1600x1200, 1600x900, 1360x768, 1280x800, 1280x720, 1024x768.
Standards	Compliant with HDMI 1.4 & HDCP2.2
Audio	
Audio Input	1 stereo audio input for DP 1 stereo audio input for VGA 1 Microphone audio
Audio Input Connector	2 3.5mm Stereo jacks 1 3-Pin phoenix connector
Audio Input Impedance	>10k Ω
Audio Output	1 Dual-Mono analog audio

Audio Output Connector	1 5-Pin phoenix connector
Audio Output Impedance	70Ω
Frequency Response	20Hz~20K Hz
Stereo Channel Separation	>80dB @ 1KHz
Control Part	
Control port	1 IR IN, 1 IR OUT, 1 IR EYE, 1 RS232, 1 TCP/IP
Control Connector	3 3.5mm mini jack; 1 3-Pin phoenix connectors; 1 RJ45
General	
Transmission Distance	1080P≤70m(Cat6)
Temperature	0 ~ +50°C
Humidity	10% ~ 90%
Power Supply	DC24V 2.71A
Power Consumption	27W
Dimension (W*H*D)	220mm x 44mm x 172.5mm
Weight	800g

7. Troubleshooting & Maintenance

Problems	Causes	Solutions
Output image with snowflake	Bad quality of the connecting cable	Try another high quality cable.
	Fail or loose connection	Make sure the connection is good
No output image when switching	No signal at the input / output end	Check with oscilloscope or multimeter if there is any signal at the input/ output end.
	Fail or loose connection	Make sure the connection is good
	The switcher is broken	Send it to authorized dealer for repairing.
POWER indicator doesn't work or no respond to any operation	Fail connection of power cord.	Make sure the power cord connection is good.
EDID management does not work normally	The HDMI cable is broken at the output end.	Change for another HDMI cable which is in good working condition.
Static becomes stronger when connecting the video connectors	Bad grounding	Check the grounding and make sure it is connected well.
Cannot control the device by control device (e.g. a PC) through RS232 port	Wrong RS232 communication parameters	Type in correct RS232 communication parameters.
	Broken RS232 port	Send it to authorized dealer for checking.
Cannot control the device by front panel buttons while can control it through RS232 port	The front panel buttons are locked	Send command 50605% to unlock the front panel buttons.
Cannot control the device by RS232 / IR remote / front panel buttons	The device has already been broken.	Send it to authorized dealer for repairing.

If your problem persists after following the above troubleshooting steps, seek further help from authorized dealer or our technical support.

8. After-sales Service

If problems arise when operating the device, please refer to this user manual. Any transport costs are borne by the users during the warranty.

- 1) Product Limited Warranty:** We warrant that products will be free from defects in materials and workmanship for **three years**, which starts from the first day the product exits warehouse. (Make note of the serial number on the product)

Proof of purchase in the form of a bill of sale or receipted invoice **MUST** be presented to obtain warranty service.

2) What the warranty does not cover:

- Warranty expiration.
- Factory applied serial number has been altered or removed from the product.
- Damage, deterioration or malfunction caused by:
 - Normal wear and tear
 - Use of supplies or parts not meeting our specifications
 - No certificate or invoice as the proof of warranty.
 - The product model showed on the warranty card does not match with the model of the product for repairing or had been altered.
 - Damage caused by force majeure.
 - Servicing not authorized
 - Any other causes which does not relate to a product defect
- Delivery, installation or labor charges for installation or setup of the product

- 3) Technical Support:** Email or call our after-sales department if there are any problems or any unanswered questions. Please inform us the following information about your cases:

- Product version and name.
- Detailed failure situations.
- The formation of the cases.

Remarks: For any questions or problems, please try to get help from your local distributor or contact kanexpro.com or call us at 888-975-1368 for further support.

9. Warranty

A. LIMITED WARRANTY

KanexPro™ warrants that (a) its products (the “Product”) will perform greatly in agreement with the accompanying written materials for a period of 36 months (3 full years) from the date of receipt and (b) that the product will be free from defects in materials and workmanship under normal use and service for a period of 3 years.

B. CUSTOMER REMEDIES

KanexPro’s entire liability and Customer’s exclusive remedy shall be, at KanexPro option, either return of the price paid for the product, or repair or replacement of the Product that does not meet this Limited Warranty and which is returned to KanexPro with a copy of customers’ receipt. This Limited Warranty is void if failure of the Product has resulted from accident, abuse, or misapplication. Any replacement Product will be warranted for the remainder of the original warranty period of 3 years, whichever is longer.

C. NO OTHER WARRANTIES

To the maximum extent permitted by applicable law, KanexPro disclaims all other warranties, either express or implied, including, but not limited to implied warranties of merchantability and fitness for a purpose, with regard to the product and any related written materials. This limited warranty gives customers specific legal rights. Customers may have other rights depending on the jurisdiction.

D. NO LIABILITY FOR DAMAGES

To the maximum extent permitted by applicable law, in no event shall KanexPro be liable for any damages whatsoever (including without limitation, special, incidental, consequential, or indirect damages for personal injury, loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use this product, even if KanexPro has been advised of the possibility of such damages.

KanexPro[®]

1405 pioneer street

Brea, CA 92821