

User's Guide

TLNETCARD

Table of Contents

1. Introduction	2	3.2 Devices.....	15
1.1 System Requirements	2	3.2.1 Management.....	15
2. Installation and Configuration	3	3.3 System	19
2.1 SNMP Configuration	3	3.3.1 Administration	19
2.1.1 Configuring with TLNET Configurator.....	3	3.3.2 Notification	24
2.1.2 Configuring via TLNET Supervisor	4	4. TLNET Configurator	27
2.1.3 Configuring via Telnet	5	4.1 Batch Configuration	27
2.1.4 Configuring via Text Mode	6	4.2 Batch Upgrade	29
2.1.5 Configuring through COM Port	9	5. Modbus TCP	31
3. TLNET Supervisor	10	5.1 Configuration	31
3.1 Monitor.....	10	5.2 Operation.....	32
3.1.1 Information	10	6. Troubleshooting	40
3.1.2 History.....	13	Appendix A – Default System Settings	42
3.1.3 Environment.....	14	Appendix B – Default SNMP Settings.....	43
3.1.4 About	15		

Documentation Notice: This User's Guide is a supplement to the printed manual that came with your TLNETCARD or network-enabled Tripp Lite device. Refer to the printed manual for instructions on hardware installation and basic configuration, including IP address assignment. If you have misplaced your printed manual, refer to the downloadable electronic version by going to www.tripplite.com/support and entering **TLNETCARD** in the search window.



1111 W. 35th Street, Chicago, IL 60609 USA • www.tripplite.com/support

Copyright © 2016 Tripp Lite. All rights reserved. All trademarks are the sole property of their respective owners.

1. Introduction

TLNETCARD is an optional network card you can install in the accessory slot of a compatible UPS system. TLNETCARD connects your Tripp Lite device to your Ethernet network for remote monitoring, control and condition reporting. You can manage the device from an SNMP Network Management Station, a Web browser or telnet. The TLNETCARD can also send SNMP traps or email messages to the addresses you specify, alerting you automatically to events such as power failures.

1.1 System Requirements

- Tripp Lite UPS system with compatible accessory slot.
- Ethernet network that supports the TCP/IP protocol. Firewall ports 3664 and 3665 may need to be opened.
- One of the following options for remote monitoring and control:
 - SNMP-based Network Management Station (such as HP® OpenView®)
 - Web browser
 - VT-100 Telnet and/or SSH Client
- For “Terminal Mode” configuration only:
 - Terminal emulation software program (such as TeraTerm Pro by Ayera Technologies)
 - Computer with available DB9 serial port

Warning: *Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.*

2. Installation and Configuration

For instructions on hardware installation, refer to the printed manual that came with your TLNETCARD.

2.1 SNMP Configuration

There are multiple ways to configure the TLNETCARD:

- **TLNET Configurator:** Use the downloadable program TLNET Configurator to quickly set up one or more TLNETCARDS over the network. Refer to **Section 2.1.1** for more information.
- **Web-based Interface:** Individual TLNETCARDS can be configured over the network through their TLNET Supervisor interfaces. Refer to **Section 2.1.2** for more information.
- **Telnet Mode:** Configure the TLNETCARD over the network in text mode. Refer to **Section 2.1.4** for more information.
- **COM Port:** If a network connection is not available, the TLNETCARD can be configured through its COM port. Please refer to **Section 2.1.5** for more information.

Notes:

- When initially connected to the network, the TLNETCARD will attempt to obtain an IP address via DHCP. If DHCP is disabled on the network, the TLNETCARD can be accessed using its default IP address: **192.168.1.100**.
- To ensure system security, it is highly recommended that the account and password be changed after the first login.
- If multiple TLNETCARDS are installed on the network, it is advisable to change the TLNETCARD's default Host Name to avoid conflicts. Likewise, it is recommended to disable BOOTP/DHCP and manually assign a valid static IP address to the TLNETCARD.

2.1.1 Configuring with TLNET Configurator

The following instructions refer to the TLNETCARD Configurator utility software. The TLNETCARD Configurator can be downloaded at tripplite.com/support and typing TLNETCARD in the search field.


The TLNET Configurator utility (compatible with Windows 2000/2003/2008/XP/Vista/7) enables easy configuration and firmware upgrade of one or more TLNETCARDS. Follow the instructions below:

Step 1: Use a Cat5 cable to connect the TLNETCARD's Network port to the network.

Step 2: Ensure the two DIP switches of the TLNETCARD are set to the **OFF** position (Normal Mode) to enable network communication and that the workstation and the TLNETCARD are on the same LAN

Step 3: Once downloaded, launch TLNET Configurator.

Step 4: Click **Discover** to search all available SNMP devices on the LAN. A list of devices will be shown.




Notes:

- To search for SNMP devices in a different domain, change the Subnet and IPv4 IPv6 Prefix Length and click Discover.
- If the TLNETCARD cannot be found, verify that UDP port 3456 on the workstation is open.

2. Installation and Configuration


Step 5: Select the TLNETCARD to be modified from the Device List. Click **Modify** and enter the Administrator's account and password (default: **admin/password**, case sensitive).



The 'IP & Account' window is a modal dialog box with a title bar containing a close button. It contains the following fields and controls:

- SNMP Device Address:**
 - IP Address:** A text field containing '172 . 18 . 48 . 210'.
- Administrator Account:**
 - Account:** A text field containing 'admin'.
 - Default:** 'admin'.
 - Password:** A text field with masked characters (dots).
 - Default:** 'password'.
- OK:** A button at the bottom center.

Step 6: Click **Configuration** to modify network settings.



The 'Configuration' window is a modal dialog box with a title bar containing a close button. It contains the following sections and controls:

- System Identification:**
 - *Host Name (NetBIOS):** A text field containing 'TLNET'.
 - System Contactor:** A text field.
 - System Location:** A text field.
- Date/Time:**
 - *SNTP** (selected) or **Manual**.
 - Time Zone:** A dropdown menu showing 'GMT-06 Central Time'.
 - *1st Time Server Name or IP:** A text field containing 'POOL.NTP.ORG'.
 - 2nd Time Server Name or IP:** A text field.
 - Set Current Time:** Includes fields for **Date** (01/01/2000) and **Time** (00:00:00).
- User Limitation:**
 - Administrator:** ☐ In The LAN, ☒ Allow Any.
 - Device Manager:** ☐ In The LAN, ☒ Allow Any.
 - Read Only User:** ☐ In The LAN, ☒ Allow Any.
- IPV4:**
 - BOOTP/DHCP Client:** ☐ Enable, ☒ *Disable.
 - *IP Address:** 172 . 18 . 48 . 210.
 - *Subnet Mask:** 255 . 255 . 255 . 0.
 - Gateway IP:** 172 . 18 . 48 . 1.
 - DNS IP:** 172 . 18 . 0 . 18.
- IPV6:**
 - DHCPv6 Client:** ☐ Enable, ☒ *Disable.
 - *IP Address:** FE80::230:A8FF:FE28:2E4F.
 - *Prefix Length:** 64.
 - Gateway IP:** ::.
 - DNS IP:** ::.
- System Configuration:**
 - HTTP Server:** ☒ Enable, ☐ Disable.
 - Telnet Server:** ☒ Enable, ☐ Disable.
 - HTTP Server Port:** 80.
 - Telnet Server Port:** 23.
- Buttons:** 'Reset to Default', 'OK', and 'Cancel' at the bottom.
- Footnote:** '* Fields marked with an asterisk indicate recommended settings and inputs.'

Note: To complete set-up of the TLNETCARD, refer to **Section 3 TLNET Supervisor**.

2.1.2 Configuring via TLNET Supervisor

To configure an individual TLNETCARD via web browser, follow the instructions below:

Step 1: Use a Cat5 network cable to connect the TLNETCARD's Network port to the network. Launch a web browser and enter the TLNETCARD's IP address – whether assigned by DHCP/network administrator or the default (**192.168.1.100**) – in the address bar.

Step 2: Log in as Administrator (default account/password: **admin/password**, case sensitive).

2. Installation and Configuration

Step 3: Click **System** → **Administration** → **User Manager** to set up accounts and passwords under the “Local Authentication” section. The access permissions for the account types are as follows:

- 1) **Administrator:** Allowed to modify all settings.
- 2) **Device Manager:** Allowed to modify device-related settings.
- 3) **Read Only User:** Allowed to view settings only.

Manually specify whether users are allowed to log in from other LANs. If login attempts from external connections are to be blocked, select **Only in This LAN**. Otherwise, select **Allow Any**.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Home' and 'Logout' links, and the system time is displayed as 'Tue 12/22/2015 AM 09:36:36'. The left sidebar contains a 'User Manager' menu item. The main content area is titled 'System » Administration » User Manager'. It features a 'User Manager' section with a 'Use RADIUS' checkbox and fields for 'Server (51 chars max.)', 'Secret (32 chars max.)', and 'Port' (set to 1812). Below this is an 'RFC2865 Service Type' section with three columns: 'Administrator', 'Device Manager', and 'Read Only User'. Each column has a list of checkboxes for various services: 'Login User', 'Framed User', 'Callback Login', 'Callback Framed', 'Outbound', 'Administrative', 'NAS Prompt', 'Authenticate Only', 'Callback NAS Prompt', 'Call Check', and 'Callback Administrative'. The 'Read Only User' column has the 'Login User' checkbox checked. At the bottom is a 'Local Authentication' section with a table for 'Privilege', 'Account Name (16 chars max.)', 'Password (16 chars max.)', and 'Login Limitation'. The table has three rows: 'Administrator' (account: admin), 'Device Manager' (account: device), and 'Read Only User' (account: user). The 'Login Limitation' column has radio buttons for 'Only in This LAN' and 'Allow Any'. The 'Allow Any' option is selected for all three user types. A 'Submit' button is located at the bottom right of the form.

Step 4: Click **System** → **Administration** → **TCP/IP** to set Host Name, IP address, Subnet Mask and Gateway IP for the TLNETCARD.

Step 5: Click **Time Server** to manually set time and date for the system, or enable automatic time synchronization between the TLNETCARD and the time servers.

Note: To complete set-up of the TLNETCARD, refer to **Section 3 TLNET Supervisor**.

2.1.3 Configuring via Telnet

Step 1: Use a Cat5 network cable to connect the TLNETCARD's network port to the network.

Step 2: Connect the workstation (Windows or Linux) to the LAN that the TLNETCARD is connected to.

Step 3: For Windows, launch DOS prompt mode (**Start** → **Run** → key in **cmd** and press **Enter**). For Linux, launch Shell.

Step 4: Enter telnet <<IP Address>> to initiate telnet connection with the TLNETCARD.

Step 5: When connection is established, enter an Administrator's account and password (default: **admin/password**, case sensitive). The Main Menu will appear on the screen. Refer to **2.1.5 Configuring via Text Mode** for more information.

Notes:

- The TLNETCARD does not support more than one concurrent terminal session.
- The TLNETCARD terminates idle connections after 120 seconds.
- For complete configuration, refer to **Section 3 TLNET Supervisor**.

2. Installation and Configuration

2.1.4 Configuring via Text Mode

This section contains descriptions and default settings for configuring a TLNETCARD using a Telnet/SSH client such as HyperTerminal or PuTTY.

Main Menu

```
+=====+
|   Web Card Main Menu   |
+=====+
Web Card Version 01.12.04f
MAC Address 00-06-67-06-00-29
[1].User Manager
[2].TCP/IP Setting
[3].Network Parameter
[4].Time Server
[5].Soft Restart
[6].Reset System To Default
[7].Reset All To Default
[z].Exit Without Save
[0].Save And Exit
```

User Manager

```
+=====+
|   User Manager   |
+=====+
RADIUS
[1].RADIUS Auth:Disable
[2].Server:
[3].Secret:
[4].Port:      1812
-----
Local Auth
  Administrator
[5].Account:   admin
[6].Password:  *****
[7].Limitation: Allow Any
  Device Manager
[8].Account:   device
[9].Password:  *****
[a].Limitation: Allow Any
  Read Only User
[b].Account:   user
[c].Password:  *****
[d].Limitation: Allow Any
[0].Back To Previous Menu

Please Enter Your Choice => █
```

No.	Item	Description	Default
[1]	RADIUS Auth	Specifies whether RADIUS is allowed.	Disable
[2]	Server	The RADIUS server's name.	
[3]	Secret	The RADIUS secret.	
[4]	Port	The RADIUS port number.	1812
[5]	Administrator Account	The Administrator's default account/ password (case sensitive).	admin
[6]	Administrator Password		password
[7]	Administrator Limitation	Restricts Administrator login area.	Only in This LAN
[8]	Device Manager Account	The Device Manager's default account/password (case sensitive). This account is only permitted to change device-related settings.	device
[9]	Device Manager Password		password
[a]	Device Manager Limitation	Restricts Device Manager login area.	Only in This LAN
[b]	Read Only User Account	The Read-Only User's default account/ password (case sensitive). This account is only allowed to view settings.	user
[c]	Read Only User Password		password
[d]	Read Only User Limitation	Restricts Read-Only User login area.	Allow Any

2. Installation and Configuration

TCP/IP Setting

```

+=====+
|   TCP/IP Setting   |
+=====+
[1].IPv4 Address:      172.18.48.146
[2].IPv4 Subnet Mask:  255.255.255.0
[3].IPv4 Gateway IP:   172.18.48.1
[4].IPv4 DNS or WINS IP:172.18.0.18
[5].DHCPv4 Client:     Disable
[6].IPv6 Address:      fe80::230:abff:fe27:635b
[7].IPv6 Prefix Length: 64
[8].IPv6 Gateway IP:   ::
[9].IPv6 DNS IP:       ::
[a].DHCPv6:            Enable
[b].Host Name (NetBIOS): TLNET
[c].System Contact:
[d].System Location:
[e].Auto-Negotiation:  Enable
[f].Speed:             100M
[g].Duplex:             Full
[h].Status Stable:     1
[i].Telnet Idle Time:  120 Seconds
[0].Back To Previous Menu

Please Enter Your Choice => █

```

No.	Item	Description	Default
[1]	IPv4 Address	The IPv4 address.	192.168.001.100
[2]	IPv4 Subnet Mask	The IPv4 subnet mask setting.	255.255.255.000
[3]	IPv4 Gateway IP	The IPv4 gateway's IP address.	192.168.001.254
[4]	IPv4 DNS or WINS IP	IPv4 Domain Name Server or WINS IP.	192.168.001.001
[5]	DHCPv4 Client	Enable/Disable DHCPv4 protocol.	Enable
[6]	IPv6 Address	The IPv6 address.	
[7]	IPv6 Prefix Length	The IPv6 prefix length.	
[8]	IPv6 Gateway IP	The IPv6 gateway's IP address.	
[9]	IPv6 DNS IP	IPv6 Domain Name Server's IP address.	
[a]	DHCPv6	Enable/ Disable DHCPv6 protocol.	Enable
[b]	Host Name (NetBIOS)	The Host Name for the TLNETCARD.	TLNET
[c]	System Contact	The System Contact information.	
[d]	System Location	The System Location information.	
[e]	Auto-Negotiation	Enable/disable automatic transfer rate (10/100Mbps) negotiation.	Enable
[f]	Speed	If the Auto-Negotiation is disabled, you can specify the transfer rate.	100M
[g]	Duplex	If the Auto-Negotiation is disabled, you can specify the duplex mode.	Full
[h]	Status Stable	Status change confirmation check time.	3
[i]	Telnet Idle Time	Telnet connection time-out setting.	60 Seconds

Network Parameter

```

+=====+
|   Network Parameter   |
+=====+
[1].HTTP Server:      Enable
[2].HTTPS Server:     Enable
[3].Telnet Server:    Enable
[4].SSH/SFTP Server:  Enable
[5].FTP Server:       Disable
[6].Syslog:           Disable
[7].HTTP Server Port:  80
[8].HTTPS Server Port: 443
[9].Telnet Server Port: 23
[a].SSH Server Port:   22
[b].FTP Server Port:   21
[c].Syslog Server1:
[d].Syslog Server2:
[e].Syslog Server3:
[f].Syslog Server4:
[g].SNMP Get,Set Port: 161
[0].Back To Previous Menu

Please Enter Your Choice => █

```

No.	Item	Description	Default
[1]	HTTP Server	Enable/disable HTTP protocol.	Enable
[2]	HTTPS Server	Enable/disable HTTPS protocol.	Enable
[3]	Telnet Server	Enable/disable Telnet protocol.	Enable
[4]	SSH/SFTP Server	Enable/disable SSH/ SFTP protocol.	Enable
[5]	FTP Server	Enable/disable FTP protocol.	Disable
[6]	Syslog	Enable/disable remote Syslog.	Disable
[7]	HTTP Server Port	HTTP port.	80
[8]	HTTPS Server Port	HTTPS port.	443
[9]	Telnet Server Port	Telnet port.	23
[a]	SSH Server Port	SSH port.	22
[b]	FTP Server Port	FTP port.	21
[c]	Syslog Server 1	The Host Name of remote Syslog Server 1.	
[d]	Syslog Server 2	The Host Name of remote Syslog Server 2.	
[e]	Syslog Server 3	The Host Name of remote Syslog Server 3.	
[f]	Syslog Server 4	The Host Name of remote Syslog Server 4.	
[g]	SNMP Get, Set Port	The SNMP port.	161

2. Installation and Configuration

Time Server

You can manually adjust time and date for the TLNETCARD or set up automatic time server synchronization. The TLNETCARD, Windows XP and later versions support SNTP (Simple Network Time Protocol).

```
+=====+
|      Time Server      |
+=====+
[1].Time Selection:      SNTP
[2].Time Zone:          -6 hr
[3].1st Time Server:     POOL.NTP.ORG
[4].2nd Time Server:
[5].Manual Date:         01/01/2000 (MM/DD/YYYY)
[6].Manual Time:         00:00:00 (hh:mm:ss)
[0].Back To Previous Menu

Please Enter Your Choice => █
```

No.	Item	Description	Default
[1]	Time Selection	SNTP or manual.	SNTP
[2]	Time Zone	Adjust your time zone.	+0 hr
[3]	1st Time Server	The first time server for SNTP.	POOL.NTP.ORG
[4]	2nd Time Server	The second time server for SNTP.	
[5]	Manual Date	Set the date manually.	01/01/2000
[6]	Manual Time	Set the time manually.	00:00:00

Soft Restart

Reset the TLNETCARD. This will not affect the operation of the UPS.

Default Reset

Reset to factory defaults.

Exit Without Saving

Exit and ignore changes.

Save and Exit

Preserve your changes and exit.

2. Installation and Configuration

2.1.5 Configuring through COM Port

If a network connection is not available, the TLNETCARD can be configured via COM port connection. Follow the instructions below:

Note: If running a non-Windows system, refer to your system's user manual for Telnet clients.

Step 1: Use the provided RJ45 to DB9 cable to connect the TLNETCARD's COM port to the workstations' COM port.


Step 2: Ensure the TLNETCARD's two DIP switches are set to the **OFF** position (Normal Mode).

Step 3: For Windows 2000, 2003, 2008 and XP, go to **Start → Programs → Accessories → Communications** and select **HyperTerminal**.

Note: Microsoft has removed HyperTerminal from Windows Vista and later versions. If the OS does not include the program, a free alternative Telnet/SSH client PuTTY can be downloaded from <http://www.putty.org>.

Step 4: Enter a name, choose an icon for the connection and click **OK**. From the **Connect** drop-down menu, select the COM port that is connected to the TLNETCARD.

Step 5: Click **Configure** and set up COM port parameters as follows:



Step 6: Click **OK** to continue. Set the two DIP switches of the TLNETCARD to the ON position (Configuration Mode). HyperTerminal will automatically connect to the TLNETCARD; if it doesn't, click the telephone icon in the tool bar. When connection is established, log in with an Administrator's account/password (default: **admin/password**, case sensitive). Once logged in, the Main Menu appears on the screen. Refer to the next section for more information.




3. TLNET Supervisor

To configure the TLNETCARD via the TLNET Supervisor, follow the steps below:

Step 1: Ensure the TLNETCARD is connected to the LAN.

Step 2: The login page will appear when a connection is established. Enter the account and password (default: **admin/ password**).



Notes:

- If unable to log in with the correct account and password, additional network configuration may be needed. The IP subnet of the computer may be different from the TLNETCARD's.
- The TLNETCARD will automatically log off if the connection is idle for 30 minutes.

The TLNET Supervisor contains three main sections: **Monitor**, **Device** and **System**. Refer to **Sections 3.1 - 3.3** for more information.


3.1 Monitor

3.1.1 Information

Note: Because the information provided by a UPS differs by model, the web page will display different information accordingly.

UPS Properties

Go to **Monitor** → **Information** → **UPS Properties** for a status overview of the UPS system's primary parameters. The values will update automatically.



TLNET Supervisor

System Time : Wed 12/16/2015 PM 11:06:12

Monitor » Information » UPS Properties

Input

Volt_{L-N}: 123.0 V
Freq: 59.6 Hz
[Detail...](#)

UPS Status

Model: TRIPP LITE SMART1000RM2U
Type: Line interactive
Rating: 1kVA
Comm.: OK
Source: Normal
[Detail...](#)

Output

Volt_{L-N}: 123.0 V
Load: 0 %
Freq: 59.6 Hz
[Detail...](#)

Schedule

Next Power Off Time: None
Next Power On Time: None
Next Test Time: None
[Weekly...](#)
[Specific...](#)

Battery

Status: Normal
Capacity: 100 %
[Detail...](#)

Countdown

Time To Power Off: --:--
Estimated OS Delay: --:--

[Event Log...](#)

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

3. TLNET Supervisor

Battery Parameters

Go to **Monitor** → **Information** → **Battery Parameters** to view Battery Status, Battery Measurement and Battery Replacement Date.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Monitor', 'Device', and 'System'. The left sidebar lists 'UPS Properties', 'Battery Parameters', 'In/Out Parameters' (selected), 'Identification', 'Status Indication', and 'Shutdown Agent'. The main content area is titled 'Monitor » Information » In/Out Parameters' and displays three measurement panels: 'Input Measurement', 'Output Measurement', and 'Bypass Measurement'. Each panel shows data for P-1, P-2, and P-12 points.

Parameter	P-1	P-2	P-12
Frequency	60.0 Hz	60.0 Hz	-
Voltage	125.6 V	125.0 V	-
Voltage	218.0 V	-	-

Parameter	P-1	P-2	P-12
Output Source	Normal		
Frequency	60.0 Hz	-	-
Voltage	119.9 V	119.9 V	-
Current	0.0 A	0.0 A	-
Power	0 W	0 W	-
Loading	0 %	0 %	-
Voltage	-	-	208.0 V

Parameter	P-1	P-2	P-12
Frequency	60.0 Hz	-	-
Voltage	125.5 V	124.8 V	-
Current	0.0 A	0.0 A	-
Power	0 W	0 W	-
Voltage	-	-	217.7 V

In/Out Parameters

Go to **Monitor** → **Information** → **In/Out Parameters** to view Input Measurement, Bypass Measurement, Output Measurement and Outlet Bank.

The screenshot shows the TLNET Supervisor web interface with the 'Battery Parameters' section selected in the sidebar. The main content area is titled 'Monitor » Information » Battery Parameters' and displays two panels: 'Battery Parameters' and 'Replacement Date'.

Parameter	Value
Battery Status	Normal
On Battery Time	0 Seconds
Battery Capacity	100 %
Voltage	217.6 V
Temperature	22 °C
Remaining Time	11:26 hh:mm

Parameter	Value
Last Battery Replacement Date	06/01/2007 (MM/DD/YYYY)
Next Battery Replacement Date	06/01/2010 (MM/DD/YYYY)

Identification

Go to **Monitor** → **Information** → **Identification** to view the system Identification and UPS Rating.

The screenshot shows the TLNET Supervisor web interface with the 'Identification' section selected in the sidebar. The main content area is titled 'Monitor » Information » Identification' and displays two panels: 'Identification' and 'UPS Rating'.

Parameter	Value
Model	SU6000RT3UPM
Type	On line
UPS Firmware	0.1
Interface Firmware	01.12.04f
Interface Serial Number	2604ALCAC897C00042
MAC Address	00-06-67-06-00-29

Parameter	Value
VA	6 kVA
Power	4.2 kW
Input Voltage	208 V
Output Voltage	208 V
Bypass Voltage	605 V
Frequency	60.0 Hz
Battery Voltage	274 V
High Transfer Voltage	276 V
Low Transfer Voltage	156 V

3. TLNET Supervisor

Status Indication

Go to **Monitor** → **Information** → **Status Indication** to view the status of various UPS parameters. When an event occurs, its corresponding icon changes color.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Monitor', 'Device', and 'System'. The left sidebar lists various monitoring options, with 'Status Indication' selected. The main content area displays a 'Status Indication' section with a list of 24 status indicators, each with a green checkmark icon. The indicators are organized into three columns. The first column includes 'Buzzer Enabled'. The second column includes 'UPS Disconnect', 'Buzzer Alarm', 'Input Out Of Range', 'Battery Low', 'Battery Depleted', 'Battery Needs Replacement', 'Battery Ground Fault', 'Test In Progress', 'Test Failure', 'Output Off', 'On Bypass', 'UPS System Off', 'UPS Shutdown', and 'Output Breaker'. The third column includes 'Output Over Voltage', 'Output Under Voltage', 'Overload', 'Temperature Out Of Range', 'Other Warning', 'Fan Abnormal', 'Fuse Abnormal', 'Inverter Abnormal', 'Charger Abnormal', 'Bypass Out Of Range', 'Emergency Power Off', 'Phase Asynchronous', and 'Rectifier Abnormal'. The footer of the interface shows the copyright notice: 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

ShutdownAgent

Go to **Monitor** → **Information** → **Shutdown Agent** to view the designated PCs' shutdown information, including IP Address, Operating System, Countdown, Reason and Last Touch.

This page will only appear if:

- The PCs are connected to the UPS using this TLNETCARD.
- The PCs have TLNET Shutdown Agent installed on them.
- In **System** → **Administration** → **SNMP Trap**, the PCs' IP Addresses have been entered in the Target IP field and TLNET Shutdown Agent has been selected from the Trap Category's pull-down menu.

The screenshot shows the TLNET Supervisor web interface with the 'Shutdown Agent' page selected. The left sidebar lists various monitoring options, with 'Shutdown Agent' selected. The main content area displays a 'Shutdown Agent' section with a table showing shutdown information for a single PC. The table has five columns: 'IP Address', 'OS', 'Countdown (sec)', 'Reason', and 'Last Touch (sec)'. The data row shows an IP address of 172.18.48.97, OS of Microsoft Windows 7 Enterprise Edition Service Pack 1 (build 7601), 64-bit, a countdown of 3 seconds, and a reason of None. The footer of the interface shows the copyright notice: 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

3. TLNET Supervisor

3.1.2 History

Event Log

Go to **Monitor** → **History** → **Event Log** → **selected pages** to view events that have occurred. The log overwrites entries when the maximum (1,000) is reached. The event archive can be downloaded (event_log.xls) by pressing the **Download All** button.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

System Time : Fri 01/08/2016 PM 01:34:38

Monitor Device System

Information History About

Event Log

Monitor » History » Event Log » Page1

Event Log

Page: 1 2 3 4 5 Download All

From: 01/05/2016 (MM/DD/YYYY) to 01/05/2016 (MM/DD/YYYY) Apply

Date	Time	Level	Event Log
01/06/2016	14:02:38	Information	Shutdown Agent(IP=172.18.48.97, host=R2-R210II-1) communication established
01/06/2016	12:01:20	Warning	Shutdown Agent(IP=172.18.48.97, host=R2-R210II-1) communication lost
01/05/2016	16:38:29	Warning	Shutdown Agent(IP=172.18.48.97, host=) communication lost
01/05/2016	16:00:09	System	admin login to the WEB from 172.18.48.110
01/05/2016	14:41:53	System	admin login to the WEB from 172.18.48.110
01/05/2016	13:39:24	System	admin login to the WEB from 172.18.21.241
01/05/2016	11:44:38	System	admin login to the TELNET from 172.18.48.110
01/05/2016	11:37:09	Warning	Shutdown Agent(IP=172.18.48.97, host=) communication lost
01/05/2016	11:35:59	System	The time has been synchronized through SNTP.
01/05/2016	17:32:48	System	admin login to the WEB from 172.18.48.110
01/05/2016	16:46:33	System	admin login to the WEB from 172.18.48.110
01/05/2016	16:45:40	System	admin login to the WEB from 172.18.48.110
01/05/2016	16:42:19	System	System startup
01/05/2016	16:42:19	System	The time has been synchronized through SNTP.
01/05/2016	10:41:21	System	Soft reboot

• Download Event Log from UPS

The TLNETCARD sends a request to the UPS, collects the event logs saved there, then replies to the user through the network. This option only appears when the UPS supports this function; the event logs saved in the UPS may be different from the event logs saved in the TLNETCARD.

Data Log

Go to **Monitor** → **History** → **Data Log** to view saved device data. The data archive can be downloaded (data_log.xls) by pressing the **Download** button.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

System Time : Fri 01/08/2016 PM 01:56:20

Monitor Device System

Information History Environment About

Event Log

Data Log

Configure

Monitor » History » Data Log » 01/05/2016 ~ 01/05/2016

Data Log

From: 01/05/2016 (MM/DD/YYYY) to 01/05/2016 (MM/DD/YYYY) Apply Download

Date	Time	In Freq	In Volt		In Amp	In Pwr	Out Freq	Out Volt	Out Amp	Out Pwr	Out Load	By Freq	By Volt
			Lo	Hi									
01/05/2016	23:57:09	59.9Hz	121.0V	122.2V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	23:47:09	59.9Hz	120.6V	121.4V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	23:37:09	59.9Hz	121.0V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	23:27:09	59.9Hz	121.0V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	23:17:08	59.9Hz	120.6V	121.4V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	23:07:08	59.9Hz	119.1V	121.4V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:57:09	59.9Hz	120.6V	121.8V			60.0Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:47:09	59.9Hz	120.6V	121.4V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:37:09	59.9Hz	121.0V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:27:08	59.9Hz	120.6V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:17:08	59.9Hz	121.0V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	22:07:09	59.9Hz	121.0V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	21:57:08	59.9Hz	120.6V	121.4V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	21:47:08	59.9Hz	120.6V	121.8V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	21:37:09	59.9Hz	121.0V	122.2V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	21:27:08	59.9Hz	121.4V	122.5V			59.9Hz	119.8V	0.0A	0W	0%		
01/05/2016	21:17:08	59.9Hz	121.0V	122.2V			59.9Hz	119.8V	0.0A	0W	0%		

3. TLNET Supervisor

Configure

Go to **Monitor** → **History** → **Configure** to clear the data and event logs and also to assign the Save Data Interval.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

Home Logout

System Time : Fri 01/08/2016 PM 01:57:10

Monitor Device System

Information History Environment About

Event Log

Data Log

Configure

Monitor » History » Configure

Data Log

Clear Data Log

Save Data Interval: 10 minute(s)

Apply

Event Log

Clear Event Log

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

- **Clear Data Log:** Empties the data log only.
- **Clear Event Log:** Empties the event log only.
- **Save Data Interval:** The time interval at which data is recorded.

3.1.3 Environment

The Environment page is displayed only when a TLNETEM is used. TLNETCARD's DIP switch 1 should be set to the ON position and DIP switch 2 should be set to the OFF position when using a TLNETEM. For more information about the TLNETEM, refer to its Owner's Manual

Information

Go to **Monitor** → **Environment** → **Information** to view the TLNET's readings and settings.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

Home Logout

System Time : Fri 01/08/2016 PM 01:57:31

Monitor Device System

Information History Environment About

Information

Configuration

Monitor » Environment » Information

Information

Sensor Information	Input Contacts	Contact Setting
Temperature: 24.0 °C	Smoke(R1): Normal	Smoke(R1): Normal Open
75.2 °F	Fire(R2): Normal	Fire(R2): Normal Open
Humidity: 39 %	Leak(R3): Normal	Leak(R3): Normal Open
	Door(R4): Normal	Door(R4): Normal Open

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

Configuration

Go to **Monitor** → **Environment** → **Configuration** to configure the TLNETEM's thresholds and other settings.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

Home Logout

System Time : Fri 01/08/2016 PM 01:57:52

Monitor Device System

Information History Environment About

Information

Configuration

Monitor » Environment » Configuration

Sensor Configuration

Sensor	Low Limit	High Limit
Temperature	60 °F	105 °F
Humidity	20 %	80 %

Input Contact Configuration

Input	Title	Type	Smart Shutdown
Contact 1	Smoke	Normal Open	<input type="checkbox"/>
Contact2	Fire	Normal Open	<input type="checkbox"/>
Contact3	Leak	Normal Open	<input type="checkbox"/>
Contact4	Door	Normal Open	<input type="checkbox"/>

Submit

3. TLNET Supervisor

3.1.4 About Information

Go to **Monitor** → **About** → **Information** to view the TLNET Supervisor version and information about the OpenSSL toolkit and licenses.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Monitor', 'Device', and 'System'. The left sidebar has 'Information', 'History', 'Environment', and 'About'. The main content area is titled 'Monitor » About » Information' and displays the following information:

TrippLite TLNET Supervisor
Version : 01.12.04d

TLNET Supervisor utilizes the "OpenSSL toolkit" functionality provided by "The Open SSL Project" at <http://www.openssl.org/>. SDI acknowledges all patent rights therein.

The OpenSSL toolkit is licensed under a dual-license (the OpenSSL license and the original SSLeay license).
[See the license text.](#)

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

3.2 Devices

3.2.1 Management

Because functions will vary by model, all UPS systems will not necessarily support all of the configurations or control items stated below.

Reaction

Go to **Device** → **Management** → **Reaction** to enable and adjust the parameters under which UPS Shutdown and Smart Shutdown are executed.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Monitor', 'Device', and 'System'. The left sidebar has 'Management', 'Reaction', 'Configure', 'Control', 'Weekly Schedule', 'Specific Schedule', and 'Event Level'. The main content area is titled 'Device » Management » Reaction' and displays the following configuration options:

Reaction

Event	UPS Shutdown Delay (in seconds)
1 Power Failure	<input type="checkbox"/> 0
2 Battery Low	<input type="checkbox"/> 0
3 Overload	<input type="checkbox"/> 0

Smart Shutdown

Estimated OS Shutdown Delay: 300
UPS Shutdown Delay: 60

☐ Perform Smart Shutdown in Schedule

Description: Smart Shutdown performs a safe shutdown of all connected computers, with one click. Enter the estimated time required to shutdown the OS of the computers which have the shutdown software installed and are connected to this card. Enter the time the card will wait before sending the shutdown command to the UPS, after the OS Shutdown Delay time has elapsed.

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

- **UPS Shutdown Delay**

Select the checkbox for each event that is to be a trigger for UPS Shutdown. Enter the time period the system will wait after the trigger event occurs before shutting down the UPS.

- **Smart Shutdown**

Smart Shutdown performs a safe shutdown of all connected computers and then the UPS, with one click. Enter the estimated time required to shutdown the OS of the computers which have the shutdown software installed and are connected to the TLNETCARD.

Enter the time period the TLNETCARD will wait before sending the shutdown command to the UPS, after the OS Shutdown Delay time has elapsed.

Select the Perform Smart Shutdown in Schedule checkbox in order to execute a Smart Shutdown when "Shutdown" is selected as the action in either of the Schedules.

3. TLNET Supervisor

Configure

Go to **Device** → **Management** → **Configure** to configure the UPS. The configuration values are saved in the UPS or in the TLNETCARD.

Note: For each of the following items, the Submit button must be pressed for the modified settings to take effect.

The screenshot shows the TLNET Supervisor web interface. At the top, there is a header with the TRIPP-LITE logo, the title 'TLNET Supervisor', and links for 'Home' and 'Logout'. Below the header is a navigation bar with tabs for 'Monitor', 'Device', and 'System'. The 'Device' tab is selected, and a sub-menu shows 'Management' as the active section. On the left side, there is a sidebar with a list of configuration options: 'Reaction', 'Configure' (highlighted with a blue arrow), 'Control', 'Weekly Schedule', 'Specific Schedule', and 'Event Level'. The main content area is titled 'Device » Management » Configure'. It features a 'Configure' section with a list of options: 'Auto-Restart' (selected), 'UPS Buzzer', 'Voltage Sensitivity', 'Transfer Voltage', 'Low Battery Alarm', 'Battery Replacement Date', 'Economy Mode', 'Output Voltage Selection', and 'Output Frequency Selection'. To the right of this list, there is a form for 'Auto Restart' settings, including a checkbox for 'Reboot After Power Restore' (checked and labeled 'Enable') and a text field for 'Boot Delay After Power Restore' set to '0' seconds. A 'Submit' button is located below these settings. A 'Refresh' button is positioned at the bottom of the configuration list.

- **Auto Restart**

Enables or disables auto restart after power has been restored.

- **UPS Buzzer**

Enables or disables the UPS buzzer.

- **Voltage Sensitivity**

This feature is not yet supported.

- **Transfer Voltage**

Sets the desired levels for Low and High Transfer voltage.

- **Low Battery Alarm**

When selected, this option will trigger a low battery alarm if the reported battery level falls below the one assigned in the provided text field.

- **Battery Replacement Date**

Dates can be entered as a record for battery maintenance purposes. Selecting the checkbox will enable pop-up notifications to appear at a frequency set in the text box.

- **Bypass Transfer Frequency**

After you set a tolerance of bypass transfer frequency and confirm your setup, the TLNETCARD will send the command to the UPS. If the UPS transfers to bypass mode and the bypass frequency is out of the tolerance, output will be turned off and critical loads will be protected.

- **Periodic Auto Test**

Enables the UPS to automatically perform a battery test at a period determined by the pulldown menu selection.

- **Economy Mode**

Enables greater electrical efficiency by suspending double conversion when the power quality is determined to be satisfactory.

- **Outlet Shed / Ramp**

Ramp allows controllable loads to be turned on in a prescribed order when a specified trigger event takes place. For instance, when the UPS returns from an on battery event (i.e. trigger = no longer on battery).

Shed allows controllable loads to be turned off in a prescribed order when a specified trigger event takes place. For instance, when the UPS goes to battery (i.e. trigger = on battery).

3. TLNET Supervisor

Control

Go to **Device** → **Management** → **Control** to configure relevant control commands.

Note: For each of the following items, the **Submit** button must be pressed for the specified control to be executed.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

Home Logout

System Time : Tue 12/22/2015 AM 11:06:48

Monitor Device System

Management

Reaction

Configure

Control

Weekly Schedule

Specific Schedule

Event Level

Device » Management » Control

Control

Select UPS Control:

Battery Test

Shutdown & Restart UPS Only

Smart Shutdown

Outlet Control

Outlet Shed/Ramp

Power Failure/Restore Simulation

Battery Test

Battery Test Type: 10-Second Test

Submit

- **Battery Test**

This control executes a 10-second battery test.

- **Shutdown & Restart UPS Only**

Upon pressing **Submit**, the UPS will shut down and/or restart per the parameters specified in this section.

- **Outlet Control**

Press the **Execute** button to control the corresponding outlet bank (on or off).

- **Power Failure/Restore Simulation**

Click the **Power Failure Test** or **Power Restore Test** button to simulate a power failure or power restore event. This function verifies functionality of the connected software. The simulation will not influence UPS operations; the UPS remains in its existing UPS mode and will not transfer to battery.

Weekly Schedule

Go to **Device** → **Management** → **Weekly Schedule** to arrange a weekly schedule for the UPS. Select the day(s) and time for a specified action (No Action, Shutdown, Restart, 10-Second Test) to take place.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

Home Logout

System Time : Tue 12/22/2015 AM 11:29:37

Monitor Device System

Management

Reaction

Configure

Control

Weekly Schedule

Specific Schedule

Event Level

Device » Management » Weekly Schedule

Weekly Schedule

	Action	SUN	MON	TUE	WED	THR	FRI	SAT	Time(hh:mm) 24-hr
1	10-Second Test	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	13:11
2	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
3	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
4	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
5	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00
6	No Action	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	00:00

Submit

3. TLNET Supervisor

Specific Schedule

Go to **Device** → **Management** → **Specific Schedule** to arrange a specific schedule for the UPS. Select the calendar day(s) and time for a specified action (No Action, Shutdown, Restart, 10-Second Test) to take place.

The screenshot shows the 'Specific Schedule' configuration page in the TLNET Supervisor interface. The page has a sidebar with navigation options: Reaction, Configure, Control, Weekly Schedule, **Specific Schedule** (selected), and Event Level. The main content area is titled 'Device » Management » Specific Schedule'. It contains a table with 10 rows for scheduling events. Each row has columns for 'Date(MM/DD/YYYY)', 'Time(hh:mm) 24-hr', and 'Action'. All dates are set to '01/01/2000' and all times are set to '00:00'. The 'Action' column has a dropdown menu with 'Stop Action' selected. A 'Submit' button is at the bottom right of the table.

	Date(MM/DD/YYYY)	Time(hh:mm) 24-hr	Action
1	01/01/2000	00:00	Stop Action
2	01/01/2000	00:00	Stop Action
3	01/01/2000	00:00	Stop Action
4	01/01/2000	00:00	Stop Action
5	01/01/2000	00:00	Stop Action
6	01/01/2000	00:00	Stop Action
7	01/01/2000	00:00	Stop Action
8	01/01/2000	00:00	Stop Action
9	01/01/2000	00:00	Stop Action
10	01/01/2000	00:00	Stop Action

Event Level

Go to **Device** → **Management** → **Event Level** to assign severity levels for each event.

The screenshot shows the 'Event Level' configuration page in the TLNET Supervisor interface. The page has a sidebar with navigation options: Reaction, Configure, Control, Weekly Schedule, Specific Schedule, and **Event Level** (selected). The main content area is titled 'Device » Management » Event Level'. It contains a section for 'Event Level' with a dropdown menu set to 'Alarm' and an 'Update' button. Below this is a table with 15 rows for event descriptions and their assigned levels. The levels are color-coded: red for 'Alarm' and yellow for 'Warning'.

	Event Description	Level
1	UPS temperature out of range	Alarm
2	UPS temperature back to normal	Alarm
3	Power failure	Warning
4	Power restored	Warning
5	Output abnormal	Alarm
6	Recover from output abnormal	Alarm
7	Overload	Alarm
8	Recover from overload	Alarm
9	Bypass abnormal	Alarm
10	Recover from bypass abnormal	Alarm
11	Turn UPS output off	Alarm
12	Turn UPS output on	Alarm
13	UPS shutdown	Warning
14	Recover from UPS shutdown	Warning
15	Charger abnormal	Alarm

3. TLNET Supervisor

3.3 System

The System pages are accessible only to users with Administrator privileges.

3.3.1 Administration

User Manager

The TLNETCARD supports RADIUS. Check the **Use RADIUS** box, enter the required Server, Secret and Port (default: 1812) information, then click **Submit**. The three user levels can be defined. If RADIUS is disabled, the Account Name, Password and Login Limitation can be managed via Local Authentication.

The screenshot shows the 'User Manager' configuration page in the TLNET Supervisor interface. The page is divided into two main sections: 'RADIUS' and 'Local Authentication'. The 'RADIUS' section is currently active, showing fields for 'Server (51 chars max.)', 'Secret (32 chars max.)', and 'Port' (set to 1812). Below these are three columns of checkboxes for 'Administrator', 'Device Manager', and 'Read Only User' roles, categorized by 'RFC2865 Service Type'. The 'Local Authentication' section is also visible, showing fields for 'Privilege', 'Account Name (16 chars max.)', 'Password (16 chars max.)', and 'Login Limitation' for the same three roles. A 'Submit' button is at the bottom right.

TCP/IP

The screenshot shows the 'TCP/IP' configuration page in the TLNET Supervisor interface. The page is divided into two main sections: 'TCP/IP Settings for IPv4' and 'TCP/IP Settings for IPv6'. The 'IPv4' section is currently active, showing fields for 'DHCP Client' (set to Disable), 'IP Address' (172.18.48.144), 'Subnet Mask' (255.255.255.0), 'Gateway IP' (172.18.48.1), 'DNS IP' (172.18.0.18), and 'Search Domain' (tripplite.com). The 'IPv6' section is also visible, showing fields for 'DHCP Client' (set to Enable), 'IP Address' (fe80::230:abff:fe20::), 'Prefix Length' (64), 'Gateway V6IP', and 'DNS V6IP'. A 'Submit' button is at the bottom right.

• TCP/ IP Settings for IPv4

- 1) **DHCP Client:** Enable/Disable DHCP. If enabled, the DHCP server automatically assigns an IP address to the TLNETCARD.
- 2) **IP Address:** The IP address in dotted format.
- 3) **Subnet Mask:** The Subnet Mask for the network.
- 4) **Gateway IP:** The IP address for the network gateway in dotted format.
- 5) **DNS IP:** The IP address Domain Name Server in dotted format.
- 6) **Search Domain:** If the domain entered cannot be found, the system defaults to the Host Name.

3. TLNET Supervisor

- **TCP/ IP Settings for IPv6**

- 1) **DHCP Client:** Enable/Disable DHCP. If enabled, the DHCP server automatically assigns an IP address to the TLNETCARD.
- 2) **IP Address:** The IPv6 address.
- 3) **Prefix Length:** The prefix length for the IPv6 address.
- 4) **Gateway V6IP:** The IP address for the IPv6 network gateway.
- 5) **DNS V6IP:** The IP address for the IPv6 domain name server.

- **System**

- 1) **Host Name:** The SNMP IPv6 Host Name on the network.
- 2) **System Contact:** System contact information.
- 3) **System Location:** System location information.

- **Link**

- 1) **Auto-Negotiation:** Enable/Disable automatic transfer rate (10/100Mbps) negotiation.
- 2) **Speed:** If the Auto-Negotiation is disabled, the transfer rate can be specified.
- 3) **Duplex:** If the Auto-Negotiation is disabled, the duplex mode can be specified.

Web

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title 'TLNET Supervisor', and links for 'Home' and 'Logout'. Below the header is a navigation bar with tabs for 'Monitor', 'Device', and 'System'. The 'System' tab is active, and within it, the 'Administration' sub-tab is selected. A left sidebar lists various system functions: User Manager, TCP/IP, Web (highlighted), Console, FTP, Time Server, Syslog, Batch Configuration, and Upgrade. The main content area is titled 'System » Administration » Web' and contains two configuration panels. The 'Web' panel has radio buttons for 'HTTP' and 'HTTPS' (both set to 'Enable'), input fields for 'HTTP Port' (80) and 'HTTPS Port' (443), and a 'Web Refresh Period' of 10 seconds. The 'SSL Certificate' panel shows a 'Certificate File (PEM format)' section with a 'Browse...' button and the text 'No file selected'. A 'Submit' button is located at the bottom right of the configuration area. A copyright notice at the bottom reads 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

- **Web**

- 1) **HTTP:** Enable/ disable HTTP connection.
- 2) **HTTPS:** Enable/ disable HTTPS connection.
- 3) **HTTP Port:** Assign an HTTP port number (default: 80).
- 4) **HTTPS Port:** Assign an HTTPS port number (default: 443).
- 5) **Web Refresh Period:** Enter a time period (in seconds).

- **SSL Certificate**

- 1) To ensure connection security between the TLNETCARD and the connecting workstation, an SSL certificate can be used to encrypt and secure the integrity of transmitted data.
- 2) Certificate File: The TLNETCARD supports PEM format which is generated by OpenSSL. Click **Choose File** to upload a certificate file.

Note: For more information about generating a private SSL certificate file, visit <http://www.openssl.org/>.

3. TLNET Supervisor

Console

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". The system time is displayed as "Tue 12/22/2015 AM 11:21:47". The navigation menu on the left includes "Monitor", "Device", and "System". Under "System", there are sub-menus for "Administration" and "Notification". The "Administration" sub-menu is expanded, showing options like "User Manager", "TCP/IP", "Web", "Console", "FTP", "Time Server", "Syslog", "Batch Configuration", and "Upgrade". The "Console" option is selected, and the main content area displays the "System » Administration » Console" configuration page. This page has three sections: "Console", "Host Key", and "Authentication Public Key". The "Console" section has radio buttons for "Telnet" (selected) and "Disable", and "SSH/SFTP" (selected) and "Disable". It also has input fields for "Telnet Port" (23) and "SSH Port" (22). The "Host Key" section has "DSA Key" and "RSA Key" fields, each with a "Browse..." button and the text "No file selected.". The "Authentication Public Key" section has a "Public Key" field with a "Browse..." button and the text "No file selected.". A "Submit" button is at the bottom right.

- **Telnet:** Enable/ disable Telnet connection.
- **SSH/ SFTP:** Enable/ disable SSH/ SFTP connection.
- **Telnet Port:** Assign a Telnet port number (default: 23).
- **SSH Port:** Assign an SSH protocol port number (default: 22).
- **Host Key/ Authentication Public Key:** The TLNETCARD supports files generated by OpenSSH, including DSA, RSA, and Authentication Public Keys.

FTP

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". The system time is displayed as "Tue 12/22/2015 AM 11:24:05". The navigation menu on the left includes "Monitor", "Device", and "System". Under "System", there are sub-menus for "Administration" and "Notification". The "Administration" sub-menu is expanded, showing options like "User Manager", "TCP/IP", "Web", "Console", "FTP", "Time Server", "Syslog", "Batch Configuration", and "Upgrade". The "FTP" option is selected, and the main content area displays the "System » Administration » FTP" configuration page. This page has a section for "FTP" with radio buttons for "Enable" and "Disable" (selected). It also has an input field for "FTP Port" (21) and a "Submit" button.

- **FTP:** Enable/ disable FTP connection.
- **FTP Port:** Assign an FTP port number (default: 21).

3. TLNET Supervisor

Time Server

The time and date can be automatically synchronized with SNTP servers or manually entered; select the desired option. If the SNTP server is not responsive, the event and data log will not register even when SNTP is enabled.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". Below this is a status bar showing "System Time : Fri 01/08/2016 PM 02:01:31". The main menu on the left lists various system functions: Monitor, Device, System, Administration, and Notification. The "System" menu is currently selected, and the "Time Server" sub-menu is active. The main content area displays the "System » Administration » Time Server" configuration page. It features two tabs: "Simple Network Time Server" and "Manual". The "Simple Network Time Server" tab is selected, showing fields for "Time Zone" (a dropdown menu), "Primary Time Server" (a text input field), "Secondary Time Server" (a text input field), and a checkbox for "Enable Daylight Saving (MM/DD)" with a date range from "04/01" to "11/01". The "Manual" tab is also visible, showing a "Set Current Time" section with a checkbox for "Refer to Local PC Time", a "Date" field (MM/DD/YYYY), and a "Time" field (hh:mm:ss). A "Submit" button is located at the bottom right of the configuration area. The footer of the page states "Copyright © 2015 Tripp Lite, Inc. All Rights Reserved."

• Simple Network Time Server

- 1) **Time Zone:** From the dropdown menu, select the time zone for the location where the TLNETCARD is located.
- 2) **Primary/ Secondary Time Server:** Two time servers can be added. Every 60 minutes, the TLNETCARD synchronizes with the first responding server.
- 3) **Enable Daylight Saving:** Check to enable daylight saving time.

• Manual

If a time server is not accessible, the time and date can be linked to the local PC or set manually. Note that in the event of a power loss, the time and date may need to be re-entered once power is restored.

Syslog

Syslog is used to store the event log on remote Syslog servers. This will not affect the local event log. Upon selecting the Enable option, enter the IP Addresses of up to four (max) Syslog servers.

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". Below this is a status bar showing "System Time : Fri 01/08/2016 PM 02:02:08". The main menu on the left lists various system functions: Monitor, Device, System, Administration, and Notification. The "System" menu is currently selected, and the "Syslog" sub-menu is active. The main content area displays the "System » Administration » Syslog" configuration page. It features a "Syslog" section with a radio button for "Enable" and a radio button for "Disable". Below this are four text input fields for "Syslog Server 1", "Syslog Server 2", "Syslog Server 3", and "Syslog Server 4". A "Submit" button is located at the bottom right of the configuration area. The footer of the page states "Copyright © 2015 Tripp Lite, Inc. All Rights Reserved."

3. TLNET Supervisor

Batch Configuration

The TLNETCARD supports batch configuration for quick and effortless setup of multiple SNMP devices. Configuration information uploaded from a source device can be downloaded onto individual target devices using the TLNET Supervisor, or onto multiple target devices using the TLNET Configurator (see **Section 4.1**).

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". Below the header is a navigation bar with tabs for "Monitor", "Device", and "System". Under the "System" tab, there are sub-tabs for "Administration" and "Notification". The left sidebar lists various configuration options: User Manager, TCP/IP, Web, Console, FTP, Time Server, Syslog, Batch Configuration (highlighted), and Upgrade. The main content area is titled "System » Administration » Batch Configuration". It contains two panels: "System Configuration" and "SNMP Configuration". Each panel has a "Download" button, a "Browse..." button, and an "Upload" button. Below these buttons, a description states: "This function configures all of the system parameters at one time. Follow these steps to complete the process:". The steps are: Step 1: Press Download to view the configure.ini file which includes all of the system parameters. Copy the contents to a new file opened in text editor software. Step 2: Edit the line items, as required. Save the file after all changes have been made.

Upgrade

The Upgrade page shows the TLNETCARD's current firmware version. Instructions for performing a firmware update are provided on-screen. The upgrade process, including a card reboot, should take about one minute.

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title "TLNET Supervisor", and links for "Home" and "Logout". Below the header is a navigation bar with tabs for "Monitor", "Device", and "System". Under the "System" tab, there are sub-tabs for "Administration" and "Notification". The left sidebar lists various configuration options: User Manager, TCP/IP, Web, Console, FTP, Time Server, Syslog, Batch Configuration, and Upgrade (highlighted). The main content area is titled "System » Administration » Upgrade". It contains a panel titled "SNMP Device Firmware". The panel shows the "Current Ver.: 01.12.04d" and a "Firmware File:" field with a "Browse..." button and an "Upload" button. Below these, a description states: "This feature updates the SNMP device firmware. Follow these steps to complete the process:". The steps are: Step 1: Using Browse, select the source firmware file then press Upload to initiate the process. Step 2: Wait about 1 minute for the process to complete and for the SNMP device to reboot. At the bottom of the page, there is a copyright notice: "Copyright © 2015 Tripp Lite, Inc. All Rights Reserved."

3. TLNET Supervisor

3.3.2 Notification

SNMP Access

The screenshot shows the TLNET Supervisor web interface. The top navigation bar includes 'Monitor', 'Device', and 'System' tabs. The left sidebar lists 'Administration' and 'Notification' sections. Under 'Notification', 'SNMP Access' is selected. The main content area is titled 'System » Notification » SNMP Access'. It contains a 'SNMP Access' configuration box with the following fields: 'SNMP Server Port' (161), 'Download MIB' (TrippLite MIB, RFC1628), 'Allowed NMS IP' (0.0.0.0), 'Community String' (public), and 'Access Level' (Read Only). Below these fields is an 'NMS List' table with two entries: 1 (0.0.0.0, public, Read Only) and 2 (0.0.0.0, tripplite, Read/Write). The footer indicates 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

The TLNETCARD supports SNMP protocol and SNMP NMS (Network Management System), which are commonly used to monitor network devices. To prevent unauthorized access, the NMS IP addresses community strings and access levels for authorized users can be specified. The maximum number of IP entries is 256.

Note: If IP address **0.0.0.0** is entered, the NMS IP access restriction is ignored. The TLNETCARD checks the community string to identify the configured access level and permission.

SNMPv3 USM

SNMPv3 offers features such as packet encryption and authentication to improve security. The SNMPv3 USM (User Session Management) allows assignment of eight User Names whose access is granted via SNMPv3 protocol. Their respective Security Levels, Auth Passwords, Priv Passwords and Access Levels can also be defined.

The screenshot shows the TLNET Supervisor web interface for the SNMPv3 USM configuration. The top navigation bar includes 'Monitor', 'Device', and 'System' tabs. The left sidebar lists 'Administration' and 'Notification' sections. Under 'Notification', 'SNMPv3 USM' is selected. The main content area is titled 'System » Notification » SNMPv3 USM'. It contains a 'SNMPv3 USM' configuration box with the following fields: 'Auth Protocol' (MD5), 'Context Name' (cn1027), 'Priv Protocol' (CBC-DES), and a table for user configuration. The table has five columns: 'User Name (16 bytes max.)', 'Security Level', 'Auth Password (>= 8 bytes)', 'Priv Password (>= 8 bytes)', and 'Access Level'. There are eight rows, each with a 'Submit' button at the bottom right of the table. The footer indicates 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

3. TLNET Supervisor

SNMP Trap

SNMP Traps alert users to specific events that occur in the monitored environment. SNMP Trap recipients must be added to the Target IP list by entering in their IP Addresses and related parameters, then clicking **Add**. Click the **Update** button to modify entries in the list. Items can be removed by clicking the **Delete** button.

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

System Time : Fri 01/08/2016 PM 02:04:29

Home Logout

Monitor Device System

Administration Notification

SNMP Access

SNMPv3 USM

SNMP Trap

Mail Server

Wake On LAN

System » Notification » SNMP Trap

SNMP Trap Target List

Target IP: 172.18.48.97 Community String: public

Trap Type: SNMPv1 MIB: TrippLite

SNMPv3 User Name: Trap Port: 2162

The SNMPv3 User Name must be the same as the User Name in the SNMPv3 USM table.

Trap Category: TLNET Shutdown Agent

SNMP Port for ShutdownAgent: 2161

Add Update Delete

	Target IP	Community	Port	MIB	Type	Trap Category	SNMPv3 User
1	172.18.48.97	public	2162	TrippLite	v1	TLNET Shutdown Agent	
2	172.18.20.242	triplite	162	RFC1628	v1	Standard	

Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.

Notes:

The TLNETCARD supports SNMPv1, SNMPv2c and SNMPv3 traps. For SNMPv3 traps, specify an SNMPv3 USM User Name. Use Trap Category to determine which event notifications are to be sent to the Target IP Address. The three categories are:

- **None:** No event notifications are sent to the target address.
- **Standard:** standard event notifications are sent to the target address
- **Shutdown Agent:** Shutdown Agent event notifications are sent to the target address. Go to **Monitor** → **Information** → **Shutdown Agent** to view the shutdown information of the designated PC.

Mail Server

TRIPP-LITE POWER PROTECTION

TLNET Supervisor

System Time : Fri 01/08/2016 PM 02:05:29

Home Logout

Monitor Device System

Administration Notification

SNMP Access

SNMPv3 USM

SNMP Trap

Mail Server

Wake On LAN

System » Notification » Mail Server

Mail Server Configuration

SMTP Server Name or IP: (51 bytes max.)

SMTP Server Port: 25

Account: admin (64 bytes max.)

Account Format: user_name@mail_server_domain (e.g., john@company.com)

Password: (32 bytes max.)

Submit

The Account and Password are not required to send emails.

Mail List

Receiver: name@company.com

Event Level: None

Add Test e-mail

	Receiver	Event Level
1	name@company.com	None

Set up an SMTP Server and specify a list of E-mail recipients who will receive notifications when events occur. The maximum number of recipients is 256.

Note: If a DNS server is not available in the network, manually assign an SMTP server address to enable the E-mail notification system.

• SMTP Server Name or IP

If a Host Name is entered, a DNS IP should be added in TCP/ IP. See section 3.3.1 for more information.

3. TLNET Supervisor

- **Account**

The mail server login account.

- **Password**

The mail server login password.

- **Receiver**

The recipients' E-mail addresses.

- **Event Level**

Select the Event Level that when triggered, an E-mail notification is sent to the corresponding recipient.

- 1) **Information:** All event notifications are sent to the target address.
- 2) **Warning:** Warning and Alarm event notifications are sent to the target address.
- 3) **Alarm:** Only Alarm event notifications are sent to the target address.

Wake on LAN

The Wake On LAN function enables a networked PC to be started up after power is restored and/or the TLNETCARD starts up. This feature supports a maximum of 256 PCs.

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title 'TLNET Supervisor', and links for 'Home' and 'Logout'. A system time display shows 'Fri 01/08/2016 PM 02:06:16'. The main navigation bar has tabs for 'Monitor', 'Device', and 'System'. Under the 'System' tab, there are sub-tabs for 'Administration' and 'Notification'. The 'Notification' sub-tab is active, showing the 'System » Notification » Wake On LAN' page. On the left sidebar, under 'Administration', the 'Wake On LAN' option is selected. The main content area displays the 'WOL Host List' configuration. It includes input fields for 'Title' (set to 'None'), 'MAC' (set to '00-00-00-00-00-00'), and 'Delay' (set to '0' minutes). There are checkboxes for 'Wake Up Condition' with options 'Power Restore' and 'System Startup'. An 'Add' button is present. Below the form is a table with the following data:

	Title	MAC	Delay	Restore	Startup
1	None	00-00-00-00-00-00	0	No	No

At the bottom, a copyright notice reads: 'Copyright © 2015 Tripp Lite, Inc. All Rights Reserved.'

4. TLNET Configurator

The TLNET Configurator utility simplifies configuration and firmware update of multiple TLNETCARDS as described in the following sections. Configuration of individual TLNETCARDS using the TLNET Configurator is covered in **Section 2.1.1**.

4.1 Batch Configuration

This function of the utility allows the configuration of one (source) TLNETCARD to be copied to one or more (target) TLNETCARDS.

Step 1: Within the TLNET Supervisor of the source TLNETCARD, go to **System → Administration → Batch Configuration** and select the **Download** button in either the System Configuration or the SNMP Configuration window. The contents of the configuration file will appear in a web page.


Step 2: Select and copy the entire contents of the configuration file.

Step 3: Open a text editor application such as Notepad and paste the contents. Save the file to a location where it can be accessed by the TLNET Supervisor or Configurator (e.g. on the computer's desktop).

Step 4: If required, make edits to the configuration file, then save it with a .ini extension (e.g. *snmp.ini*).


Note: The configuration file name cannot contain spaces, hyphens or special characters.

Caution: The Network settings, including IP Address, Mask and Gateway of the source TLNETCARD will be transferred to the target TLNETCARDS. To prevent a setting from being transferred to other devices, simply "comment out" its line item by placing a semicolon (;) at the beginning of the line item. In the example below, the IP Address will NOT be transferred but the remaining items will.



```
IdentName=
AttachDevice=
; IP=172.18.48.144
Mask=255.255.255.0
Gateway=172.18.48.1
DNS IP=172.18.0.18
Domain=tripplite.com
Bootp=Disable
```

Launch the TLNET Configurator and set the required network parameters (LAN, Subnet), then click **Discover**.



4. TLNET Configurator

Step 5: The *Account* and *Password* fields for all target TLNETCARDS will need to be entered. If the cards all share the same account user name and password, skip to the next step. Otherwise, select each target TLNETCARD's line item (not its checkbox) and click **Modify** to enter the credentials. Once completed, the line item in the Device List will show values in the *Account* and *Password* fields.

The screenshot shows the 'IP & Account' dialog box on the left and the 'Device List' table on the right.

IP & Account Dialog:

- SNMP Device Address: IP Address: 172 . 18 . 48 . 211
- Administrator Account: Account: admin, Default: admin
- Password: Password: [masked], Default: password
- OK button

Device List Table:

IP Address	Host Name	Account	Password	Version	Model/Product	
<input type="checkbox"/> 172.018.048.210	TLNET	admin	*****	01.12.04	TRIPP LITE SM...	0
<input type="checkbox"/> 172.018.048.205	TLNET	admin	*****	01.12.04	TRIPP LITE SM...	0
<input type="checkbox"/> 172.018.048.209	TLNET	admin	*****	01.12.04	SU16000RT4U...	0
<input type="checkbox"/> 172.018.048.208	TLNET	admin	*****	01.12.04	TRIPP LITE SM...	0
<input type="checkbox"/> 172.018.048.215	TLNET	admin	*****	01.12.04	SU10000RT3U...	0
<input type="checkbox"/> 172.018.048.211	TLNET	admin	*****	01.12.04	SU6000RT4U ...	0
<input checked="" type="checkbox"/> 172.018.048.217	TLNET	*****	????????	01.12.04	SU1000RTXL2...	0

Step 6: Select the checkboxes of all the target TLNETCARDS, then click on **Batch Configuration**. Click the **Browse** button in the pop up window, then navigate to and select the configuration file saved in Step 3. If the cards all share the same account username and password information, enter those credentials in the space provided. Even if the default values will be used, they need to be re-entered into fields.

The screenshot shows the 'Batch Configuration' dialog box.

Batch Configuration Dialog:

- Select a configuration file for the SNMP device
- Configuration File Name: C:\Users\USER\Desktop\configure.ini
- Buttons: Browse..., Edit...
- Please note that, there are 2 configuration files for the device:
 - configure.ini: To configure the system parameters
 - snmp.ini: To setup the snmp permissions and trap target(s)
- Buttons: Upload Now, Exit
- Enter the default Account and Password if they have not been specified for the selected devices:
 - Account: [field], Default: admin
 - Password: [field], Default: password

Step 7: Click on the **Upload Now** button. A notification appears when the process is complete.

The screenshot shows the 'Information' dialog box.

Information Dialog:

- Icon: Information (i)
- Text: Upload process completed.
- Button: OK


4. TLNET Configurator

4.2 Batch Upgrade


This function of the Batch Upgrade utility allows a firmware file to be loaded onto one or more TLNETCARDS. Firmware files will typically be downloaded from Tripp Lite's website.

Step 1: Place the (downloaded) firmware file in a location where it can be accessed by the TLNET Configurator (e.g. on the computer's desktop).

Step 2: Launch the TLNET Configurator, set the required network parameters (LAN, Subnet), then click **Discover**.




Step 3: The *Account* and *Password* fields for all target TLNETCARDS will need to be entered. If the cards all share the same account username and password, skip to the next step. Otherwise, select each target TLNETCARD's line item (not its checkbox) and click **Modify** to enter the credentials. Once completed, the line item in the Device List will show values in the *Account* and *Password* fields.



4. TLNET Configurator


Step 4: Select the checkboxes of all TLNETCARDS to be upgraded, then click on **Batch Upgrade**. Click the **Browse** button in the pop up window, then navigate to and select the firmware file saved in Step 1. If the cards all share the same account username and password information, enter those credentials in the space provided. Even if the default values will be used, they need to be re-entered into fields.



The **Batch Upgrade** dialog box contains the following fields and buttons:

- Select a firmware file for the SNMP device**
 - Firmware File Name:** A text field containing `C:\Users\USER\Desktop\TLNET Software\TLNET Su` and a **Browse...** button.
 - File Information:** A text field containing `Product: ups, Ver: 01.12.04`.
- Upgrade Now** button
- Exit** button
- Enter the default Account and Password if they have not been specified for the selected devices**
 - Account:** `admin` (Default: admin)
 - Password:** `.....` (Default: password)

Step 5: Click the **Upgrade Now** button. A progress bar will indicate the upgrade status for each TLNETCARD sequentially. An information window will denote when the upgrade has been completed. Click **OK**.




The **TLNET Configurator v2.0.15** main window includes the following sections:

- Instructions:**
 - Press "Discover" button to search all of the SNMP devices in the LAN.
 - Then select one of device in the "Device List" which you would like to configure or upgrade it. But before to do that please provide the account name and password by pressing the "Modify" button.
 - "Configuration" is used to setup the basic IP address, netmask, enable or disable networking services...
 - "Upgrade" button is used to load the device firmware file then transmit it to the single selected device. (Ignore the checkbox)
- LAN Settings:**
 - LAN:** `172.18.48.110`
 - Subnet:** `172.18.48.0`
 - IPv4 Mask / IPv6 Prefix length:** `255.255.255.0`
- Device List:**

IP Address	Host Name	Account	Password	Version	Model/Product
<input checked="" type="checkbox"/> 172.018.048.216	TLNET				
<input checked="" type="checkbox"/> 172.018.048.215	TLNET				
<input checked="" type="checkbox"/> 172.018.048.210	TLNET				
<input checked="" type="checkbox"/> 172.018.048.208	TLNET				
<input type="checkbox"/> 172.18.48.110	R2-R210II-4	????????	01.04.10c		EMS3000

An **Upgrading Now** progress bar is overlaid on the Device List.
- Actions:**
 - Discover**, **Configuration...**, **Upgrade...**
 - Add...**, **Modify...**, **Remove**
 - Select All**, **Deselect All**
 - Batch Upgrade...**, **Batch Configuration...**



The **Information** dialog box displays the message: **Upgrade process completed.** with an **OK** button.

4. TLNET Configurator

Note: The TLNET Configurator will not automatically show the updated firmware version in the Device List. Exit, then re-launch the TLNET Configurator to confirm the selected devices successfully uploaded the new firmware. The update can also be confirmed in the TLNET Supervisor interface of each device in the **Monitor >> About** tab.

The screenshot shows the TLNET Supervisor web interface. The top header includes the Tripp-Lite logo, the title "TLNET Supervisor", a "Home" button, and the system time "Thu 11/12/2016". Below the header is a navigation bar with tabs: Monitor, Device, System, Information, History, and About. The "About" tab is selected. The main content area displays the "Monitor >> About >> Information" path. A box titled "Information" contains the following text: "TrippLite TLNET Supervisor Version : 01.12.04", "TLNET Supervisor utilizes the 'OpenSSL toolkit' functionality provided by 'The Open SSL Project' at <http://www.openssl.org/>. SDI acknowledges all patent rights therein.", "The OpenSSL toolkit is licensed under a dual-license (the OpenSSL license and the original SSLeay license).", and a link "See the license text."

5. Modbus TCP

Beginning with firmware revision 01.12.05c, TLNETCARD supports Modbus TCP.

5.1 Configuration

In the TLNET Supervisor interface, go to **System** → **Notification** tab and select "Modbus TCP" from the menu. Select the "Enable Service" checkbox in order to allow up to 8 clients to access the TLNETCARD; leaving the box unchecked will disable TCP service. Enter the required ID and Port information, then click "Submit". In the Remote List section, add the IP address and access level for each host, as required.

The screenshot shows the TLNET Supervisor web interface with the "System >> Notification >> Modbus TCP" path selected. The "Modbus TCP" configuration box contains the following fields: "Enable Service (8 sessions max.)" (checkbox), "Slave ID" (text input with value 1), and "Port" (text input with value 502). A "Submit" button is below these fields. Below the configuration box is the "Remote List" section, which includes a table for adding remote hosts. The table has columns for "Remote IP" and "Access Level". A text box above the table shows "Allowed Remote IP: 0.0.0.0" and "Access Level: Read Only". A note states: "Remote IP Address 0.0.0.0 will allow the modbus TCP packets to be received from any host." Below the table, there are "Add" and "Update" buttons. The table currently contains one entry:

	Remote IP	Access Level
1	0.0.0.0	Read Only

At the bottom of the page, the copyright notice "Copyright © 2016 Tripp Lite, Inc. All Rights Reserved." is displayed.

5. Modbus TCP

5.2 Operation

Discrete Inputs (Range 0x0100 - 0x012F, Read Function 0x02)

The Read Discrete Inputs function code is used to read 1-2000 contiguous statuses of Discrete Inputs in a remote device. The starting address and number of inputs is specified by the request Protocol Data Unit. Addresses start at 0 and Discrete Inputs numbered 1-16 would address as 0-15.

Description	Address (hex - dec)		Value 0	Value 1
Alarm Over Temperature	0x0100	256	OK	Over Temperature
Alarm Input Out Of Range	0x0101	257	OK	Input Bad
Alarm Output Bad (obsolete, reserved)	0x0102	258	OK	Output Bad
Alarm Overload	0x0103	259	OK	Overload
Alarm Bypass Out Of Range	0x0104	260	OK	Bypass Bad
Alarm Output Off	0x0105	261	Output On	Output Off
Alarm UPS Shutdown	0x0106	262	OK	Shutdown
Alarm Charger Fail	0x0107	263	OK	Charger Failed
Alarm Standby	0x0108	264	Others	Standby
Alarm Fan Fail	0x0109	265	OK	Fan Fault
Alarm Fuse Fail	0x010A	266	OK	Fuse Fault
Alarm Other Warning	0x010B	267	OK	General Fault
Alarm Awaiting Power	0x010C	268	OK	Awaiting Power
Alarm Shutdown Pending	0x010D	269	OK	Shutdown Pending
Alarm Shutdown Imminent	0x010E	270	OK	Shutdown Imminent
Buzzer Status	0x010F	271	Silent	Buzzer is Alarming
Economic Mode	0x0110	272	No	Yes
Alarm Inverter Fail	0x0111	273	No	Yes
Emergency Power Off	0x0112	274	Oiff	On
Buzzer State	0x0113	275	Disabled	Enabled
Battery Ground Fault	0x0114	276	Normal	Ground Fault
*Reserved	0x0115	277		
	~	~		
	0x0127	295		
Alarm bypass voltage/freq bad	0x0128	296	OK	Bypass Volt/Freq. Bad
Alarm bypass phase sequence bad	0x0129	297	OK	Bypass Phase Sequence Bad
Alarm bypass STS overload	0x012A	298	OK	Bypass STS Overload
Alarm bypass STS over temperature	0x012B	299	OK	Bypass STS Over Temperature
Alarm bypass STS Fault	0x012C	300	OK	Bypass STS Fault
*Reserved	0x012D	301		
	~	~		
	0x012F	303		

Coils (Range 0x0200 -- 0x020F, Read Function 0x01, Write Function 0x05)

The Read Coils function reads 1-2000 contiguous status of coils in a remote device. The starting address and number of coils is specified by the request Protocol Data Unit. Addresses start at 0 and Coils numbered 1-16 would address as 0-15.

The Write Coils function writes a single output to ON/OFF in a remote device. A specified constant in the data field requests the ON/OFF state. Addresses start at 0 and Coils numbered 1 would address as 0.

Description	Address (hex - dec)		Value 0	Value 1
UPS Buzzer	0x0200	512	Silent	Alarm
*Reserved	0x0201	513		
Economic Mode Setting	0x0202	514	Disable (Back from ECO mode)	Enable(Goto ECO mode)
*Reserved	0x0203	515		
AC Fail & Restore Auto-Reboot	0x0204	516	Disable	Enable(default)
*Reserved	0x0205	517		
Enable/Disable Buzzer	0x0206	518	Disable	Enable(Default)
*Reserved	0x0207	519		
	~	~		
	0x020F	527		

5. Modbus TCP

Holding Register (Range 0x0300 -- 0x0321, Read Function 0x03, Write Function 0x06)

The Read Holding Registers function code is used to read contents of a contiguous block of Holding Registers in a remote device. The starting register address and number of registers is specified by the request Protocol Data Unit. Addresses start at 0 and registers numbered 1-16 would address as 0-15.

The Write Single Register function code is used to write a Single Holding Register in a remote device. The address of the register to be written is specified by the request Protocol Data Unit. Addresses start at 0 and registers numbered 1 would address as 0.

Description	Address (hex - dec)		Value	Unit
UPS Shutdown Delay	0x0300	768	0 – 9999 (0=Abort)	Seconds
UPS Restart Delay	0x0301	769	"0 – 65535 0~65534: Minutes to restart 65535: Cancel restart"	Minutes
Test	0x0302	770	0 = Abort test	for protocols 4001 & 4006
			3 = Test for 10 seconds	
			3 = Test for 10 seconds	for protocols 3003 & 3005
			0 = Abort test	for protocol 3015
			1/2/3 = Quick test	
			4= Deep battery test	
*Reserved	0x0303	771		
Low Transfer Voltage	0x0304	772	0 – 999	Voltage
High Transfer Voltage	0x0305	773	0 – 999	Voltage
Voltage Sensitivity	0x0306	774	0 = Normal	
			1 = Reduced	
			2 = Low	
Last Battery Replace Date -Year	0x0307	775	0 –9999	
Last Battery Replace Date - Month	0x0308	776	1 - 12	
Last Battery Replace Date - Day	0x0309	777	1 - 31	
Next Battery Replace Date - Year	0x030A	778	0 –9999	
Next Battery Replace Date - Month	0x030B	779	1 - 12	
Next Battery Replace Date - Day	0x030C	780	1 - 31	
UPS Periodic Auto-Test	0x030D	781	1 = Disable	
			4 = BiWeekly	
*Reserved	0x030E	782		
UPS Boot Delay	0x030F	783	0 – 999	Seconds
Bypass Frequency Tolerance	0x0310	784	5 to 50	0.1Hz
*Reserved	0x0311	785		
Test Time	0x0312	786	1 – 60	Minutes
Test Voltage	0x0313	787	0 – 999	Voltage
*Reserved	0x0314	788		
	0x0315	789		
External Battery Pack	0x0316	790	0 - 10	
*Reserved	0x0317	791		
	~	~		
	0x031C	796		
Bypass Low Transfer Voltage	0x031D	797	0 - 999 , Read Only	Voltage
Bypass High Transfer Voltage	0x031E	798		Voltage
Bypass Voltage Tolerance	0x031F	799	0 - 999	Voltage
Dry Contact Input Status 1	0x0320	800	High Byte -- B7:	
			0=Normal Open	
			1=Normal Close	
			B5 ... B0:	
			0=None	
			1=Dry Contact_in_1	
			2=Dry Contact_in_5	
			Low Byte -- B7:	
			0=Inactive, 1=Active	
			B6 ... B0:	
Dry Contact Input Status 2	0x0321	801	0=None	
			1=Event1, ... 20=Event20	

5. Modbus TCP

Input Register (Range 0x0400 -- 0x051C, Read Function 0x04)

The Read Input Registers function code is used to read 1-125 contiguous input registers in a remote device. The starting register address and number of registers is specified by the request Protocol Data Unit. Addresses start at 0 and registers numbered 1-16 would address as 0-15.

Description	Address (hex - dec)		Value	Unit
Series	0x0400	1024	0 = T	
			1 = H	
			2 = NT	
			3 = NH	
			4 = DPS	
			5 = DPH	
Rating Input Voltage	0x0401	1025	0 to 999	Voltage
Rating Input Frequency	0x0402	1026	0 to 999	0.1 Hz
Rating Output Voltage	0x0403	1027	0 to 999	Voltage
Rating Output Frequency	0x0404	1028	0 to 999	0.1 Hz
Rating VA	0x0405	1029	0 to 65534	10 VA
Rating Output Power	0x0406	1030	0 to 65534	10 Watt
Low Battery Time (not used, reserved)	0x0407	1031	0 to 99	Minute
Mains Input Low Tx Voltage Point	0x0408	1032	0 to 999	Voltage
Mains Input High Tx Voltage Point	0x0409	1033	0 to 999	Voltage
Mains Input Low Tx Voltage Upper Bound	0x040A	1034	0 to 999	Voltage
Mains Input Low Tx Voltage Lower Bound	0x040B	1035	0 to 999	Voltage
Mains Input High Tx Voltage Upper Bound	0x040C	1036	0 to 999	Voltage
Mains Input High Tx Voltage Lower Bound	0x040D	1037	0 to 999	Voltage
UPS Type	0x040E	1038	0: On-Line	
			1: Off-Line	
			2: Line-Interactive	
			3: 3 Phase	
			4: Split Phase	
			5: Others	
			6: HVDC	
Rating Battery Voltage	0x040F	1039	0 to 999	Voltage
Mains Low Tx Freq Point	0x0410	1040	0 to 999	0.1 Hz
Mains High Tx Freq Point	0x0411	1041	0 to 999	0.1 Hz
Bypass Rating Freq	0x0412	1042	0 to 999	0.1 Hz
Bypass Freq Max Tolerance	0x0413	1043	5 to 50	0.1 Hz
Bypass Freq Set Tolerance	0x0414	1044	5 to 50	0.1 Hz
Bypass Low Tx Voltage Point/ Bypass Rating Voltage	0x0415	1045	0 to 999	Voltage
Bypass High Tx Voltage Point	0x0416	1046	0 to 999	Voltage
Bypass Low Tx Voltage Upper Bound/ Bypass Voltage Max Tolerance	0x0417	1047	0 to 999	Voltage
Bypass Low Tx Voltage Lower Bound/ Bypass Voltage Set Tolerance	0x0418	1048	0 to 999	Voltage
Bypass High Tx Voltage Upper Bound	0x0419	1049	0 to 999	Voltage
Bypass High Tx Voltage Lower Bound	0x041A	1050	0 to 999	Voltage
*Reserved	0x041B	1051		
	~			
	0x041D	1053		
Battery Condition	0x041E	1054	0 = Good	
			1 = Weak	
			2 = Replace	
Battery Status	0x041F	1055	0 = OK	
			1 = Low	
			2 = Depleted	
Battery Charge	0x0420	1056	0 = (obsolete)	
			1 = Charging	
			2 = Resting	
			3 = Discharging	
Seconds on Battery	0x0421	1057	0 to 65534	Second
Estimated Minutes Remaining	0x0422	1058	0 to 9999	

5. Modbus TCP

Description	Address (hex - dec)		Value	Unit
Estimated Charge Remaining (not used, reserved)	0x0423	1059	0 to 999	
Battery Voltage	0x0424	1060	0 to 9999	0.1 Voltage
Battery Current	0x0425	1061	0 to 9999	0.1 Amp
UPS Internal Temperature	0x0426	1062	0 to 999	Degrees Celsius
Battery Level	0x0427	1063	0 to 100	%
External Batt-Pack Number	0x0428	1064	0 to 10	
Negative Battery Voltage	0x0429	1065	0 to 9999	-0.1 Voltage
Negative Battery Current	0x042A	1066	0 to 9999	0.1 Amp
*Reserved	0x042B	1067		
Negative Battery Level	0x042C	1068	0 to 999	%
Positive Charging Current	0x042D	1069	0 to 9999	0.1 Amp
Negative Charging Current	0x042E	1070	0 to 9999	0.1 Amp
Battery Charge Mode	0x042F	1071	0 = None	
			1 = Boost charge	
			2 = Float charge	
Input Num Lines(Phases)	0x0430	1072	0 to 9	
Input Frequency1	0x0431	1073	0 to 999	0.1 Hz
Input Voltage1	0x0432	1074	0 to 9999	0.1 Voltage
Input Current1	0x0433	1075	0 to 9999	0.1 Amp
Input Power1	0x0434	1076	0 to 65534	10 Watt
Input Frequency2	0x0435	1077	0 to 999	0.1 Hz
Input Voltage2	0x0436	1078	0 to 9999	0.1 Voltage
Input Current2	0x0437	1079	0 to 9999	0.1 Amp
Input Power2	0x0438	1080	0 to 65534	10 Watt
Input Frequency3	0x0439	1081	0 to 999	0.1 Hz
Input Voltage3	0x043A	1082	0 to 9999	0.1 Voltage
Input Current3	0x043B	1083	0 to 9999	0.1 Amp
Input Power3	0x043C	1084	0 to 65534	10 Watt
Input Voltage12	0x043D	1085	0 to 9999	0.1 Voltage
Input Voltage23	0x043E	1086	0 to 9999	0.1 Voltage
Input Voltage31	0x043F	1087	0 to 9999	0.1 Voltage
*Reserved	0x0440	1088	Value = 0xFFFF	
Total Output Power Factor	0x0441	1089	0 to 999	KW/KVA %
Output Source	0x0442	1090	0 = Normal	
			1 = Battery	
			2 = Bypass (3phase Reserve Power Path)	
			3 = Reducing	
			4 = Boosting	
			5 = Manual Bypass\	
			6 = Other	
			7 = No output	
Output Frequency	0x0443	1091	0 to 999	0.1 Hz
Output Num Lines(Phase)	0x0444	1092	0 to 9 (Number of output lines)	
Output Voltage1	0x0445	1093	0 to 9999	0.1 Voltage
Output Current1	0x0446	1094	0 to 65534	0.1 Amp
Output Power1	0x0447	1095	0 to 65534	10 Watt
Output Load1	0x0448	1096	0 to 999	Percent
Output Voltage2	0x0449	1097	0 to 9999	0.1 Voltage
Output Current2	0x044A	1098	0 to 65534	0.1 Amp
Output Power2	0x044B	1099	0 to 65534	10 Watt
Output Load2	0x044C	1100	0 to 999	Percent
Output Voltage3	0x044D	1101	0 to 9999	0.1 Voltage
Output Current3	0x044E	1102	0 to 65534	0.1 Amp
Output Power3	0x044F	1103	0 to 65534	10 Watt
Output Load3	0x0450	1104	0 to 999	Percent
Output Voltage12	0x0451	1105	0 to 9999	0.1 Voltage
Output Voltage23	0x0452	1106	0 to 9999	0.1 Voltage
Output Voltage31	0x0453	1107	0 to 9999	0.1 Voltage

5. Modbus TCP

Description	Address (hex - dec)		Value	Unit
Total Output Power KW	0x0454	1108	0 to 65534	0.1 KW
Total Output Power KVA	0x0455	1109	0 to 65534	0.1 KVA
Bypass Frequency	0x0456	1110	0 to 999	0.1 Hz
Bypass Num Lines(Phase)	0x0457	1111	0 to 9 (Number of bypass lines)	
Bypass Voltage1	0x0458	1112	0 to 9999	0.1 Voltage
Bypass Current1	0x0459	1113	0 to 65534	0.1 Amp
Bypass Power1	0x045A	1114	0 to 65534	10 Watt
Bypass Voltage2	0x045B	1115	0 to 9999	0.1 Voltage
Bypass Current2	0x045C	1116	0 to 65534	0.1 Amp
Bypass Power2	0x045D	1117	0 to 65534	10 Watt
Bypass Voltage3	0x045E	1118	0 to 9999	0.1 Voltage
Bypass Current3	0x045F	1119	0 to 65534	0.1 Amp
Bypass Power3	0x0460	1120	0 to 65534	10 Watt
Bypass Voltage12	0x0461	1121	0 to 9999	0.1 Voltage
Bypass Voltage23	0x0462	1122	0 to 9999	0.1 Voltage
Bypass Voltage31	0x0463	1123	0 to 9999	0.1 Voltage
Bypass STS Temperature	0x0464	1124	0 to 999	Degrees Celsius
*Reserved	0x0465	1125		
*Reserved	0x0466	1126		
Test Result	0x0467	1127	0 = No test performed	
			1 = Test passed	
			2 = Test in progress	
			3 = General test failed (Obsolete)	
			4 = Battery test failed	
			5 = Deep battery test failed (Obsolete)	
			6 = Test Aborted	
Number of Output Relay	0x0468	1128	0 : Not Available	
			> 0 : Available(<=99)	
Temperature	0x0469	1129	0 – 999, 0xFFFF: NO Connect	0.1 Degrees Celsius
Humidify	0x046A	1130	0 – 999, 0xFFFF: NO Connect	%
Relay 1	0x046B	1131	0 : Off, 1 : On, 0xFFFF: NO Connect	
Relay 2	0x046C	1132	0 : Off, 1 : On, 0xFFFF: NO Connect	
Relay 3	0x046D	1133	0 : Off, 1 : On, 0xFFFF: NO Connect	
Relay 4	0x046E	1134	0 : Off, 1 : On, 0xFFFF: NO Connect	
*Reserved	0x046F	1135		
	~	~		
	0x0482	1154		
UPS Event Log Entry	0x0483	1155	0 to 500	
Event log report format	0x0484	1156	0: NT 9 byte format	
			1: NH 8 byte format	
			2: Oline 6 byte format	
Event Reporting method	0x0485	1157	0: ELS	
			1: EVT	
Power Module ID/Attribute	0x0486	1158	Lo: ID(1-6) Hi: Attribute	
			B0: PFC	
			B1: Rectifier	
			B2: Charger	
			B3: Inverter	
			B4: Bypass	
			B5, B6, B7: TBD	
Power Module ID/Attribute	0x0487	1159		
Power Module ID/Attribute	0x0488	1160		
Power Module ID/Attribute	0x0489	1161		
Power Module ID/Attribute	0x048A	1162		
Power Module ID/Attribute	0x048B	1163		

5. Modbus TCP

Description	Address (hex - dec)		Value	Unit
Power Module ID/ General Status	0x048C	1164	Lo: ID(1-6), Hi: Status	
			B0: The power module exists or the power module is powered	
			B1: OFF	
			B2: Repair (NH+: The front screw is open)	
			B3: Fault shutdown	
Power Module ID/ General Status	0x048D	1165		
Power Module ID/ General Status	0x048E	1166		
Power Module ID/ General Status	0x048F	1167		
Power Module ID/ General Status	0x0490	1168		
Power Module ID/ General Status	0x0491	1169		
Power Module ID	0x0492	1170	Power Module ID: 1 ~ 6 PFC Status:	
			B0: PFC fuse open fault	
			B1: PFC over temperature warning	
			B2: PFC over temperature shutdown	
			B3: DC bus over voltage warning	
			B4: DC bus over voltage shutdown	
			B5: DC bus under voltage warning	
			B6: DC bus under voltage shutdown	
			B7: PFC circuit general fault	
			B8: Fan failure	
			B9: Output Current Limit	
			B10: PFC Off	
			B11: Inner communication failure	
			B12: Not calibrated	
			B13: Battery fuse open warning	
PFC Status	0x0493	1171		
Power Module ID	0x0494	1172		
PFC Status	0x0495	1173		
Power Module ID	0x0496	1174		
PFC Status	0x0497	1175		
Power Module ID	0x0498	1176		
PFC Status	0x0499	1177		
Power Module ID	0x049A	1178		
PFC Status	0x049B	1179		
Power Module ID	0x049C	1180		
PFC Status	0x049D	1181		
Power Module ID	0x049E	1182	Power Module ID: 1 ~ 6 Inverter Status:	
			B0: Inverter fuse open	
			B1: Inverter over temperature warning	
			B2: Inverter over temperature shutdown	
			B3: Fan failure	
			B4: Inverter short circuit	
			B5: Inverter STS failure	
			B6: Inverter voltage abnormal	
			B7: Inverter circuit general fault shutdown	
			B8: DC bus over voltage shutdown	
			B9: Inverter overload	
			B10: Inner communication loss	
			B11: EPO shutdown	
			B12: Inverter parallel communication loss	
			B13: Inverter parallel failure	
			B14: STS on/off. 1:on,0:off.	
			B15: Not calibrated	
Inverter Status	0x049F	1183		
Power Module ID	0x04A0	1184		
Inverter Status	0x04A1	1185		
Power Module ID	0x04A2	1186		

5. Modbus TCP

Description	Address (hex - dec)		Value	Unit
Inverter Status	0x04A3	1187		
Power Module ID	0x04A4	1188		
Inverter Status	0x04A5	1189		
Power Module ID	0x04A6	1190		
Inverter Status	0x04A7	1191		
Power Module ID	0x04A8	1192		
Inverter Status	0x04A9	1193		
Power Module ID/ Charger Status	0x04AA	1194	Power Module ID: 1 ~ 6 Charger Status:	
			B0: Charger circuit general fault	
			B1-B7: Reserved	
Power Module ID/ Charger Status	0x04AB	1195		
Power Module ID/ Charger Status	0x04AC	1196		
Power Module ID/ Charger Status	0x04AD	1197		
Power Module ID/ Charger Status	0x04AE	1198		
Power Module ID/ Charger Status	0x04AF	1199		
Power Module ID	0x04B0	1200	Power Module ID: 1 ~ 6 Temperature: 0 - 9999	Temperature: Degree Celsius
Temperature - PFC	0x04B1	1201		
Temperature - TBD	0x04B2	1202		
Temperature – Inverter	0x04B3	1203		
Temperature – Inverter R	0x04B4	1204		
Temperature – Inverter S	0x04B5	1205		
Temperature – Inverter T	0x04B6	1206		
Power Module ID	0x04B7	1207		
Temperature - PFC	0x04B8	1208		
Temperature - TBD	0x04B9	1209		
Temperature – Inverter	0x04BA	1210		
Temperature – Inverter R	0x04BB	1211		
Temperature – Inverter S	0x04BC	1212		
Temperature – Inverter T	0x04BD	1213		
Power Module ID	0x04BE	1214		
Temperature - PFC	0x04BF	1215		
Temperature - TBD	0x04C0	1216		
Temperature – Inverter	0x04C1	1217		
Temperature – Inverter R	0x04C2	1218		
Temperature – Inverter S	0x04C3	1219		
Temperature – Inverter T	0x04C4	1220		
Power Module ID	0x04C5	1221		
Temperature - PFC	0x04C6	1222		
Temperature - TBD	0x04C7	1223		
Temperature – Inverter	0x04C8	1224		
Temperature – Inverter R	0x04C9	1225		
Temperature – Inverter S	0x04CA	1226		
Temperature – Inverter T	0x04CB	1227		
Power Module ID	0x04CC	1228		
Temperature - PFC	0x04CD	1229		
Temperature - TBD	0x04CE	1230		
Temperature – Inverter	0x04CF	1231		
Temperature – Inverter R	0x04D0	1232		
Temperature – Inverter S	0x04D1	1233		
Temperature – Inverter T	0x04D2	1234		
Power Module ID	0x04D3	1235		
Temperature - PFC	0x04D4	1236		
Temperature - TBD	0x04D5	1237		
Temperature – Inverter	0x04D6	1238		
Temperature – Inverter R	0x04D7	1239		
Temperature – Inverter S	0x04D8	1240		
Temperature – Inverter T	0x04D9	1241		

5. Modbus TCP

Description	Address (hex - dec)		Value	Unit
Power Module ID	0x04DA	1242	Power Module ID: 1 ~ 6 Voltage: 0 - 9999	Voltage: 0.1Voltage
Inverter Voltage R	0x04DB	1243		
Inverter Voltage S	0x04DC	1244		
Inverter Voltage T	0x04DD	1245		
Power Module ID	0x04DE	1246		
Inverter Voltage R	0x04DF	1247		
Inverter Voltage S	0x04E0	1248		
Inverter Voltage T	0x04E1	1249		
Power Module ID	0x04E2	1250		
Inverter Voltage R	0x04E3	1251		
Inverter Voltage S	0x04E4	1252		
Inverter Voltage T	0x04E5	1253		
Power Module ID	0x04E6	1254		
Inverter Voltage R	0x04E7	1255		
Inverter Voltage S	0x04E8	1256		
Inverter Voltage T	0x04E9	1257		
Power Module ID	0x04EA	1258		
Inverter Voltage R	0x04EB	1259		
Inverter Voltage S	0x04EC	1260		
Inverter Voltage T	0x04ED	1261		
Power Module ID	0x04EE	1262		
Inverter Voltage R	0x04EF	1263		
Inverter Voltage S	0x04F0	1264		
Inverter Voltage T	0x04F1	1265		
Battery Cabinet #1 Temperature	0x04F2	1266	0 – 999	Degrees Celsius
Battery Cabinet #2 Temperature	0x04F3	1267	0 – 999	Degrees Celsius
Battery Cabinet #3 Temperature	0x04F4	1268	0 – 999	Degrees Celsius
Battery Cabinet #4 Temperature	0x04F5	1269	0 – 999	Degrees Celsius
Battery cabinet breaker	0x04F6	1270	1: close, 0:open	
*Reserved	0x04F7	1271		
	~	~		
	0x0502	1282		
Model Byte 0, 1	0x0503	1283	Lo: Byte0, Hi: Byte 1	
Model Byte 2, 3	0x0504	1284	Lo: Byte2, Hi: Byte 3	
Model Byte 4, 5	0x0505	1285	Lo: Byte4, Hi: Byte 5	
Model Byte 6, 7	0x0506	1286	Lo: Byte6, Hi: Byte 7	
Model Byte 8, 9	0x0507	1287	Lo: Byte8, Hi: Byte 9	
Model Byte 10, 11	0x0508	1288	Lo: Byte10, Hi: Byte 11	
Model Byte 12, 13	0x0509	1289	Lo: Byte12, Hi: Byte 13	
Model Byte 14, 15	0x050A	1290	Lo: Byte14, Hi: Byte 15	
*Reserved	0x050B	1291		
*Reserved	~	~		
*Reserved	0x050D	1293		
Firmware Version Byte 0, 1	0x050E	1294	Lo: Byte0, Hi: Byte 1	
Firmware Version Byte 2, 3	0x050F	1295	Lo: Byte2, Hi: Byte 3	
Firmware Version Byte 4, 5	0x0510	1296	Lo: Byte4, Hi: Byte 5	
Firmware Version Byte 6, 7	0x0511	1297	Lo: Byte6, Hi: Byte 7	
Firmware Version Byte 8, 9	0x0512	1298	Lo: Byte8, Hi: Byte 9	
Firmware Version Byte 10, 11	0x0513	1299	Lo: Byte10, Hi: Byte 11	
Firmware Version Byte 12, 13	0x0514	1300	Lo: Byte12, Hi: Byte 13	
Firmware Version Byte 14, 15	0x0515	1301	Lo: Byte14, Hi: Byte 15	
*Reserved	0x0516	1302		
*Reserved	~	~		
*Reserved	0x0518	1304		
CPU Byte 0, 1	0x0519	1305	Lo: Byte0, Hi: Byte 1	
CPU Byte 2, 3	0x051A	1306	Lo: Byte2, Hi: Byte 3	
*Reserved	0x051B	1307		
UPS Connection Status	0x051C	1308	0:Disconnection 1:Connection	

6. Troubleshooting

1. How do I confirm the link between the TLNETCARD and the UPS is established?

If the link between the TLNETCARD and the UPS is correctly established, the yellow LED on the TLNETCARD Network port should flash rapidly.

2. I can access the TLNET Supervisor, but I cannot login.

Check the IP addresses of the TLNETCARD and the workstation on which you are trying to log in. By default, they must be within the same LAN. To enable external connections, launch the TLNET Configurator and for that device's configuration, change User Limitation to *Allow Any*, as shown below.

The screenshot shows the 'Configuration' window of the TLNET Configurator. It is divided into several sections: 'System Identification', 'Date/Time', 'User Limitation', 'IPv4', 'IPv6', and 'System Configuration'. In the 'User Limitation' section, three radio button options are shown for 'Administrator', 'Device Manager', and 'Read Only User'. Each has three choices: 'In The LAN', 'Allow Any', and 'Allow Any'. The 'Allow Any' option is selected for all three, and this entire section is circled in red. Other settings include IP addresses, subnet masks, gateways, and DNS servers for both IPv4 and IPv6. The 'System Configuration' section at the bottom right shows 'HTTP Server' and 'Telnet Server' both enabled.

3. I am unable to connect to the TLNETCARD via its Host Name

If you just assigned a new static IP address to the TLNETCARD, you may need to refresh the NetBIOS table so that it corresponds with the new setting. Although Windows updates its NetBIOS table periodically, you can manually force it to refresh by entering **nbtstat -R** in DOS prompt mode. After that, you should be able to connect to the TLNETCARD its Host Name. Ensure that the Host Name assigned to the TLNETCARD does not exceed 16 bytes.

4. I am unable to ping the TLNETCARD from my workstation

If the SNMP IPv6 is non-responsive, check the following:

- If the green LED on the TLNETCARD's Network port is off, check that the network cable is correctly connected from the TLNETCARD to the network equipment.
- If the green LED is on, the current IP address may be unreachable. Manually assign a valid IP address to the TLNETCARD.
- If the green LED flashes and your network configuration includes a DHCP server, verify that the DHCP service is working properly. Otherwise, verify that the IP address is not already assigned to another device on the network. Note that if the current configuration is not useable, the TLNETCARD will reset to default IP settings (IPv4 address: 192.168.1.100/ net mask: 255.255.255.0/ gateway: 192.168.1.254).
- If the problem persists, use a network cable to cross link the TLNETCARD and the workstation. Ping the TLNETCARD's default or assigned static IP address. If the ping is successful, indicating that the TLNETCARD is working properly, check your network equipment. If not, contact your local dealer or service personnel for assistance.

5. I am unable to perform an SNMP Get or Set command

Refer to **3.3.2 Notification** to check SNMP settings. Verify that the workstation's IP address is added to the NMS IP list with Read or Read/Write (for Set) access. The community string on the workstation and the SNMP IPv6 must match.

6. I am unable to receive an SNMP trap

Refer to **3.3.2 Notification** to check SNMP Trap settings. Verify that the workstation's IP address is added to the Target IP list.

6. Troubleshooting

7. I forgot the Administrator's account and password

The Administrator's account and password can be reset via text mode. Refer to **2.1.5 Configuring through COM Port** to establish a COM port connection with the TLNETCARD. When the login information is prompted, key in **rstadmin**—for both login and password—within 30 seconds, then press enter. The Administrator account and password are now reset to the default (admin/password).

8. How do I generate a private SSL certificate file (in PEM format) for HTTPs connection?

To ensure a secure connection between the TLNETCARD and your workstation, you can create your own SSL certificate file. Download and install the OpenSSL Toolkit from <http://www.openssl.org>. Launch Shell or DOS prompt mode and enter the following command to create your own certificate file:

```
openssl req -x509 -nodes -days 3650 -newkey  
rsa:1024 -keyout cert.pem -out cert.pem
```

- Answer the prompted questions. Proceed with the given directions. Once completed, a file named cert.pem is created in the current working directory.
- Upload cert.pem to the TLNET Supervisor. Please refer to **3.3.1 Administration, Web**.

9. How do I generate DSA, RSA and Public keys for SSH?

For Linux:

- Download and install OpenSSH from <http://www.openssh.org>.
- Launch Shell and enter the following commands to create your own keys (ignore the prompt to provide a passphrase):
DSA Key:ssh-keygen -t dsa
RSA Key:ssh-keygen -t rsa
- Upload DSA and RSA keys to the InsightPower SNMP IPv6 for UPS Web. Please refer to 5-3-1 Administration – Console for more information.

For Windows:

- Download and install PuTTY from <http://www.putty.org>.
- Run puttygen.exe from the installed directory.
- Select SSH-2 RSA from the Parameters area and click Key → Generate key pair to generate a RSA key.
- Click Conversions → Export OpenSSH Key and assign a filename to the RSA key. Ignore the prompt to provide key passphrase.
- Select SSH-2 DSA from the Parameters, click Key → Generate key pair to generate a DSA key.
- Click Conversions → Export OpenSSH Key and assign a filename to the DSA key. Ignore the prompt to provide key passphrase.
- Copy the generated key from the text box, paste in a text editor and save as a text file.
- Upload the DSA/ RSA/ Public keys files to the TLNET Supervisor. Refer to **3.3.1 Administration, Console** for more information.

10. How do I upload a configuration / firmware / key files via SSH/ SFTP?

For quick configuration of the TLNETCARD, the files can be uploaded via SSH/ SFTP. The TLNETCARD automatically imports your settings after the files are uploaded to the designated directories. Refer to the following table:

Directory	Files
\config_snmp	snmp.ini
\config_system	configure.ini
\ssh_dsa	DSA key
\ssh_rsa	RSA key
\ssh_pubkey	Public key
\upgrade_snmp	SNMP IPv6's firmware upgrade package (binary)
\upgrade_device*	Device's firmware upgrade package (binary)

*Appears on specific devices only.

Upload files to their respective directories. Make sure the filenames do not contain non-English characters to avoid read error. Overwrite existing files if prompted by your SFTP client.

APPENDIX A – Default System Settings

After performing a “Reset System To Defaults” in text mode. The System Configuration file will contain the following (default) contents:

```
[Format]
SNMP device
Version=20
Restart=No
[System]
Name=TLNET
Contact=
Location=
IdentName=
AttachDevice=
IP=192.168.1.100
Mask=255.255.255.0
Gateway=192.168.1.254
DNS IP=
Domain=
Bootp=Enable
HTTP=Enable
HTTPS=Enable
Telnet=Enable
SSH=Enable
FTP=Disable
HTTP Port=80
HTTPS Port=443
Telnet Port=23
SSH Port=22
FTP Port=21
SNMP Port=161
Trap Port=162
Status Stable=1
Hist Data Interval=600
SysLog=Disable
SysLog Server=
SysLog Server2=
SysLog Server3=
SysLog Server4=
Web Refresh=10
Telnet Idle=120
Auto Negotiation=Enable
Speed=100
Duplex=Full
V6 DHCP=Enable
V6 IP=::/0
V6 Gateway=::
V6 DNS=::
Language=0
[User]
Enable RADIUS=No
Enable Local=Yes
RADIUS Server=
RADIUS Secret=
RADIUS Port=1812
Admin Account=admin
Admin Password=password

Admin Limit=0
Device Account=device
Device Password=password
Device Limit=0
User Account=user
User Password=password
User Limit=1
RADIUS Admin User Type=32
RADIUS Device User Type=2
RADIUS User User Type=1
Password Encrypt=No
[Time]
SNTP=Yes
Zone=+0
Server1=POOL.NTP.ORG
Server2=
Manual Date=01/01/2000
Manual Time=00:00:00
Use PC Time=No
Daylight Saving=No
Start Date=04/01
End Date=11/01
[Mail]
Server=
SMTP Port=25
Sender=
Password=
Receive Num=0
[UPS Configure]
Power Fail Shutdown=No
Power Fail Shutdown Delay=0
Batt Low Shutdown=No
Batt Low Shutdown Delay=0
Overload Shutdown=No
Overload Shutdown Delay=0
Smart Shutdown Estimated OS
Delay=300
Smart Shutdown UPS Delay=60
Smart Shutdown Apply to
Schedule=No
Enable Load Warning=No
Load Warning=90
Enable Load Severity=No
Load Severity=100
Batt Low Warning=No
Batt Low Level=30
Enable Batt Notification=No
Batt Notification Day=0
[Wake On LAN]
WOL Num=0
[Weekly Schedule]
Number=6
Weekday1=0000000
Time1=00:00
Action1=0
Weekday2=0000000
Time2=00:00
Action2=0
Weekday3=0000000
Time3=00:00
Action3=0
Weekday4=0000000
Time4=00:00

Action4=0
Weekday5=0000000
Time5=00:00
Action5=0
Weekday6=0000000
Time6=00:00
Action6=0
[Specific Schedule]
Number=10
Date1=01/01/2000
Time1=00:00
Action1=0
Date2=01/01/2000
Time2=00:00
Action2=0
Date3=01/01/2000
Time3=00:00
Action3=0
Date4=01/01/2000
Time4=00:00
Action4=0
Date5=01/01/2000
Time5=00:00
Action5=0
Date6=01/01/2000
Time6=00:00
Action6=0
Date7=01/01/2000
Time7=00:00
Action7=0
Date8=01/01/2000
Time8=00:00
Action8=0
Date9=01/01/2000
Time9=00:00
Action9=0
Date10=01/01/2000
Time10=00:00
Action10=0
[Environment]
Title Input1=Smoke
Title Input2=Fire
Title Input3=Leak
Title Input4=Door
Temperature Low Limit=60
Temperature High Limit=105
Humidity Low Limit=20
Humidity High Limit=80
Normal Open Input1=Yes
Normal Open Input2=Yes
Normal Open Input3=Yes
Normal Open Input4=Yes
Smart Shutdown Temperature=No
Smart Shutdown Humidity=No
Smart Shutdown Input1=No
Smart Shutdown Input2=No
Smart Shutdown Input3=No
Smart Shutdown Input4=No
[End]
```

APPENDIX B – Default SNMP Settings

After performing a “Reset All To Defaults” in text mode, the SNMP Configuration file will contain the following (default) contents:

```
Version=4
[SNMP Trap]
Number=0
[SNMP Access]
Port=161
Number=1
IP1=0.0.0.0/32
Community1=public
Permission1=1
[SNMP USM]
Context Name=cn1027
User1=
Security1=0
Auth1=
Priv1=
Permission1=1
User2=
Security2=0
Auth2=
Priv2=
Permission2=1
User3=
Security3=0
Auth3=
Priv3=
Permission3=1
User4=
Security4=0
Auth4=
Priv4=
Permission4=1
User5=
Security5=0
Auth5=
Priv5=
Permission5=1
User6=
Security6=0
Auth6=
Priv6=
Permission6=1
User7=
Security7=0
Auth7=
Priv7=
Permission7=1
User8=
Security8=0
Auth8=
Priv8=
Permission8=1
[End]
```



1111 W. 35th Street, Chicago, IL 60609 USA • www.tripplite.com/support