



Wall-mounted Whiteboard Instructions

Parts List


Note: Hardware provided is for drywall installation. If attaching to other material fasteners are to be furnished by other.



A x8



B x8



C x8



D x8

Tools Required

- Tape Measure
- Chalk Line
- Drill
- 1/4" Drill Bit
- Extended Drive Phillips
- Hammer

05/01/13

- Slide tray into groove on bottom of wall board. Snap two horizontal chalk lines at the heights indicated from the floor. If attaching to drywall drill eight 1/4" holes as specified.
- Insert drywall anchors B into holes then attach brackets A at the bottom with screw C making sure the bracket is in the lowest position.
- Attach brackets A at the top with screw C making sure the bracket is in the highest position. Tighten screw just enough so that the bracket can be tapped down with hammer.
- Place white board on lower brackets making sure to center it with middle lower bracket A. Attach bracket to wallboard using screw D starting with the middle lower bracket.
- Tap the top brackets down so they are touching the top of the board. Attach bracket to wallboard using screw D.

