







ASSEMBLY INSTRUCTION

miniCON | Cable Connector

Standard & Crimp Version



- A** Put bushing onto the cable.
- B** Prepare cable as shown.
- C** Only crimp version:
Slide crimp ferrule onto the cable.
- Crimp ferrule, only for cable O.D. 4.5 - 6.0 mm
- Crimp ferrule + reduction ferrule 1, for cable O.D. 3.3 - 4.4 mm
- Crimp ferrule + reduction ferrule 2, for cable O.D. 2.5 - 3.2 mm
- D** Wire contacts:
• Solder standard contacts.
• For crimp contact use our HX-CONTACT crimp tool with the appropriate positioner (see ordering info)
- E** Snap the contacts into the insert.

Contact Arrangement:

Male



Female



- F** Press the distance sleeve / chuck onto the cable.
- G** Slide insert and chuck into the housing and fasten the bushing.

Same procedure for MSC & MMC housing with female or male inserts!

NEUTRIK AG
NEUTRIK Zürich AG
NEUTRIK USA Inc.
NEUTRIK (UK) Ltd.

LI T: +423 / 237 24 24 F: +423 / 232 53 93
CH T: +41 44 / 736 5010 F: +41 44 / 736 5011
USA T: +1 732 / 901 9488 F: +1 732 / 901 9608
UK T: +44 1983 / 811 441 F: +44 1983 / 811 439

NEUTRIK Vertriebs GmbH DE/NL/AT T: +49 8131 / 280 890 F: +49 8131 / 280 830
NEUTRIK France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511
NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796
NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052

Draft. Nr.: BDA 126 / 3102M1231 | Update: 29.09.2009 | Data subject to change without prior notice. ©2009 NEUTRIK®. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK