AN-30 Speaker Monitor Owners Manual



A Message from the President

Congratulations on purchasing an Anchor Audio Speaker Monitor, the choice of thousands of satisfied customers including the White House, prestigious universities, school districts nationwide, police and fire departments, and all branches of the U.S. Military. Our products are made of the finest materials and built with pride in the U.S.

We've incorporated the latest technology into your sound system yet kept it simple to use. Just take a

few minutes to review this manual to ensure the maximum enjoyment of your Anchor system. Or, you can view a demonstration video complete with a trouble shooting section at www.anchoraudio.com.

Feel free to call our friendly customer support staff at 1-800-ANCHOR1 with any questions. We love to hear from our customers.

on behalf of all Anchor employees

CONTENTS

GETTING STARTED	1
ARCHITECTS' SPECIFICATION / SB-30 SPEAKER BRACKET	2
IMPORTANT SAFETY INSTRUCTIONS	3
AN-30 TECHNICAL SPECIFICATIONS / ANCHOR WARRANTY	4



GETTING STARTED

Please check your new unit carefully for any damage which may have occurred during shipment. Each Anchor product is carefully inspected at the factory and packed in specially designed boxes for safe transport.

Notify the freight carrier immediately of any damage to the shipping box or product. Repack the unit in the original box and wait for inspection by the carrier's claim agent. Notify your dealer of the pending freight claim.

NOTE: All damage claims must be made with freight carrier!

RETURNING SYSTEMS FOR SERVICE OR REPAIR

For service or repair, please contact the dealer you purchased your system from, call us at 1-800-262-4671, or visit www.AnchorAudio. com, Contact Us page. Our tech support team will issue an RA number for warranted systems, after which, you can ship the item(s) to Anchor for repair. All shipments to Anchor Audio must include an RA number and must be shipped prepaid. C.O.D. shipments and shipments without an RA number will be refused and returned at your expense.

> IMPORTANT: Save the shipping box & packing materials, they were specially designed to ship your unit!



ARCHITECTS' SPECIFICATION

The speaker monitor shall be an Anchor AN-30 or equivalent. The general construction shall include an injection-molded case, one 4.5" Neodymium woofer and input terminations consisting of both 3.5 mm and 1/4" phone.

The maximum speaker dimensions shall not exceed 5.5" high, 5.5" wide and 6.5" deep. The maximum weight shall be 1.5 pounds.

The case shall be formed by injection-molded highimpact polycarbonate, and shall have a smooth finish of black.

The woofer shall be magnetically shielded so as not to cause video interference, and shall be protected by a polycarbonate grill molded into the case.

The speaker monitor has the ability to be mounted on walls, ceilings, equipment racks and speaker stands with appropriate hardware and accessories.

NOTE: When connecting multiple AN-30 units *(daisy chaining)* stereo cable MUST be used to avoid interference.

SB-30 SPEAKER BRACKET

Mounting the AN-30 speaker *(included hardware: allen wrench & two allen head cap screws with lock washers)* to a wall, ceiling or other flat surface using the SB-30 speaker bracket.


Attention: The AN-30 only comes in Black. Picture is for illustration purposes only.




1. Attach mounting bracket securely to wall/ ceiling with pre-drilled holes.



2. Remove allen head cap screws from bracket mounts on AN-30.



3. Align bracket arm hole with mounting hole on AN-30 case.



4. Attach both sides of speaker securely to mounting bracket.

Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice.



AN-30 Speaker Monitor Owners Manual



Important Safety Instructions

- 1) Read Instructions All the safety and operation instructions should be read before the product is operated.
- 2) Retain Instructions The safety and operating instructions should be retained for future reference.
- 3) Heed Warnings- All warnings on the product and in the operating instructions should be adhered to.
- 4) Follow Instructions All operating and use instructions should be followed.
- 5) Cleaning Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Exception: A product that is meant for uninterrupted service and that for some specific reason, such as the possibility of the loss of an authorization code for the CATV converter, is not intended to be unplugged by the user for cleaning or any other purpose, may exclude the reference to unplugging the product in the cleaning description otherwise in above 5).

- 6) Attachments Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- 7) Water and Moisture Do not use this product near water for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
- 8) Accessories Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
- 9) A product and cart combination should be moved with care. Quick stop, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
- 10) Ventilation Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a build-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- 11) Power Sources This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- 12) Grounding or Polarization This product may be equipped with a polarized alternatingcurrent line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. IF you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
- 13) Power-Cord Protection Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
- 14) Protective Attachment Plug The product is equipped with an attachment plug having overload protection. This is a safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.

- 15) Outdoor Antenna Grounding If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure grounding of the lead in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection of grounding electrodes, and requirements for the grounding electrode. See Figure A.
- 16) Lightning For added protection this product during lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- 17) Power Lines An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- Overloading Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 19) Object and Liquid Entry Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 20) Servicing Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 21) Damage Requiring Service Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. When the power-supply cord or plug is damaged.
 - b. If liquid has been spilled, or objects have fallen into the product.
 - c. If the product has been exposed to rain or water.
 - d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - e. If the product has been dropped or damaged in any way.
 - f. When the product exhibits a distinct change in performance this indicates a need for service.
- 22) Replacement Parts When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- 23) Safety Check Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operation condition.
- 24) Wall or Ceiling Mounting The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 25 Heat The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

AN-30 Speaker Monitor Owners Manual

AN-30 DESCRIPTION & APPLICATIONS

The AN-30 speaker may be the smallest system in the Anchor Audio product line but it's big in power with 109 dB of sound from 30 watts of rated power output. The AN-30 can cover a typical sized conference room or classroom with ease. The AN-30 is so lightweight, at under two pounds, that it mounts effortlessly to a wall or ceiling bracket. It has a shielded magnet speaker that won't cause interference when installed near video monitors.

Applications for this product include foreground and background music systems, music playback, full-range paging and instructional applications. Combine an AN-30 and projector in a classroom for the perfect audio visual solution.

A variety of mounting accessories are available for wall, ceiling and speaker stand installations.



Anchor Audio Warranty

Anchor Audio only warranties products sold by authorized Anchor Audio dealers. Anchor Audio is unable to repair products that are out of warranty. Please visit the Anchor FAQ page at http://www.anchoraudio.com/anchor-faq.html for more information on battery replacement options.

To locate an authorized dealer near you, please contact sales@anchoraudio.com. Anchor Audio products are warranted to be free from defects in materials and workmanship for the period of SIX (6) YEARS from the date of original purchase unless listed below:

- 1. All microphone and beltpack transmitters shall be warranted for a TWO (2) YEAR period.
- 2. Batteries shall be warranted for a TWO (2) YEAR period.
- 3. PortaCom and ProLink 500 headsets and beltpacks shall be warranted for a TWO (2) YEAR period.
- 4. All woodworking shall be warranted for a TWO (2) YEAR period.
- 5. CouncilMAN and Assistive Listening Systems shall be warranted for a TWO (2) YEAR period.
- 6. All cases and covers shall be warranted for a TWO (2) YEAR period.

AN-30 TECHNICAL SPECIFICATIONS

Rated Power Output Max SPL @ Rated Power Frequency Response Speaker Type 4.5" Neodymium woofer Line Out Jack Line In Jack DC Input Jack Dimensions (HWD) Weight

30 Watts 100 dB @ 1 meter 100Hz - 15KHz ±3dB

line level, 3.5 mm – stereo line level, 3.5 mm - stereo & 1/4" phone - mono 12-24 V, 2A Min. 5.5" x 5.5" x 6.5" (14 x 14 x 16.5 cm) 1.5 pounds / 0.68 Ka

ANCHOR AUDIO CUSTOMER SERVICE 800.262.4671

FOR ADDITIONAL INFORMATION visit www.anchoraudio.com



(Specifications Subject to Change Without Notice)