

Battery Charger

- become warm during charging.

- For best

- For best performance and optimal safety, use only the included

This device complies with Part 15 of FCC rules. (

and (z) this device must accept any interference received, including

You are cautioned

in this manual could void your authority to operate this equipment.

This equi

[illegible]

- Consult the dealer or an experienced radio/TV technician for help.

This charge

WARNING

- To prevent

- Do not place any objects filled with liquids, such as vases, on

- Do not use

- Do not expose batteries or charger to excessive heat such as

- Do not dispose the batteries as uns

- [illegible]

This Class B digital

uniquement de la classe D est comprise à la limite inférieure de la classe D.

ATW Once

is available online at www.audio-technica.com in a selection of languages.

une large sélection de langue.

www.audio-technica.com/it.

providencia as informações dos seus produtos em diversas línguas na www.audio-tecnica.com.

Informazioni sui prodotti sono disponibili online in diverse lingue sul sito www.audio-tecnica.com

Sprachen auf unserer Homepage: www.audio-technica.com.

productinformatie in verschillende talen on-line beschikbaar op: www.audio-technica.com.

www.audio-technica.com 的官方網頁上選擇所屬語言及瀏覽。

www.audio-technica.com的官方网站上选择所属语言和浏览。

ATW-CHG2 Features

- Batteries are charged within the transmitters.
- Versatile unit charges ATW-T220a handheld transmitters and/or ATW-T210a UniPak® transmitters (in any combination).
- Built-in safety feature monitors cell voltage and automatically turns off the unit if problems are detected.
- Automatic shut-off if alkaline (non-rechargeable) batteries are installed.
- Automatic shut-off if damaged batteries are installed.
- Maintenance charging prevents battery self-discharge until the transmitter is removed from charger.
- Includes Ni-MH rechargeable batteries – 2 x AA 2000 mAh

How to charge

1. Connect the power cord.
2. Set the transmitter's power switch to the off position.
(Note: The transmitter's power is automatically turned off if the transmitter is set in the charger with its power switch on; in this case, the transmitter will resume operation when it is removed from the charger.)
3. Install the Ni-MH AA batteries in the transmitter, observing correct polarity as marked inside the transmitter. For installation instructions, see the 2000 Series installation & operation manual.
4. Insert the transmitter into the charger with transmitter charging contacts facing toward the charger's contact pins.
5. Power is supplied to the charging bay when the transmitter is set into the unit; at this point the red indicator of each port lights.
(Note: If the red indicator does not light, poor contact may be the cause; set the transmitter in the charger again.)
6. When the charge is completed, the red indicator is turned off.
(Note: Maximum charging time is about ten hours.)
7. The unit keeps charging with ultra-low current (maintenance charge) until the transmitter is removed from the charger.

LED Status Indication

Charger indicator status	Charging status	Transmitter status
Off	Power off	Transmitter not in unit
Red light	Charging*	Transmitter in unit
Red flashing	Charging error (Charging is stopped)	Transmitter in unit
Off	Charging is finished (Still maintenance charging)	Transmitter in unit

Note: Red flashing light (charging error) is caused by use of alkaline (non-rechargeable) or damaged battery.

***Note: If a transmitter with fully charged batteries is placed in the charger, the red light will remain on for a minimum of 3 hours, even though the batteries are fully charged.**

Specifications*

Input Rating	12V DC, 230 mA (maximum)
Output Rating	3.2V DC, 230 mA x2
Charging Time	Approx. 10 hours (2000 mAh Ni-MH)
Operating Temperature	0~+40° C
Dimensions	Approx. 131.0 mm (5.16") W x 130.0 mm (5.12") D x 105.0 mm (4.13") H
Weight	Approx. 40 g (1.4 oz)

*Specifications are subject to change without notice.