Mobile Board Instructions

Note: After assembly, remove the protective film from both sides of the board with a utility knife.

Cleaning Tip: A mild dish washing liquid can be used with a soft cloth to clean the writing surface.

NOTICE ON BLACKBOARD UNITS

Do not use dry erase markers on black board units. Only Neon Wet-Erase markers should be used on the black board's surface. Sold separately.



