
## LUXOR H.WILSON

## **3 Shelf Presentation Station Instructions**



**Parts List** 


Optional fluted legs for units with cabinet pack




## **Tools Required**


- Rubber Mallet






Install optional cabinet pack after step 1






4. Install optional pullout shelf before step 4



5




6



## LUXOR H.WILSON

www.luxorfurn.com www.hwilson.com

<u>LP + LE Electrical</u> <u>Assembly Instructions</u> **Parts List** 







**Tools Required** 

- Philips Screwdriver







Attach electric outlet **F** to top shelf **A**, secure with L bracket **G** and cable lock **J**. Loop outlet cable **F** through cable lock **J** and the inserts on shelf **A**. Screw L bracket **G** and cable lock **J** onto top shelf **A** with screw **H** and a philips screwdriver.