Installation Instructions
Slim 5 Series
Rackrail Mounting Bracket

TOOLS REQUIRED

1/2” Wrench
7/16” Hex Key

PARTS LIST

QTY	DESCRIPTION *(29 space and higher)*	PART NUMBER
8	Rackrail Mounting Bracket	A
16	6-32 X .188 Hex Screw	B
4	Rackrail	C
8	5/16-18X5/8 Pem Stud	D
8	5/16-18 Flange Nut	E

QTY	DESCRIPTION *(28 space and under)*	PART NUMBER
4	Rackrail Mounting Bracket	A
8	6-32 X .188 Hex Screw	B
2	Rackrail	C
4	5/16-18X5/8 Pem Stud	D
4	5/16-18 Flange Nut	E

INSTALLATION

1) Install rackrail mounting bracket (A) to hex screws (B) using a 7/16” hex key. The brackets can be installed in any of the mounting slots. **(FIGURE A)**

IMPORTANT NOTE: Models 29 spaces and higher that have a 3” wide center brace, will need to have that brace replaced with a 4” wide brace.



FIGURE A
INSIDE OF RACK

2) Install rackrail (C) to brackets using PEM nut (D) and flange nut. A 1/2” wrench is required. **(FIGURE B)**



FIGURE B

WARRANTY

Middle Atlantic Products, Inc. (the "Company") warrants the Slim 5 Series Rackrail Mounting Bracket to be free from defects in material or workmanship under normal use and conditions for the lifetime of the product.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory.

This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

Corporate Headquarters
Corporate Voice 973-839-1011 - Fax 973-839-1976 / International Voice +1 973-839-8821 - Fax +1 973-839-4982
middleatlantic.com - info@middleatlantic.com

Middle Atlantic Canada
Voice 613-836-2501 - Fax 613-836-2690 / middleatlantic.ca - @middleatlantic.ca

Factory Distribution
USA: NJ - CA - IL Canada: ON - BC