

Checking the Included Items

- The unit
- AC adaptor, insertion plugs (3 types)
- RS-232 conversion cable (2 m)
- Ferrite core x 3
- Owner's Manual (this document)


Main Features

This unit is a transmitter/receiver for long-distance transmission of HDMI signals over up to 100 meters using a single LAN cable (Cat5e or higher).

- Support for 1080/59.94p (full HD) and 3D video
- Support for HDMI 1.4 and HDCP 2.0
- Support for RS-232 signals


Panel Descriptions

HT-TX01 (Transmitter)



No.	Name	Explanation
1	Power indicator	This lights up when power is supplied.
2	LINK indicator	This lights up when the transmitter/receiver is correctly connected
3	HDMI INPUT connector	The HDMI signal from the source device is input here.
4	AC adaptor connector	This is for connecting the included AC adaptor.

HT-RX01 (Receiver)




No.	Name	Explanation
5	HDBaseT (TX) connector	This is for connecting a receiver.
6	RS-232 connector	This is for connecting a remote-control device (RS-232-compatible computer, projector, or the like) using the included RS-232 conversion cable.
7	HDMI OUTPUT connector	This outputs the HDMI signal to a display device.
8	HDBaseT (RX) connector	This is for connecting a transmitter, Roland XS series unit, or other such device.

Attaching the Ferrite Cores

1. Open an included ferrite core by spreading apart the tabs at two places.




2. Attach the ferrite core to an HDMI cable, LAN cable, or RS-232 conversion cable.



Attaching an AC Adaptor Insertion Plug


1. Attach an included AC adaptor insertion plug to the AC adaptor.
- \* Attach the insertion plug for your country or region.
  - \* Attach the insertion plug by pressing it in until it clicks into place.
  - \* Be sure always to use the included AC adaptor with the unit.



To detach, pull out the insertion plug while squeezing the left and right sides of the lock section inward.

Connection Examples

- \* For a connection to the HDBaseT connector, use a Cat5e (Category 5e) or higher shielded LAN cable.
- \* For a connection to the RS-232 connector, use the included RS-232 conversion cable.



RS-232 Connector (RS-232 Conversion Cable) Specifications

Pin No.	Signal
1	N.C.
2	RXD
3	TXD
4	N.C.
5	GND
6	N.C.
7	N.C.
8	N.C.
9	N.C.

Communication method	Synchronous (asynchronous), full-duplex
Communication speed	9600 bps, 19200 bps, 38400 bps, 115200 bps
Parity	none
Data length	8 bit
Stop bit	1 bit
Code set	ASCII
Flow control	none

Main Specifications

Input Formats	480/59.94i, 576/50i, 480/59.94p, 576/50p, 720/59.94p, 720/50p, 1080/59.94i, 1080/50i, 1080/59.94p, 1080/50p, 640 x 480, 800 x 600, 1024 x 768, 1280 x 768, 1280 x 1024, 1366 x 768, 1400 x 1050, 1600 x 1200, 1920 x 1200 * RGB formats : Conforms to VESA DMT Version 1.0 Revision 11. * The maximum refresh rates of RGB is 75 Hz. (excluding 1600 x 1200 and 1920 x 1200. The refresh rate of these 2 is 60Hz) * 1920 x 1200/60Hz : Reduced blanking * Also check the supported resolutions of the connected device.
Audio Formats	The maximum is PCM 8ch, Dolby Digital, True HD DTS-HD Master Audio
Input Connectors	HT-TX01 HDMI x 1: Type A 19 pins HT-RX01 RJ45 x 1
Output Connectors	HT-TX01 RJ45 x 1 HT-RX01 HDMI x 1: Type A 19 pins
Other Connectors	RS-232 x 1: 9 pins D-sub type * When using additional RS-232 cable.
Transmission distance	The maximum is 100 m (328 ft) * The available distance depends on the quality of the LAN cable.
Operating temperature range	0 to 40 degree C 32 to 104 degrees F
Operating temperature humidity	10 to 85 % (no condensation)
Storage temperature range	-20 to 60 degree C -4 to 140 degrees F
Storage temperature humidity	10 to 85 % (no condensation)
Power Supply	AC Adaptor
Current Draw	2 A
Dimensions	81 (W) x 93 (D) x 24 (H) mm 3-3/16 (W) x 3-11/16 (D) x 1 (H) inches
Weight excl. AC adaptor	300 g 11 oz

\* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

**For EU Countries**

**UK** This symbol indicates that in EU countries, this product must be collected separately from household waste, as defined in each region. Products bearing this symbol must not be discarded together with household waste.

**DE** Dieses Symbol bedeutet, dass dieses Produkt in EU-Ländern getrennt vom Hausmüll gesammelt werden muss gemäß den regionalen Bestimmungen. Mit diesem Symbol gekennzeichnete Produkte dürfen nicht zusammen mit dem Hausmüll entsorgt werden.

**FR** Ce symbole indique que dans les pays de l'Union européenne, ce produit doit être collecté séparément des ordures ménagères selon les directives en vigueur dans chacun de ces pays. Les produits portant ce symbole ne doivent pas être mis au rebut avec les ordures ménagères.

**IT** Questo simbolo indica che nei paesi della Comunità europea questo prodotto deve essere smaltito separatamente dai normali rifiuti domestici, secondo la legislazione in vigore in ciascun paese. I prodotti che riportano questo simbolo non devono essere smaltiti insieme ai rifiuti domestici. Ai sensi dell'art. 13 del D.lgs. 25 luglio 2005 n. 151.

**ES** Este símbolo indica que en los países de la Unión Europea este producto debe recogerse aparte de los residuos domésticos, tal como está regulado en cada zona. Los productos con este símbolo no se deben depositar con los residuos domésticos.

**PT** Este símbolo indica que nos países da UE, a recolha deste produto deverá ser feita separadamente do lixo doméstico, de acordo com os regulamentos de cada região. Os produtos que apresentam este símbolo não deverão ser eliminados juntamente com o lixo doméstico.

**NL** Dit symbool geeft aan dat in landen van de EU dit product gescheiden van huishoudelijk afval moet worden aangeboden, zoals bepaald per gemeente of regio. Producten die van dit symbool zijn voorzien, mogen niet samen met huishoudelijk afval worden verwijderd.

**DK** Dette symbol angiver, at EU-lande skal dette produkt opsamles adskilt fra husholdningsaffald, som defineret i hver enkelt region. Produkter med dette symbol må ikke smides ud sammen med husholdningsaffald.

**NO** Dette symbolet indikerer at produktet må behandles som spesialfall i EU-land, iht. til rettsregulering for den enkelte regionen, og ikke kastes sammen med vanlig husholdningsavfall. Produkter som er merket med dette symbolet, må ikke kastes sammen med vanlig husholdningsavfall.

**SE** Symbolen anger att i EU-länder måste den här produkten kasseras separat från hushållsavfall, i enlighet med varje regions bestämmelser. Produkter med den här symbolen får inte kasseras tillsammans med hushållsavfall.

**FI** Tämä merkitseminen tarkoittaa, että tuote on EU-maissa kerättävä erillään kotitalousjätteenä kunkin alueen voimassa olevien määräysten mukaisesti. Tällai merkitämillä varustettuja tuotteita ei saa hävittää kotitalousjätteen mukana.

**HU** Ez a szimbólum azt jelenti, hogy az Európai Unióban ezt a terméket a háztartási hulladéktól elkülönítve, az adott régióban érvényes szabályozás szerint kell gyűjteni. Az ezzel a szimbólummal ellátott termékeket nem szabad a háztartási hulladékkal közre dobni.

**PL** Symbol oznacza, że zgodnie z regulacjami w odpowiednim regionie, w krajach UE produkty nie należy wyrzucać z odpadami domowymi. Produkty oznaczone tym symbolem nie można utylizować razem z odpadami domowymi.

**CZ** Tento symbol udává, že v zemích EU musí být tento výrobek sbíráán odděleně od domácího odpadu, jak je určeno pro každou region. Výrobky nesoucí tento symbol se nesmí vyhazovat spolu s domácími odpady.

**SK** Tento symbol vyjadruje, že v krajích EU sa musí byť tento produkt vykonávané oddelene od domového odpadu, podľa nariadení platných v konkrétnej krajine. Produkty s týmto symbolom sa nesmú vyhazovať spolu s domovými odpadmi.

**EE** See sümbol näitab, et EL-i maades tuleb see toode olemispiirkonnas eraldi koguda, nii nagu on igan piirkonnas määratletud. Selle sümboliga märgitud tooteid ei tohi ära visata koos olmeprügiga.

**LT** Šis simbolis rodo, kad ES šalys šis produktas turi būti surenkamas atskirai nuo buitinių atliekų, kaip nustatyta kiekviename regione. Šiuo simboliu paženklinoti produktai neturi būti išmetami kartu su buitineis atliekomis.


**LV** Šis simbols norāda, ka ES valstīs šo produktu jāievieca atsevišķi no mājokļu atkritumiem atkritumiem, kā noteikts katrā reģionā. Produktus ar šo simbolu nedrīkst izmest kopā ar mājokļu atkritumiem.

**SI** Ta simbol označuje, da je treba proizvod v državah EU zbrati ločeno od gospodinjstvih odpadkov, tako kot je določeno v vsaki regiji. Proizvoda s tem znakom ni dovoljeno odlagati skupaj z gospodinjstvinimi odpadki.

**GR** Το σήμα αυτό υποδηλώνει ότι, στις χώρες της Ε.Ε. το συγκεκριμένο προϊόν πρέπει να συλλέγεται χωριστά από τα οικιακά απορρίμματα, σύμφωνα με τους κανονισμούς σε κάθε περιοχή. Τα προϊόντα με φέρουν το συγκεκριμένο σήμα δεν πρέπει να απορρίπτονται μαζί με τα οικιακά απορρίμματα.


Cable Wiring Diagram

When using the included RS-232 conversion cable, RXD, TXD, and GND are wired as shown below.



\* When you want to extend the RS-232 conversion cable, use a straight cable.

Dimensions



有关产品中所含有害物质的说明

本资料就本公司产品中所含的特定有害物质及其安全性予以说明。本资料适用于 2007 年 3 月 1 日以后本公司所制造的产品。

环保使用期限

此标志适用于在中国国内销售的电子信息产品，表示环保使用期限的年限。所谓环保使用期限是指在自制造日起的定期限内，产品中所含的有害物质不致引起环境污染，不会对人身、财产造成严重的不良影响。环保使用期限仅在遵照产品使用说明书，正确使用产品的条件下才有效。不当的使用，将会导致有害物质泄漏的危险。

产品中有毒有害物质或元素名称及含量

部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
外壳(壳体)	×	○	○	○	○	○
电子部件(印刷电路板等)	×	○	×	○	○	○
附件(电源线、交流适配器)	×	○	○	○	○	○

○：表示该有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。  
×：表示该有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。  
因根据现有的技术水平，还没有什么物质能够代替它。



**USING THE UNIT SAFELY**

**INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS**

About  WARNING and  CAUTION Notices

 <b>WARNING</b>	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
 <b>CAUTION</b>	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly.  * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

**ALWAYS OBSERVE THE FOLLOWING**

 **WARNING**

**To completely turn off power to the unit, pull out the plug from the outlet**

Even with the power switch turned off, this unit is not completely separated from its main source of power. When the power needs to be completely turned off, turn off the power switch on the unit, then pull out the plug from the outlet. For this reason, the outlet into which you choose to connect the power cord's plug should be one that is within easy reach and readily accessible.

**Do not disassemble or modify by yourself**

Do not carry out anything unless you are instructed to do so in the owner's manual. Otherwise, you risk causing malfunction.

**Do not repair or replace parts by yourself**

Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information."

**Do not use or store in the following types of locations**

- Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
- Damp (e.g., baths, washrooms, on wet floors); or are
- Exposed to steam or smoke; or are
- Subject to salt exposure; or are
- Exposed to rain; or are
- Dusty or sandy; or are
- Subject to high levels of vibration and shakiness.

**Do not place in an unstable location**

Otherwise, you risk injury as the result of the unit toppling over or dropping down.

**Use only the supplied AC adaptor and the correct voltage**

Be sure to use only the AC adaptor supplied with the unit. Also, make sure the line voltage at the installation matches the input voltage specified on the AC adaptor's body. Other AC adaptors may use a different polarity, or be designed for a different voltage, so their use could result in damage, malfunction, or electric shock.

**Do not bend the power cord or place heavy objects on it**

Otherwise, fire or electric shock may result.

 **WARNING**

**Do not allow foreign objects or liquids to enter unit; never place containers with liquid on unit**

Do not place containers containing liquid (e.g., flower vases) on this product. Never allow foreign objects (e.g., flammable objects, coins, wires) or liquids (e.g., water or juice) to enter this product. Doing so may cause short circuits, faulty operation, or other malfunctions.

**Turn off the unit if an abnormality or malfunction occurs**

Immediately turn the unit off, remove the AC adaptor from the outlet, and request servicing by your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" when:

- The AC adaptor or the power cord has been damaged; or
- If smoke or unusual odor occurs; or
- Objects have fallen into, or liquid has been spilled onto the unit; or
- The unit has been exposed to rain (or otherwise has become wet); or
- The unit does not appear to operate normally or exhibits a marked change in performance.

**Be cautious to protect children from injury**

Always make sure that an adult is on hand to provide supervision and guidance when using the unit in places where children are present, or when a child will be using the unit.

**Do not drop or subject to strong impact**

Otherwise, you risk causing damage or malfunction.

**Do not share an outlet with an unreasonable number of other devices**

Otherwise, you risk overheating or fire.

**Do not use overseas**

Before using the unit in overseas, consult with your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information."

 **CAUTION**

**Place in a well ventilated location**

The unit and the AC adaptor should be located so their location or position does not interfere with their proper ventilation.

 **CAUTION**

**When disconnecting the power cord, grasp it by the plug**

To prevent conductor damage, always grasp the power cord by its plug when disconnecting it from this unit or from a power outlet.

**Periodically clean the power plug**

An accumulation of dust or foreign objects between the power plug and the power outlet can lead to fire or electric shock.

At regular intervals, be sure to pull out the power plug, and using a dry cloth, wipe away any dust or foreign objects that may have accumulated.

**Disconnect the power plug whenever the unit will not be used for an extended period of time**

Fire may result in the unlikely event that a breakdown occurs.

**Route all power cords and cables in such a way as to prevent them from getting entangled**

Injury could result if someone were to trip on a cable and cause the unit to fall or topple.

**Avoid climbing on top of the unit, or placing heavy objects on it**

Otherwise, you risk injury as the result of the unit toppling over or dropping down.

**Never connect/disconnect a power plug if your hands are wet**

Otherwise, you could receive an electric shock.

**Disconnect all cords/cables before moving the unit**

Before moving the unit, disconnect the power plug from the outlet, and pull out all cords from external devices.

**Before cleaning the unit, disconnect the power plug from the outlet**

If the power plug is not removed from the outlet, you risk receiving an electric shock.

**Whenever there is a threat of lightning, disconnect the power plug from the outlet**

If the power plug is not removed from the outlet, you risk receiving an electric shock.

**Keep small items out of the reach of children**

To prevent accidental ingestion of the parts listed below, always keep them out of the reach of small children.

- Included Parts: Ferrite core

**IMPORTANT NOTES**

**Power Supply**

- Do not connect this unit to same electrical outlet that is being used by an electrical appliance that is controlled by an inverter or a motor (such as a refrigerator, washing machine, microwave oven, or air conditioner). Depending on the way in which the electrical appliance is used, power supply noise may cause this unit to malfunction or may produce audible noise. If it is not practical to use a separate electrical outlet, connect a power supply noise filter between this unit and the electrical outlet.

- The AC adaptor will begin to generate heat after long hours of consecutive use. This is normal, and is not a cause for concern.

- This unit is equipped with a protection circuit. A brief interval (a few seconds) after turning the unit on is required before it will operate normally.

**Placement**

- This unit may interfere with radio and television reception. Do not use this unit in the vicinity of such receivers.

- Noise may be produced if wireless communications devices, such as cell phones, are operated in the vicinity of this unit. Such noise could occur when receiving or initiating a call, or while conversing. Should you experience such problems, you should relocate such wireless devices so they are at a greater distance from this unit, or switch them off.

- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.

- Do not place containers or anything else containing liquid on top of this unit. Also, whenever any liquid has been spilled on the surface of this unit, be sure to promptly wipe it away using a soft, dry cloth.

**Additional Precautions**

- Use a reasonable amount of care when using its jacks and connectors. Rough handling can lead to malfunctions.

- When disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.

- When you need to transport the unit, pack it in shock-absorbent material. Transporting the unit without doing so can cause it to become scratched or damaged, and could lead to malfunction.

**Copyrights/Licenses/Trademarks**

- MMP (Moore Microprocessor Portfolio) refers to a patent portfolio concerned with microprocessor architecture, which was developed by Technology Properties Limited (TPL). Roland has licensed this technology from the TPL Group.

- Roland is an either registered trademark or trademark of Roland Corporation in the United States and/or other countries.

- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

**Information**

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

<b>AFRICA</b>	<b>TAIWAN</b> ROLANDTAIWAN ENTERPRISE CO., LTD. 9F-5, No. 112 Chung Shan North Road Sec. 2 Taipei 104, TAIWAN R.O.C. TEL: +886 2 2561 3339	<b>FINLAND</b> Roland Scandinavia As, Filial Finland Vanha Nummijarventie 62 01670 Vantaa, FINLAND TEL: +358 9-6824020	<b>SWEDEN</b> Roland Scandinavia A/S SWEDISH SALES OFFICE Mårbackagatan 31, 4 tr. SE-123 43 Farsta, Sweden TEL: +46 8-683 04 30	<b>IRAN</b> MOCO INC. Jadeh Makhshous karaj (K-9), Nakhe Zarin AVE. SE-123 43 Farsta, Reza Alley NO.4 Tehran, 1389716791, IRAN TEL: +98-21 44545370-5
<b>ALGERIA / ANGOLA / CABO VERDE / GUINEA / LIBYA / MOROCCO / MOZANBIQUE /TUNISIA</b> Roland Iberia, S.L. Paseo García Faria, 33-35 08005 Barcelona, SPAIN TEL: +34 93 493 9136	<b>VIET NAM</b> VIET THUONG CORPORATION 386 Cach Mang Thang Tam St. Dist.3, Ho Chi Minh City, VIET NAM TEL: +84-08-9316540	<b>GREECE</b> Bon Studio 6 Zaimi Street Exarhia 106 83 Athens, GREECE TEL: +30 210 3809605	<b>SWITZERLAND / LIECHTENSTEIN</b> Roland (Switzerland) AG Landstrasse 5, CH-4452 Ittingen, SWITZERLAND TEL: +41 61 975 99 99	<b>ISRAEL</b> Halilit P. Greenspoon & Sons Ltd. 8 Retzif Ha' alia Hashnia St. Tel-Aviv-Yafo ISRAEL TEL: +972-03-6823666
<b>SOUTH AFRICA</b> Paul Bothner(PTY) Ltd. Royal Cape Park, Unit 24 Londonderry Road, Ottery 7800 Cape Town, SOUTH AFRICA TEL: +27 21 799-4900	<b>Other CENTRAL/ SOUTH AMERICA</b> Roland Corporation U.S. 5100S. Eastern Ave. Los Angeles, California 90040, USA TEL: +1 (323) 215-2111	<b>HUNGARY / ROMANIA</b> Roland East Europe Ltd. 2045. Torokbalint, FSD Park 3. ep. HUNGARY TEL: +36 (23) 511-011	<b>UKRAINE</b> EURHYTHMICS Ltd. P.O.Box: 37-a. Nedecey Str. 30 UA - 89600 Mukachevo, UKRAINE TEL: +380 3131 414-40	<b>SAUDI ARABIA</b> Khaldi Est. P.O. Box 3475 Abdul Malik Bin Marwan St 11471 Riyadh, SAUDI ARABIA TEL: +966-1-219-5050
<b>CHINA</b> Roland China Limited Shanghai Mart, Room 1507, No. 2299 Yanan Road West, Changning District, Shanghai, 200336, CHINA TEL: +86-021-6236-6800	<b>Other CENTRAL/ SOUTH AMERICA</b> Roland Corporation U.S. 5100S. Eastern Ave. Los Angeles, California 90040, USA TEL: +1 (323) 215-2111	<b>ITALY</b> Roland Italy SpA Viale dell'Industria, 8 20020, Arese-Mi, ITALY TEL: +39(0)2-937781	<b>IRELAND/ UNITED KINGDOM</b> Roland (U.K.) Ltd. Atlantic Close, Swansea Enterprise Park, Swansea SA7 9FJ, UNITED KINGDOM TEL: +44 1792 702701	<b>TURKEY</b> Atemop Ses ve Isik Sistemleri Ltd. Sti. GUVENLIK SISTEMLERI LTD. STI. AHL SERBEST BOLGESI A BLOK NO: 28 YE 34830 Istanbul, TURKEY TEL: +90 212 288 0612
<b>INDIA</b> Rivera Digitec (India)Pvt.Ltd 411, Nirman Kendra Mahalaxmi Flats Compound off Dr.Edwin Moses Road, Mumbai-400011, INDIA TEL: +91 22 2493 9051	<b>EUROPE</b>	<b>MALTA</b> Roland Iberia, S.L. Paseo García Faria, 33-35 08005 Barcelona, SPAIN TEL: +34 93 493 9136	<b>NORTH AMERICA</b>	<b>CANADA</b> Roland Canada Ltd. (Head Office) 5480 Parkwood Way, Richmond B. C., V6V 2M4, CANADA TEL: +1 (604) 270 6626
<b>INDONESIA</b> PT. Citra Intirama Ruko Garden Shopping Arcade Unit 8 CR, Podomoro City, Jl.Let Jend. S.Panman Kav.28, Jakarta Barat 11470, INDONESIA TEL: +62 21 5698-5519	<b>AUSTRIA / GERMANY</b> Roland Germany GmbH Adam-Opel-Strabe 4, 64569, Naueheim, GERMANY TEL: +49 (0)6152-955 46 00	<b>PORTUGAL / SPAIN</b> Roland Iberia, S.L. Paseo García Faria, 33-35 08005 Barcelona, SPAIN TEL: +34 93 493 9136	<b>NEW ZEALAND</b> Roland Corporation Australia Pty.,Ltd. 38 Campbell Avenue Dee Why West, NSW 2099, AUSTRALIA	<b>Roland Canada Ltd. (Toronto Office)</b> 170 Admiral Boulevard Mississauga ON L5T 2N6, CANADA TEL: +1 (905) 362 9707
<b>KOREA</b> KOREA AVICS CO., LTD. Unit B-2208, Woolimblue9, #240-21, Yeomchang-dong, Gangseo-gu, Seoul, KOREA TEL: +82 2-322-3264	<b>BELGIUM / FRANCE / HOLLAND / LUXEMBOURG</b> Roland Center Europe NV Houtstraat 3, B-2260, Westerlo(Oevel), BELGIUM TEL: +32(0) 14 57 58 11	<b>PORTUGAL / SPAIN</b> Roland Iberia, S.L. Paseo García Faria, 33-35 08005 Barcelona, SPAIN TEL: +34 93 493 9136	<b>MEXICO</b> Roland Corporation U.S. 5100S. Eastern Ave. Los Angeles, California 90040, USA TEL: +1 (323) 215-2111	<b>MEXICO</b> Roland Corporation U.S. 5100S. Eastern Ave. Los Angeles, California 90040, USA TEL: +1 (323) 215-2111
<b>MALAYSIA / SINGAPORE</b> Roland Asia Pacific Sdn. Bhd. 45-1, Block C2, Jalan PJU 1/39, Dataran Prima, 47301 Petaling Jaya, Selangor, MALAYSIA TEL: +603-7805-3263	<b>CROATIA</b> ART-CENTAR Degenova 3, HR - 10000 Zagreb, CROATIA TEL: +385 1 46 68 493	<b>RUSSIA</b> Roland Music LLC Dorozhnaya ul.3, korp.6 117 545 Moscow, RUSSIA TEL: +7 (495) 981-4967	<b>QATAR / U.A.E</b> NMK Electronics P.O.Box 3191 Sharjah, UAE TEL: +971-4-2665244	<b>U. S. A.</b> Roland Corporation U.S. 5100S. Eastern Ave. Los Angeles, California 90040, USA TEL: +1 (323) 215-2111
<b>PHILIPPINES</b> EVI DISTRIBUTION PHILIPPINES, INC. 117, Sevilla Street , Brgy. Pedroo Cruz, San Juan City 1210, PHILIPPINES TEL: +632 774-5555	<b>CZECH REP.</b> CZECH REPUBLIC DISTRIBUTOR s.r.o Vocetárova 247/16 180 00 Praha 8, CZECH REP TEL: +420 283 020 270	<b>SERBIA</b> Music AP Ltd. Sutjeska br.5 XS - 24413 Palic, SERBIA TEL: +381-24-539-395	<b>CYPRUS / JORDAN / IRAQ / LEBANON / SYRIA /YEMEN</b> Roland Iberia, S.L. Paseo García Faria, 33-35 08005 Barcelona, SPAIN TEL: +34 93 493 9136	<b>For the USA</b>
	<b>DENMARK</b> Roland Scandinavia A/S Skagerakvej 7 Postbox 880 DK-2150 Nordhavn, DENMARK Tlf: +45 39 16 67 00	<b>SLOVAKIA</b> DAN Distribution s.r.o Povazská 18, SK - 940 01 Nové Zámky, SLOVAKIA TEL: +421 35 6424 330	<b>For the USA</b>	<b>For the USA</b>

**For the USA**

**DECLARATION OF CONFORMITY  
Compliance Information Statement**

Model Name : HT-TX01 / HT-RX01  
Type of Equipment : HDMI Extender  
Responsible Party : Roland Corporation U.S.  
Address : 5100 S. Eastern Avenue Los Angeles,  
CA 90040-2938  
Telephone : (323) 890-3700

**For the USA**

**FEDERAL COMMUNICATIONS COMMISSION  
RADIO FREQUENCY INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment requires shielded interface cables in order to meet FCC class B limit. Any unauthorized changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**For Canada**

CAN ICES-3 (B)/NMB-3 (B)

**For Korea**

**사용자 안내문**

기종별	사용자 안내문
B 급 기기 (가정용 방송통신기자재)	이 기기는 가정용(B 급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

**For C.A. US (Proposition 65)**

**WARNING**

This product contains chemicals known to cause cancer, birth defects and other reproductive harm, including lead.

