

**AIWA**

Equipment Model	Battery #
AV-50M	144
CV-50/60/80	EPP-103-2
VF-80	EPP-103-2

**BATTERY MODEL TO BATTERY MODEL**

NP-22	EPP-103-2
-------	-----------

**AIKA**

Equipment Model	Battery #
PVC-4/8/8S	EPP-105
PVC-100E	110**

**BATTERY MODEL TO BATTERY MODEL**

BPN100/800	110**
------------	-------

**BAUER-BOSCH**

Equipment Model	Battery #
VCC-306	EPP-104
VCC-326	EPP-107 / EPP-107-2
VCC-400	112C
VCC-506	EPP-104
VCC-516/526/550	EPP-100C / EPP-100
VCC-606AF/610/616AF	110**
VCC-651	150**
VCC-656/660AF	110**
VCC-806/816AH	EPP-107 / EPP-107-2
VC-826	EPP-107 / EPP-107-2
VRP-30	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

BA20	EPP-101C
BA32-1	EPP-100C / EPP-100
BA400	112C
BA600/601	110**
BA800	EPP-107 / EPP-107-2

**BELL & HOWELL**

Equipment Model	Battery #
JMJ-20910	150**
JSJ-20900	EPP-146-3.5

**BATTERY MODEL TO BATTERY MODEL**

64324217	150**
----------	-------

**BLAUPUNKT**

Equipment Model	Battery #
CR-1500/1800/2000S	EPP-100C / EPP-100
CR-4800/5000/6000	110**
CR-8000/8010	EPP-107 / EPP-107-2
CR-8080	EPP-107 / EPP-107-2
PTV-260	EPP-100C / EPP-100
PTV8-77	109**

**BATTERY MODEL TO BATTERY MODEL**

AX-77/80 109\*\*

**CANON**

Equipment Model	Battery #
A-1, A-1.MARK II	EPP-132
A-2	118**
A-5	BNH-194
A-10	118**
A-50	BNH-194
CR-30A	EPP-100C / EPP-100
CV-T60/65/70	EPP-100C / EPP-100
D30	BLI-193-*
E-06/07/08/09	118**
E-20/30/40	118**
E-50/51/53/57	118**
E-60/61/63/65/66/67	118**
E-70/77	118**
E-80/90	118**
E-210/230/250	118**
E-350	118**
E-440/460	118**
E-520	118**
E-640/660	118**
E-700/708	118**
E-800/808	118**
ELURA	BLI-169-*
ELURA 2, ELURA 2MC	BLI-199-*
ELURA 10, ELURA 20MC	BLI-199-*
EOSD30, EOSD60	BLI-193-*
EQ-350	118**
ES-10V/20V/40	118**
ES-50/55	BLI-161-*
ES-60/65	BLI-161-*
ES-70/75/80/90	118**
ES-100/170/180/190	118**
ES-200/200A/270/280/290	118**
ES-300/400	118**
ES-410V/420V	BLI-161-*
ES-500	118**
ES-520A	BLI-161-*
ES-550	118**
ES-600	118**
ES-750	118**
ES-800/870	118**
ES-900/970	118**
ES-1000	118**
ES2000/2500	118**
ES-3000	118**
ES-4000/5000/6000/6500	BLI-161-*
ES-7000/8000	BLI-161-*
ES-8100V/8200V/8400V	BLI-161-*
EX-1	118**
F-1000S	EPP-100C / EPP-100
FR-1	BLI-161-*

**CANON (CONTINUED)**

G1 (INSIDE MOUNT)	BLI-193-*
G2	BLI-193-*
GLI	BLI-161-*
H-460/480	118**
H-640/660/680	118**
H-800/850	118**
L1, L2	EPP-132
LX-100	EPP-132
OPTURA	BLI-161-**
OPTURA 100MC, OPTURA PI	BLI-193-*
POWERSHOT A5, A50	BNH-194
POWERSHOT G1/G2	BLI-193-*
POWERSHOT PRO70	BNH-194
POWERSHOT PRO90is	BLI-193-*
POWERSHOT S10/20	BNH-194
POWERSHOT S30/40	BLI-204
POWERSHOT S100 /S110	BLI-198
POWERSHOT S300/S330	BLI-198
PRO90IS	BLI-193-*
S10/20	BNH-194
UC1	118**
UCS1, UCS2, UCS3, UCS5	118**
UCX2	BLI-161-*
ULTURA	BLI-161-*
VC-1	118**
VC-10/20/30	EPP-101C
VC-200	EPP-101C
VCS-1/2/3/5	118**
VCX-2	BLI-161-*
VHS PORT	EPP-101C
VISTURA	BLI-161-**
VM-E2/2N	EPP-116
VME-70A	118**
VR-10/20/20A	EPP-101C
VR-30A/40A/50A	EPP-101C
VT-LC50	118**
XL1, XL1S	BLI-161-*
ZR	BLI-169-**
ZR-10/20	BLI-193-*
ZR-25MC/30MC	BLI-193-*
ZR-40/45MC/50MC	BLI-193-*

**BATTERY MODEL TO BATTERY MODEL**

BP-10/10A	EPP-101C
BP-30/30A31/32	EPP-100C / EPP-100
BP-80/85	BLI-161-*
BP-100	EPP-100C / EPP-100
BP-406/412/422	BLI-199-*
BP-511/512/522/535	BLI-193-*
BP-608/617	BLI-169-*
BP-711/714/729/818	118**
BP-911/914/915	BLI-161-*

**CANON (CONTINUED)**

**BATTERY MODEL TO BATTERY MODEL**

BP-924/927/930	BLI-161-*
BP-941/945	BLI-161-*
BP-E22	EPP-116
BP-E30A	EPP-101C
BP-E77/E77K	118**
BP-E718	EPP-132
BP-E722	118**
ES-410	BLI-161-*
NB-1L/1LH	BLI-198
NB-2L	BLI-204
NB-5H	BNH-194

**CHINON**

Equipment Model	Battery #
C8	EPP-107 / EPP-107-2
C8-1003	EPP-107 / EPP-107-2
C8-C60	EPP-107 / EPP-107-2
C8-SC70/SC80	EPP-107 / EPP-107-2
C8-SC90	EPP-107 / EPP-107-2
C8-SC96/SC98	150**
C8-SL70	EPP-105
CV-765/770	EPP-100C / EPP-100
CV-C70	EPP-100C / EPP-100
CV-C600	110**
CV-C800	EPP-100C / EPP-100
CV-T7	EPP-100C / EPP-100
CV-T60/T60G/T63/T65	EPP-100C / EPP-100
CV-T70/T72/T73	EPP-100C / EPP-100
CV-T80	EPP-100C / EPP-100
CV-T84	130C
CV-T124	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

BP-80	EPP-100C / EPP-100
C8-B33	EPP-107 / EPP-107-2
C8-B36-1/B36-2	150**
CV-BP80/BP82	EPP-100C / EPP-100
CV-BP89	130C
CVC-BP82	110**

**CURTIS MATHES**

Equipment Model	Battery #
768, 770	EPP-100C / EPP-100
AV800	EPP-100C / EPP-100
AV850	110**
BV880	EPP-100C / EPP-100
CV800	EPP-100C / EPP-100
DV600	110**
DV700	130C
DV800	EPP-100C / EPP-100
FV500	130C

FV600	150**
FV700/800	130C
FV900	150**
GV700	130C
HV773	EPP-100C / EPP-100
MV800	112C
PV800	EPP-100C / EPP-100
QD00004	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

14B655-001	EPP-101C
VSBS001	112C
VSBS0016	130C

**DAEWOO**

Equipment Model	Battery #
DVM-131X	109**
DVM-210N	109**
DVM-239F	EPP-104

**ELMO**

Equipment Model	Battery #
ECR-8	EPP-107 / EPP-107-2
ECR-600	112C
ER-10	EPP-100C / EPP-100
PRO.ECR-8S	EPP-107 / EPP-107-2

**BATTERY MODEL TO BATTERY MODEL**

BP-10	EPP-100C / EPP-100
EA-BP8	EPP-107 / EPP-107-2
EA-BP60	112C
PVBP80	EPP-100C / EPP-100

**EMERSON**

Equipment Model	Battery #
70-2026	EPP-101C
V-CAM-14/18	110**
VHS	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

1411200001	110**
ERB-22	101
ERB-122	101
ERB-150/151	110**
ERB-155	150**

**FERGUSON**

Equipment Model	Battery #
C303/08	110**
3V01	110**
3V41	EPP-105
3V50	EPP-105
FC15	110**
FC23/27/28	110**

**BATTERY MODEL TO BATTERY MODEL**

VA282/283293/310	EPP-105
------------------	---------

VA314/315/337	110**
---------------	-------

**FISHER**

Equipment Model	Battery #
FVC-10/10A	109**
FVC-701/720/730/750/770	109**
FVC-800	109**
FVC-801	EPP-103-2
FVC-860/880	109**
FVC-901/950/990	109**
FVC-1000/2000/4000	109**
FVC-P701/730/750/770	109**
FVC-P880	109**
FVC-P901/950/990	109**
FVC-S2	109**
FVP-201	EPP-103-2
FVP-501/503	EPP-103-2
FVP-803	EPP-103-2

**BATTERY MODEL TO BATTERY MODEL**

BP-80	EPP-100C / EPP-100
C8-B33	EPP-107 / EPP-107-2
C8-B36-1/B36-2	150**
CV-BP80/BP82	EPP-100C / EPP-100
CV-BP89	130C
CVC-BP82	110**

**FUJI**

Equipment Model	Battery #
F-120SW/122SW	109**
F-60Y	109**
F-610/615/620	109**
F-810	109**
FF-60/66	109**
FH-80	109**
FINEPIX 50i	BLI-203
FINEPIX 4800/4900	BLI-183
FINEPIX 6800/6900	BLI-183
FINEPIX F601	BLI-203
H-80	109**
H-128SW	109**
M-6AF	EPP-103-2
M-600AF/680/690	109**
M-830HR/890	109**
MX-500/600/600Z/700	BLI-174
MX-1700/2700/2900	BLI-183
P-40U	109**
P-90/100	EPP-103-2
P-300AF/600AF	EPP-103-2
P-650/660/850	109**
Z-600AF	EPP-103-2

**FUJI**

**BATTERY MODEL TO BATTERY MODEL**

NP-55	109**
NP-60	BLI-203
NP-77H	109**
NP-80	BLI-183
NP-100	BLI-174
VM-BPL30A	BLI-166-*
VMBPL60A	BLI-166-*

**G.E.**

<b>Equipment Model</b>	<b>Battery #</b>
1CVD2020X/2021X	EPP-102
1CVD3020X	EPP-102
1CVD4020/4021	101
1CVD5021	EPP-100C / EPP-100
1CVD5021X/5023	EPP-100C / EPP-100
1CVD5025B/5025X	EPP-100C / EPP-100
1CVD5027/5028B	EPP-100C / EPP-100
1CVK5040	EPP-100C / EPP-100
1CVM6060E	112C
1CVM6080	EPP-102
1CVM8080	EPP-100C / EPP-100
1CVP2020/2022X	EPP-102
1CVP4020X/4022/4022X	101
1CVP4024/4024X	101
1CVP5021	EPP-100C / EPP-100
1CVP5022B/5022X	EPP-100C / EPP-100
1CVP5024/5026X	EPP-100C / EPP-100
1CVP5027/5028B	EPP-100C / EPP-100
1CVP5030	EPP-100C / EPP-100
1CVP6022/6024	EPP-100C / EPP-100
1CVP6026/6028	EPP-100C / EPP-100
1CVP6030	EPP-100C / EPP-100
5036	EPP-100C / EPP-100
5200	EPP-100C / EPP-100
5424, 5426, 5428	EPP-100C / EPP-100
5430	EPP-100C / EPP-100
5440, 5442	EPP-100C / EPP-100
5740, 5747	EPP-100C / EPP-100
9-9605/9606	EPP-100C / EPP-100
9-9607/9608/9609	EPP-100C / EPP-100
9-9610	EPP-100C / EPP-100
9-9705/9709	110**
9-9710/9711	110**
9-9712/9715	110**
9-9719	EPP-105
9-9805/9806/9807/9808	EPP-100C / EPP-100
9-9810/9815	EPP-100C / EPP-100
CG-400	109**
CG-501/504/505/506	150**

CG-515	150**
CG-650/670/671/680/681	130C
CG-683	EPP-152
CG-684/686	130C
CG-690/691/695	150**
CG-696/697/698	150**
CG-700/701	EPP-100C / EPP-100
CG-703	EPP-152
CG-706	EPP-142S
CG-732/733	EPP-142S
CG-800/805	150**
CG-812/814/818	109**
CG-895	130C
CG-911	EPP-100C / EPP-100
CG-9805/9806/9807	EPP-100C / EPP-100
CG-9808/9809	EPP-100C / EPP-100
CG-9810/9815	EPP-100C / EPP-100
CG-9820/9825	EPP-100C / EPP-100
CG-9906/9907/9908	130C
CG-9910/9911	130C
CG-9915/9920	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

1CVA100	EPP-102
1CVA115	EPP-101C
1CVA125	EPP-100C / EPP-100
1CVA135	112C
1CVA145	110**
1CVA150	110**
1CVA155	EPP-100C / EPP-100
1CVA156	130C
1CVA157C/158C	150**
1CVA190	EPP-146-3.5
AV-608	109**
AV-8MM	109**
GB-090	EPP-152
SV-LB5	EPP-152

**GOLDSTAR**

<b>Equipment Model</b>	<b>Battery #</b>
GS-8AF	EPP-103-2
GS-E2	109**
GS-HE1	109**
GS-LT1	EPP-124-2
GS-V1M	EPP-104
GS-V21M	EPP-154-2
GVC-A425/C425/D425	EPP-154-2
GVC-D475/E475/F475	EPP-154-2
GVC-F477	EPP-154-2
LC-E76M (REAR)	109**
VM-BP3M	EPP-154-2

**BATTERY MODEL TO BATTERY MODEL**

243-696T	EPP-154-2
243-949A	EPP-154-2

534-014EE	EPP-124-2
GS-E2	109**
VM-BP2M	EPP-104
VM-BP4M/6M	EPP-154-2

**GRAETZ**

<b>Equipment Model</b>	<b>Battery #</b>
SK-60	109**
TMC-93	110**
TMC-4877	110**
TMC-4888	109**

**GRUNDIG**

<b>Equipment Model</b>	<b>Battery #</b>
VS-150AF	EPP-104
VS-160/170/180	EPP-100C / EPP-100
VS-8000/8100/8320	109**
VS-8500/8800	109**
VS-C05	EPP-105
VS-C20/30/40/45	110**
VS-C50	EPP-105
VS-C55	109**
VS-C60/70	110**
VS-C75	109**
VS-C80/85	110**
VS4-8	109**

**BATTERY MODEL TO BATTERY MODEL**

BP-60	110**
BP-70	109**
BP-80	110**
BP-82	109**
BP-122	EPP-100C / EPP-100
BP-150/151	EPP-104

**HITACHI**

<b>Equipment Model</b>	<b>Battery #</b>
DZ-MV100A	BLI-172-*
THIN-MAN	EPP-145-1.4
TWIST/SHOOT	EPP-145-1.4
VJP170	111
VLH-100L	BLI-166-*
VM-H945LA/955LA	BLI-166-*
VM30	EPP-106
VM100/200A/500E/600E	EPP-104
VM825LA	143**
VM835LA	BLI-166-*
VM1200	EPP-104
VM1300/1350	EPP-142
VM1350A	EPP-142S
VM1400A/1600A	EPP-142S
VM1700A/1800A/1900	EPP-142S
VM2000A/2100A	EPP-104
VM2140	EPP-142S
VM2250A/2270A	EPP-124-2

**HITACHI**

Equipment Model	Battery #
VM2300	EPP-142
VM2300A	EPP-142S
VM2300E	EPP-142
VM2380	EPP-124-2
VM2400A	EPP-142
VM2400E	143**
VM2500A	EPP-142
VM2580E	EPP-142S
VM2600A/2800A/2900	EPP-142S
VM3000A	EPP-104
VM3100A/3150/3150A	EPP-104
VM3200/3250A	EPP-124-2
VM3260/3270A	EPP-124-2
VM3300A/3350	EPP-142
VM3700/3700A/3800A	EPP-142S
VM4400A	EPP-142S
VM4400E	EPP-142
VM5000A/5100A	EPP-104
VM5200	EPP-124-2
VM5300A/5350A	EPP-142
VM5400A/5400C	EPP-142S
VM5720A	EPP-124-2
VM6000A/6100A	EPP-104
VM6300A/6500A	EPP-142S
VM7000A	EPP-104
VM7300A/7400A	EPP-142S
VM8200A/8300A	EPP-142S
VM8400LA	EPP-142S
VMBP82G	143**
VMBP84	143**
VMBP826	143**
VMC1A/1E/1R/1S	EPP-145-1.4
VMC2A	EPP-145-1.4
VMC11A	EPP-106
VMC30A	EPP-106
VMC34	EPP-124-2
VMC40E	EPP-106
VMC50A/52/60	EPP-106
VMD975LA	BLI-166*
VME10A/10E	143**
VME15A/15E	143**
VME22A/23A/23E/25A/25E	143**
VME53A/54/55A/56A/58A	143**
VME110/130A	143**
VME220A/220A/230A	143**
VME310	143**
VME340A	BLI-166*
VME410	143**
VME455LA	BLI-166*
VME510/520A/521A	143**

VME530A/535LA
VME540A/545LA
VME555LA
VME565
VME625LA
VME635A/635LA/645LA
VME755LA
VME855LA
VMH10/18A
VMH35LA
VMH38A/39A
VMH57A/59A
VMH71A/81A
VMH100LA
VMH620A
VMH640A
VMH665LA, VMH675LA
VMH710A/720A/725LA
VMH755LA
VMH825LA
VMH835LA/855LA
VMH945LA/955LA
VMS7200A/7200E/7280E
VMS8100A
VMS8200A
VMSP1A
VT3P/5P/7P/8A
VT-4/98
VT6000/6500
VT6800/6800A
VTCL50EM

**BATTERY MODEL TO BATTERY MODEL**

DZ-BP16/BP28
VMBP21/22
VMBP51/52
VMBP60
VMBP61A/63A
VMBP64
VMBP64AS
VMBP65/66/67
VMBP71
VMBP81
VMBP82/83/84
VMBP502
VMBPL13, VMBPL13A
VMBPL27A, VMBPL30A
VMBPL60A
VME38A/39A
VME58A
VMNP720
VTBP7A
VTBP65A

BLI-166*
BLI-166*
BLI-166*
BLI-166*
143**
BLI-166*
BLI-166*
BLI-166*
143**
BLI-166*
143**
BLI-166*
BLI-166*
153
143**
BLI-166*
BLI-166*
143**
BLI-166*
BLI-166*
EPP-124-2
EPP-104
EPP-142S
143**
111
111
EPP-102
EPP-102
EPP-124-2

BLI-172*
EPP-104
EPP-106
EPP-102
EPP-124-2
EPP-142
EPP-142S
EPP-142
EPP-124-2
EPP-145-1.4
143**
BLI-166*
BLI-166*
BLI-166*
BLI-166*
143**
143**
153
111
EPP-102

**ITT**

Equipment Model	Battery #
VMC-3639A	110**
VMC-3865	EPP-105
VMC-3875/3877	EPP-105
VMC-3877AF	110**
VMC-3888	EPP-105
VMC-6000	110**

**JVC**

Equipment Model	Battery #
GC-QX3/QX3HDU/QX5HDU	BLI-197
GC-X1EK	BLI-197
GF-450	110**
GF-500U/700U	110**
GF-S550U	110**
GR-25U/35U	110**
GR-40/40U/45	110**
GR-60E	150**
GR-60U/65EG/65U	110**
GR-303/303EG/303U	110**
GR-323U	150**
GR-400/450	110**
GR-5550U	110**
GR-5505	110**
GR-A1E/A1U	110**
GR-A30/30E/30S/30U	110**
GR-A60S/60U	110**
GR-AK5BKU/5GYU	150**
GR-AW1/1U	150**
GR-AX2/2U	150**
GR-AX5/5EG/5U	150**
GR-AX7EG/7U	150**
GR-AX10/10EG/10U	150**
GR-AX17/17U	150**
GR-AX25U/26U	150**
GR-AX30/33/33U	150**
GR-AX34U/35/37	150**
GR-AX46U/47U/48U	150**
GR-AX50/50U	150**
GR-AX55/55U	150**
GR-AX70U/74U/75U/76/77U	150**
GR-AX81U/84U	150**
GR-AX90U/94U/96U/97U	150**
GR-AX200U/201U/202U	150**
GR-AX210/210U	150**
GR-AX220/220U	150**
GR-AX230U/250	150**
GR-AX300U/310U	150**
GR-AX350U	150**
GR-AX400U/401U/404U	150**
GR-AX410U/420U/430U	150**
GR-AX500U/510U	150**

**JVC**

Equipment Model	Battery #
GR-AX606U/610U	150**
GR-AX640U/655U/660U	150**
GR-AX700U/710U/717UM	150**
GR-AX720/730U/760U	150**
GR-AX800U/808U	150**
GR-AX810/810U	150**
GR-AX820US/830US	150**
GR-AX840U/841U/844U	150**
GR-AX900U/910/910U/911U	150**
GR-AX920/930U/940U/970U	150**
GR-AX1010U	150**
GR-AXM1U/2U/4U	150**
GR-AXM10U	150**
GR-AXM20U/25U/27U	150**
GR-AXM30U/40U/50U	150**
GR-AXM70U/80U/100U	150**
GR-AXM210U/220U	150**
GR-AXM225U/230U/231/270	150**
GR-AXM300U/310U/330U	150**
GR-AXM510/511	150**
GR-AXM650U/AXM670	150**
GR-AXM700/700U	150**
GR-AXM710U/750U	150**
GR-AXM800/840U/841U	150**
GR-AXM900U/910U/920U	150**
GR-C1U/2U	110**
CR-C7	110**
GR-C7S	150**
GR-C7U	110**
GR-C9	110**
GR-C11/11S	110**
GR-C25	110**
GR-C30/35U/40	110**
GR-C55	110**
GR-C250	110**
GR-DV1/1U	BLI-160
GR-DV3/3U	BLI-170*
GR-DV14	BLI-160
GR-DV510U	150**
GR-DV2000/DV2000U	BLI-192*
GR-DVA1/1U	150**
GR-DVF3A/DVF10/DVF20	150**
GR-DVF11/21/31	BLI-182-1.5
GR-DVL100U/105U/107U	BLI-192*
GR-DVL120/200U	BLI-192*
GR-DVL320/522/725/820	BLI-192*
GR-DVL300U/305/307/310	BLI-192*
GR-DVL400U	BLI-192*
GR-DVL500U/505U/507U	BLI-192*
GR-DVL510U	BLI-192*
GR-DVL600U	BLI-192*

GR-DVL707U	
GR-DVL800/U805U/815/817	
GR-DVL915U	
GR-DVL9000/9000U	
GR-DVL9500U/9800U	
GR-DVM1	
GR-DVM5/5U	
GR-DVM50U/55U	
GR-DVM70U/75U/80U/90U	
GR-DVP3U	
GR-DVX	BLI-168
GR-EZ1	150**
GR-HF805	150**
GR-LT7	150**
GR-M3/M3U/M5/M5U	150**
GR-M7/7PRO/7U	150**
GR-S27/29	150**
GR-S35/S55	110**
GR-S70EG/S70U	110**
GR-S75/S77E/S77U	110**
GR-S99/S99EG	110**
GR-S505EG/505U	110**
GR-S707/707E/707EG/707U	110**
GR-SV3/S3V/S7U	150**
GR-SX9U	150**
GR-SX90	150**
GR-SX851/960U	150**
GR-SXM-230U/320U/330U	150**
GR-SXM515U/520U	150**
GR-SXM525U/527U	150**
GR-SXM720U/730U	150**
GR-SXM850U	150**
GR-SXM920U/930U/950U	150**
GR-SZ1/SZ7/SZ9U	150**
GR-VBM1	BLI-162*
GS-1000	EPP-100C / EPP-100
GV-HT1U	BLI-170*
GY-DV500U	114**
HRP-1U	110**
SCF007U	110**
WEATHERCAM	150**

**BATTERY MODEL TO BATTERY MODEL**

BN-V5GU/V6GU/V7GU	110**
BN-V11U/V12U/V14U/V18U	150**
BN-V20U/V22U/V25U	150**
BN-V37	BLI-197
BN-V50U/V60U/V66RU	150**
BN-V75U/V77RU	110**
BN-V101	BLI-174
BN-V107	BLI-202*
BN-V111U/V112U	150**
BN-V114	BLI-202-1.5
BN-V200U	150**

BLI-192*	BN-V207U/V214U	BLI-182-1.5
BLI-192*	BN-400U	150**
BLI-192*	BN-V408U/V416U/V428U	BLI-192*
BLI-162*	BN-V507U/V514U	BLI-175*
BLI-170*	BN-V607UV/615UV/628U	BLI-170*
BLI-162*	BN-V712U/V714U	BLI-160
BLI-170*	BN-V812U/V814U/V856U	BLI-162*
BLI-175*	BN-V907U	BLI-168
BLI-175*	BN-V970U	BLI-160
BLI-202*	NB-P5U/P6U/7/P7U	110**
	NBP-8/9	EPP-105

**KODAK**

Equipment Model	Battery #
4800	BLI-183

Battery Model	Battery #
KLIC-3000	BLI-183

**KYOCERA**

Equipment Model	Battery #
DSC-F707	BLI-180*
DSC-P1	173C*
DSC-S75/S85	BLI-180*
FINECAM S3	BLI-207
KD-200K	EPP-103-2
KD-530	109**
KD-700	EPP-113
KD-1000/1100U	EPP-103-2
KD-1700	109**
KD-2010U/3010U/3030U	EPP-113
KD-5010/5050/5820	109**
KD-H130/H150/H170	109**
KD-M710/M730/M770	109**
KD-S530	109**
KD-S820	EPP-113

**LOEW OPTA**

Equipment Model	Battery #
CC90	EPP-104
PROF1800/1810/1820	EPP-113

**MAGNAVOX**

Equipment Model	Battery #
8290	112C
8292/8293	EPP-100C / EPP-100
8380	EPP-100C / EPP-100
8400/8450/8451/8474	EPP-101C
8900	EPP-101C
CK300	EPP-101C
CV5320AV	EPP-100C / EPP-100
CVJ310/312/320/322	EPP-100C / EPP-100
CVJ340/350	EPP-100C / EPP-100
CVJ360	130C

**MAGNAVOX**

Equipment Model	Battery #
CVK300/310/315/320	130C
CVK321/332/342/352	EPP-100C / EPP-100
CVK610	130C
CVL300/301/310/318/319	130C
CVL320/325	EPP-100C / EPP-100
CVL335/345	150**
CVL610/611/612/620	150**
CVL810	130C
CVM310/315	130C
CVM320/325	150**
CVM610/620/630	150**
CVM710/720	130C
CVN310AV	130C
CVN610/620/630/630AV	150**
CVN715	EPP-151
CVR315AV	EPP-154-2
CVR325AV/330AV/335AV	130C
CVR630	150**
CVS315AV/325AV	EPP-154-2
CVS620	150**
CVT325/330/340AV	EPP-154-2
CVT620/630/640	150**
VR8207GY01	112C
VR8208AV01/8245BK01	EPP-100C / EPP-100
VR8285	110**
VR8285AV01	EPP-105
VR8290GY01	112C
VR8292/8293	EPP-100C / EPP-100
VR8294/8294AF	EPP-100C / EPP-100
VR8295/9297	110**
VR8350/8355	EPP-102
VR8356	EPP-101C
VR8357	110**
VR8370/8371/8377/8383	EPP-102
VR8380/8382	EPP-100C / EPP-100
VR8400	EPP-100C / EPP-100
VR8450/8451/8453/8454	EPP-100C / EPP-100
VR8455/8456/8457	EPP-100C / EPP-100
VR8462/8470	EPP-101C
VR8471/8472/8474/8475	EPP-100C / EPP-100
VR8480	EPP-100C / EPP-100
VR8481	EPP-101C
VR8484/8485/8486	EPP-100C / EPP-100
VR8570/8572	EPP-100C / EPP-100
VR8585/8590/8592	EPP-100C / EPP-100
VR9143	EPP-100C / EPP-100
VR9240AV/9244/9246	EPP-100C / EPP-100
VR9254/9256AV	110**

VR9260A/9297	110**
VR9656	EPP-105

**BATTERY MODEL TO BATTERY MODEL**

AR8378BK01	EPP-100C / EPP-100
AR8390BK01	EPP-102
AR8395BK01	EPP-101C
V80039BK01	EPP-100C / EPP-100
V80063BK01	112C
V80076BK01/80085BK01	110**
V80086BK01	EPP-100C / EPP-100
V80096BK01	130C
V80115BK01/80116BK01	150**
V80139BK01	EPP-151
V80146BK01/80149BK01	EPP-154-2
VE550UE	EPP-101C
VSBS0011	EPP-100C / EPP-100
VSBS0016	130C

**MARANTZ**

Equipment Model	Battery #
CV-B800	EPP-100C / EPP-100

**MEMOREX**

Equipment Model	Battery #
16-827/828	EPP-146-3.5
16-858/859	109**
CRD-0050	150**
MODEL 103	EPP-142
MODEL 127, 128	EPP-146-3.5
MODEL 153, 154	109**
MODEL 155	150**
MODEL 157	143**
MODEL 158	109**
MODEL 16837	130C
SM1000	EPP-104
SM2000	EPP-106
SM4200/4300/4400	130C
SM8400	150**

**BATTERY MODEL TO BATTERY MODEL**

BP-30RS	130C
BT-30RS	EPP-146-3.5
BT-70	109**
CS6012	109**
OB-15	150**
T16-BP64	EPP-142S
VM-BP21M	EPP-104
VSBW0003	150**

**METZ**

Equipment Model	Battery #
9624	EPP-105
9625	110**
9628, 9629	EPP-107 / EPP-107-2
9637, 9702	150**

**MINOLTA**

Equipment Model	Battery #
8-80/81	EPP-113
8-308/308E/378	143**
8-406/406E/418/428/438	143**
8-761/761C/762CS/778	143**
8-808/808E/812/832	EPP-113
8-838	143**
8-842	143**
8-848	143**
8-852/862/863S/864S	143**
8-878	143**
8-912/918	143**
8-8000/8100/8200	143**
770S	111
C-1E	EPP-128
C-50/51	110**
C-503/512/513/516/518	150**
C-522/532/538/542	150**
C-550/552	150**
C-560/560C/561	150**
C-562CL/563CLS	150**
C-570	150**
C-606/606E/618	150**
CR-80AF/81AF	EPP-124-2
CR-800S/880	EPP-113
CR-1000A	EPP-105
CR-1000S/1100S/1200S	EPP-104
CR-8000S/8100	EPP-113
KR-1000	EPP-104
MS-2100	EPP-104
V-10/10R/11/11R	EPP-124-2
V-16/16R/18/18R/20/20R	EPP-142
V-118	EPP-142
V-218/228	EPP-142S
V-700	EPP-101C
V-1400/2000/2100	EPP-104

**BATTERY MODEL TO BATTERY MODEL**

B-8002	EPP-113
BP-800	EPP-113
BP-1001/1002	EPP-104
BP-3001	EPP-105
BP-3301	EPP-128
BP-8001/8002	EPP-113
BP-M3001	EPP-105
VBC-166	EPP-142
VBP-100/101	EPP-124-2
VBP-160/161/165/166	EPP-142S
VBP-400/401/410	143**
VBP-500/501	110**
VBP-600/601/630	150**
VBP-912	143**

**MITSUBISHI**

Equipment Model	Battery #
CVK-G99	110**
HS-C1XE	150**
HS-C20U	EPP-105
HS-C30U	110**
HS-C45/50	110**
HS-CX1/CX4	150**
HS-VX4E	150**
HS-C4U/C7U	150**
HS-F10UR	EPP-104

**BATTERY MODEL TO BATTERY MODEL**

BY-B99	110**
BY-C101/F102	110**
BY-F101/F102	EPP-104
BY-U1/U2	150**

**NEC**

Equipment Model	Battery #
CV-10U	112C
CV-30U/40U	EPP-100C / EPP-100
CVB-70U	110**
EM-ABU	EPP-103-2
NCVK400	110**
V-20U/40U	EPP-100C / EPP-100
V-50U (REAR)	112C
V-300/400	EPP-100C / EPP-100
VM10U	112C
VM40U	EPP-100C / EPP-100
VMA80	EPP-103-2

Battery Model	Battery #
BC-10	112C
VB-10U	112C
VB-30U/50U	EPP-100C / EPP-100

**NIKON**

Equipment Model	Battery #
ACTION PRO	EPP-107 / EPP-107-2
COOLPIX 775/880/885	BLI-201
COOLPIX 950/995/5000	BLI-201
VHS SPORT	EPP-101C
VN-300/310/330/340/360	109**
VN-400/500/550	109**
VN-700	109**
VN-720/730	153-1.5C
VN-750	109**
VN-800/801/810	EPP-107 / EPP-107-2
VN-820/830/840	109**
VN-850/860/870	109**
VN-900/910/960	109**
VN-3000	EPP-101C

VN-7000	109**
VN-8200	109**
VN-9000/9100/9500	109**
VS-BL71	BLI-156-*

**BATTERY MODEL TO BATTERY MODEL**

BP-80	EPP-107 / EPP-107-2
BP-300	EPP-101C
EN-EL1	BLI-201
LRHM3WM	BLI-201
NP-55/66H/77/77H	109**
NP-500	153-1.5C

**NORMANDE**

Equipment Model	Battery #
CV100	110**
CV155	EPP-105
CV301	110**
CV1100	110**
CV2001, CV2101	EPP-105
CV2201	110**
RP300	110**
SV500	110**

**BATTERY MODEL TO BATTERY MODEL**

AC-155/2005	EPP-105
-------------	---------

**OLYMPUS**

Equipment Model	Battery #
VC-103	EPP-101C
VC-104/105/106	EPP-100C / EPP-100
VC-106A	EPP-101C
VX-43/54/81/82/82E	109**
VX-401	112C
VX-402	EPP-100C / EPP-100
VX-402 (REAR)	112C
VX-403	110**
VX-404/405/406	EPP-100C / EPP-100
VX-407	130C
VX-801/802/802E/803	EPP-107 / EPP-107-2
VX-806	109**
VX-H804	EPP-107 / EPP-107-2
VX-S405	EPP-100C / EPP-100
WPP-1000	EPP-107 / EPP-107-2
WPP-1500	EPP-107 / EPP-107-2
WPP-5000	EPP-107 / EPP-107-2

**BATTERY MODEL TO BATTERY MODEL**

NP-55/77H	109**
VFBA5U	112C
VFBP1	EPP-101C
VFBP3, VFBP3U	EPP-100C / EPP-100
VFBP6, VFBP6U	112C
VFBP7, VFBP7U	EPP-100C / EPP-100
VFBP8U	130C
VFBP81	EPP-107 / EPP-107-2

**ORION**

Equipment Model	Battery #
C-MV1/MV11	110**
C-MV103/MV203	110**
VC-M0300	150**

**BATTERY MODEL TO BATTERY MODEL**

OD-18	150**
-------	-------

**PANASONIC**

Equipment Model	Battery #
AFX3	EPP-100C / EPP-100
AFX8, AFX12	EPP-130C
AG-100/155	EPP-112C
AG-160/170/180	EPP-100C / EPP-100
AG-185U/187/188	EPP-130C
AG-190	EPP-100C / EPP-100
AG-195-196U	EPP-130C
AG-400P/450	EPP-100C / EPP-100
AG-455/456	EPP-130C
AG-460	EPP-100C / EPP-100
AG-461	EPP-130C
AG-2400/6400	EPP-100C / EPP-100
AG-BP188U	EPP-130C
AG-BP202/212DX	EPP-100C / EPP-100
AG-DVC15	BLI-172-*
AG-EZ1/EZ20/EZ30	BLI-162-*
AG-V50	EPP-100C / EPP-100
CGR-D320	BLI-172-2.8
EB362	EPP-100C / EPP-100
IQ-PBA306	150**
M-3000	EPP-130C
MC-50	110**
NV-100	EPP-101C
NV-180	EPP-100C / EPP-100
NV-3000	EPP-102
NV-6500/6600	EPP-101C
NV-8410	EPP-102
NV-8420	EPP-101C
NV-A1EN	EPP-155-*
NV-C1	BLI-172-*
NV-CS1EN	EPP-155-*
NV-DA1/DA1EN	BLI-172-*
NV-DE3	BLI-162-*
NV-DJ1/DJ100	BLI-162-*
NV-DS1/DS5	BLI-162-*
NV-DS77/DS77EN	BLI-172-*
NV-DX1/DX100	BLI-162-*
NV-EX1/EX1EN	BLI-172-*
NV-G2	150**
NV-M1/M2/M3	112C
NV-M5/M7	EPP-100C / EPP-100
NV-M7EO/M7EW	EPP-100C / EPP-100
NV-M8PX/M9/M10	EPP-100C / EPP-100

**PANASONIC**

<b>Equipment Model</b>	<b>Battery #</b>				
NV-M10K/M30	110**	PV-800	130C	PV-DV600/DV600K	BLI-172-*
NV-M50/M70/M90	110**	PV-808	150**	PV-DV601/DV602	BLI-172-*
NV-M350	110**	PV-810	130C	PV-DV700	BLI-162-*
NV-M400	130C	PV-822	EPP-100C / EPP-100	PV-DV701	BLI-172-*
NV-M1000/M8000	EPP-100C / EPP-100	PV-900	130C	PV-DV702/DV710	BLI-162-*
NV-MC5/MC6/MC6EG	110**	PV-908	150**	PV-DV800/DV800K/DV852	BLI-172-*
NV-MC10EG	110**	PV-910/918/940/950	130C	PV-DV900/DV900K	BLI-172-*
NV-R200/R200PN	EPP-155-*	PV-960	150**	PV-DV910/DV910K	BLI-172-*
NV-R500EN/R550EN	EPP-155-*	PV-1220	112C	PV-DV950	BLI-162-*
NV-RX7EN	EPP-155-*	PV-2200	EPP-100C / EPP-100	PV-DV952	BLI-172-*
NV-S1/S2/S6/S7/S8	150**	PV-5110	EPP-100C / EPP-100	PV-DV1000	BLI-162-*
NV-S100	150**	PV-5150	110**	PV-IQ203/IQ204/IQ205	150**
NV-S850EN/S950EN	EPP-155-*	PV-5200/5350	EPP-100C / EPP-100	PV-IQ214/IQ215	150**
NV-VX17EN/VX27EN	BLI-181-*	PV-5372	150**	PV-IQ244D/IQ255	150**
NV-VX57EN	BLI-181-*	PV-5400	EPP-101C	PV-IQ294/IQ295	150**
PK-410/412/450/452	EPP-100C / EPP-100	PV-5420	EPP-100C / EPP-100	PV-IQ303/IQ304/IQ304A	150**
PK-500/503/530	EPP-100C / EPP-100	PV-5500	EPP-101C	PV-IQ305/IQ314/IQ315	150**
PK-557/558	EPP-100C / EPP-100	PV-5630	150**	PV-IQ325/IQ344/IQ375	150**
PL-597	EPP-101C	PV-5800/5810	EPP-100C / EPP-100	PV-IQ384/IQ384A	150**
PK-700	130C	PV-5850	EPP-101C	PV-IQ393/IQ394	150**
PK-802/805	EPP-100C / EPP-100	PV-6000	EPP-101C	PV-IQ403/IQ404/IQ404A	150**
PK-903	EPP-100C / EPP-100	PV-6100	130C	PV-IQ405/IQ425/IQ434	150**
PK-956/957/958/959	EPP-100C / EPP-100	PV-6110	EPP-100C / EPP-100	PV-IQ475/IQ485	150**
PK-972	EPP-101C	PV-6500/6600	EPP-101C	PV-IQ493/IQ494/IQ495	150**
PK-973/975/976/980	EPP-100C / EPP-100	PV-8000/8100/8110	EPP-100C / EPP-100	PV-IQ503/IQ504/IQ505	150**
PRO-846	150**	PV-8440/8484/8485	EPP-100C / EPP-100	PV-IQ525/IQ575/IQ594	150**
PV-10/10B/10PX	150**	PV-8500/8600/8650	EPP-100C / EPP-100	PV-IQ604/IQ635	150**
PV-14/17/18/19	150**	PV-9000/9000A	EPP-100C / EPP-100	PV-L50/L59/L60	150**
PV-20/21/22	150**	PV-9600/9600A	EPP-100C / EPP-100	PV-L352	150**
PV-31/32	150**	PV-A206/A207/A216	150**	PV-L450K/L451/L452/L459K	150**
PV-40/41/42/43	150**	PV-A227/A286	150**	PV-L501/L550/L551/L552	150**
PV-50/53	150**	PV-A306/A307/A376/A386	150**	PV-L557/L558/L559	150**
PV-100/110**/120/122	110**	PV-D29	150**	PV-L560/L560K/L579	150**
PV-200	EPP-100C / EPP-100	PV-D101	BLI-172-*	PV-L580/L590	150**
PV-200D	112C	PV-D209/D209KJ	150**	PV-L600/L600C/L606/L647	150**
PV-210/220	EPP-100C / EPP-100	PV-D300/D300K/D301	150**	PV-L650/L650K/L651/L652	150**
PV-300/320/330	EPP-100C / EPP-100	PV-D308/D326	150**	PV-L657/L658/L659/L660	150**
PV-332/333	150**	PV-D406/D407/D414	150**	PV-L670/L678/L679/L679K	150**
PV-350	EPP-100C / EPP-100	PV-D426/D427	150**	PV-L680/L690	150**
PV-362	150**	PV-D476/D486/D496	150**	PV-L750/L750K/L751	150**
PV-400/420/425	EPP-100C / EPP-100	PV-D506/D507/D526	150**	PV-L757/L758/L759	150**
PV-430/460	EPP-100C / EPP-100	PV-D607	150**	PV-L779/L779K/L780	150**
PV-500/501/502/510	130C	PV-D700	BLI-162-*	PV-L850/L850K	150**
PV-515/520/530/535	EPP-100C / EPP-100	PV-D705	150**	PV-L857/L858	150**
PV-602/604	130C	PV-D710	BLI-162-*	PV-L859/L859K	150**
PV-606	150**	PV-D776	150**	PV-L958	150**
PV-610	130C	PV-D900	BLI-172-*	PV-M429	EPP-100C / EPP-100
PV-645/650/660	EPP-100C / EPP-100	PV-D1000	BLI-162-*	PV-S43/S53	150**
PV-700/704/710/720	130C	PV-DV10/DV51/DV52	BLI-172-*	PV-S62/S63/S64	150**
PV-750	EPP-100C / EPP-100	PV-DV100/DV100K/DV102	BLI-172-*	PV-S70	130C
PV-760/760A/760B	130C	PV-DV200/DV200K	BLI-172-*	PV-S140/S150/S160	110**
		PV-DV201/DV202	BLI-172-*	PV-S332	150**
		PV-DV400/DV400K	BLI-172-*	PV-S350	EPP-100C / EPP-100
		PV-DV401/DV402	BLI-172-*	PV-S362/S372	150**



**PANASONIC**

Equipment Model	Battery #
PV-S4420/S440	EPP-100C / EPP-100
PV-S445/S460	EPP-100C / EPP-100
PV-S540/S545/S550	EPP-100C / EPP-100
PV-S565/S575	EPP-100C / EPP-100
PV-S630	150**
PV-S770	130C
PV-S770A	150**
PV-SD4090/SD5000	NR
PV-VM202	BLI-172-*
VM-539	150**
VSB-0164	130C
WV-3400/4850	EPP-101C

**BATTERY MODEL TO BATTERY MODEL**

AG-BP15/BP15P	BLI-162-*
AG-BP20	130C
AG-B20P	EPP-100C / EPP-100
AG-B21P	130C
AG-BP25	EPP-152
BP-508	150**
BP-BP20P	130C
CGP-D110/D210/D320	BLI-172-*
CGR-B202/B403/B814	BLI-162-*
CGR-D08/D16/D28/D53A	BLI-172-*
CGR-D120/D220/D815	BLI-172-*
CGR-V610/V620	BLI-181-*
EPK1185	EPP-100C / EPP-100
HHR-V20A/V40A/V60A	150**
HHR-V214	150**
LCR-1812P/1812VB	EPP-102
LCS-2012APC/2012AV	EPP-100C / EPP-100
LCS-2012BVBN	112C
LCS-2012DVBN	130C
LCS-2012P/2012VBNC	EPP-101C
LCS-2312AVBNC	EPP-100C / EPP-100
LCS-D122BU	130C
LCT-1912AP	EPP-100C / EPP-100
NVA3	EPP-155-*
P-9AS/8U13	110**
PV-122D	110**
PV-214A/215A/611A	150**
PV-BP10/BP11/BP12	110**
PV-BP15/16/17/18/19	150**
PV-BP20M/BP22M	112C
PV-BP50	130C
PV-BP80/BP88	EPP-100C / EPP-100
PV-D200	BLI-172-*
PV-DBP5	BLI-162-*
PV-DBP8	BLI-172-*
PV-DBP9	BLI-172-*
PV-V213	150**

UP10V1.1AN/UP10VI.IN	110**
VSB-0011	EPP-100C / EPP-100
VSB-0016	130C
VSB-0190/0200	EPP-155-*
VW-VB30/VB31	EPP-100C / EPP-100
VW-VBC1E/VBC3	110**
VW-VBC4E/VBC5E	110**
VW-VBCE4E	110**
VW-VBD1/VBD1E/VBD2	BLI-162-*
VW-VBD21/VBD23	BLI-172-*
VW-VBD24/VBD25	BLI-172-*
VW-VBM2/VBM3	112C
VW-VBM7E/VBM10	EPP-100C / EPP-100
VW-VBM10E	EPP-155-*
VW-VBS1E/VBS2E	150**
VW-VBS20E	EPP-155-*

**PENTAX**

Equipment Model	Battery #
EI-2000	BLI-208
OPTIO 330, 430	BLI-203
PV800E	EPP-103-2
PVC1SA/11A/33	EPP-104
PVC55A/66A/67A	EPP-104
PVC77A/78A	EPP-124-2
PVC480E	109**
PVC800A	EPP-113
PVC840E	109**
PVC850A	EPP-113
PVC860E	109**
PVC880A/900A	EPP-113
PVC905A/909A	143**
PVEM100E	109**
PVR020	EPP-102
PVR1000A	EPP-104
PVR1100A	EPP-100C / EPP-100
PVR83030AV01	150**
V1	EPP-104

Battery Model	Battery #
D-Li1	BLI-208
D-Li2	BLI-203
PVBT1A/11/12	EPP-104
PVBT71/72	EPP-124-2
PVBT810/820	EPP-113
PVBT901/902	143**

**PHILCO**

Equipment Model	Battery #
V1715, V1720	EPP-102
V1728SL01, V1728TSL01	EPP-100C / EPP-100
100	
VC1726SL01, VC1727SL01	EPP-101C
VCR740SL01, VCR790SL01	112C

VCR800SL01	112C
VCR801AV01	EPP-100C / EPP-100
VCR802AV01	EPP-100C / EPP-100
VCR807AV01	EPP-100C / EPP-100
VCR809AV01	EPP-100C / EPP-100
VCR901AV01	EPP-100C / EPP-100
VKR110	130C

**BATTERY MODEL TO BATTERY MODEL**

SC2124	EPP-102
SC2154	EPP-101C
V80039BK01	EPP-100C / EPP-100
V80063BK01	112C

**PHILIPS**

Equipment Model	Battery #
CPJ-810/815	EPP-100C / EPP-100
CPK-816/832	130C
CPK-834/855	EPP-100C / EPP-100
CPK-910	110**
CPL-820/827/915	130C
CVJ-360	110**
CVL-345	EPP-100C / EPP-100
CVR-315/325	EPP-154-2
CVT-330/340	EPP-154-2
PRO 1	EPP-100C / EPP-100
VKR-2000	EPP-100C / EPP-100
VKR-6800/6810	112C
VKR-6820S	EPP-100C / EPP-100
VKR-6830/6835/6836	110**
VKR-6837/6838/6840	110**
VKR-6841/6842/6843	110**
VKR-6846	EPP-108
VKR-6850/6851/6855	EPP-100C / EPP-100
VKR-6865	110**
VKR-9000/9005/9300	110**

**BATTERY MODEL TO BATTERY MODEL**

22AV5112, 22AV5119	112C
22AV5125, 22AV5126	EPP-105
22AV5145, 22AV5166	110**
22AV5191	EPP-108
22AV5591	EPP-100C / EPP-100
AR8378BK01	EPP-100C / EPP-100
AR8390BK01	EPP-102
AR8395BK01	EPP-100C / EPP-100
SBC5212	110**
SBC5214	110**
SBC5215	EPP-100C / EPP-100
SC2154	EPP-101C
V80039BK01	EPP-100C / EPP-100
V80063BK01	112C
V80076BK01	110**
V80085BK01	110**
V80086BK01	EPP-100C / EPP-100

V80096BK01	130C
V80115BK01	150**
V80116BK01	150**
V80139BK01	EPP-151
V80146BK01	EPP-154-2
V80149BK01	EPP-154-2
VE550UE	EPP-101C

**PIONEER**

<b>Equipment Model</b>	<b>Battery #</b>
VEM-800	EPP-103-2
VM-50	EPP-105

**PROSCAN**

<b>Equipment Model</b>	<b>Battery #</b>
CC-HIT555/566/577	BLI-166-*
PRO 598/698H	BLI-166-*
PRO 898LH/998LH	BLI-166-*
PSC10	EPP-142
PSC15C	150**
PSC20HB	143**

**BATTERY MODEL TO BATTERY MODEL**

BB060	143**
HIT 555/566/577	BLI-166-*

**QUASAR**

<b>Equipment Model</b>	<b>Battery #</b>
PS-40/150	110**
VH-5300/5410	EPP-102
VH-5420/5430/5435	EPP-101C
VK-726TE	EPP-102
VM-10	112C
VM-11C	EPP-100C / EPP-100
VM-20AC/21AC/22AC	EPP-100C / EPP-100
VM-23AC/24AC/25AC	EPP-100C / EPP-100
VM-26AC/27AC/29	EPP-100C / EPP-100
VM-32/32AC/33/33AC	130C
VM-34/35/37	EPP-100C / EPP-100
VM-40AC	110**
VM-50	110**
VM-50AC	EPP-105
VM-51AC/52/52AC/53	110**
VM-100/110**	150**
VM-500/505/508	150**
VM-510/511/512/513	150**
VM-514/515/516/517/518	150**
VM--520/521/522/524/525	150**
VM-526	110**
VM-530/535/538/539	150**
VM-544/545/547/549	150**
VM-550/555	150**
VM-560/565/575	150**
VM-700/705/706	130C
VM-708/709	EPP-100C / EPP-100

VM-710/716/717/718	130C
VM-735/737/749	130C
VM-2100	EPP-100C / EPP-100
VM-D100/D101	150**
VM-L450/L457/L458/L459	150**
VP-2100	EPP-100C / EPP-100
VP-5420	EPP-101C
VP-5430	EPP-100C / EPP-100
VP-5435	EPP-101C
VP-5440/5441/5442	EPP-100C / EPP-100
VP-5450/5451/5452	EPP-100C / EPP-100
VP-5740/5741	EPP-100C / EPP-100
VP-5742/5744	EPP-100C / EPP-100
VP-5747/5748	EPP-100C / EPP-100
VP-5750/5751	EPP-100C / EPP-100
VP-5756/5757	EPP-100C / EPP-100
VV-9404	EPP-100C / EPP-100

**BATTERY MODEL TO BATTERY MODEL**

BP-500/508	150**
KT561SE	EPP-102
P-V213A/1B	150**
P-V214A/1B	150**
P-V215A/1B	150**
P-V611A/1B	150**
VE250	112C
VE255, VE256	110**
VE257	EPP-100C / EPP-100
VE258	130C
VE550UE	EPP-101C
VE551XE	EPP-100C / EPP-100
VSBS0011	EPP-100C / EPP-100

**RCA**

<b>Equipment Model</b>	<b>Battery #</b>
CC-009	EPP-102
CC-150	EPP-106
CC-174	150**
CC-175	EPP-106
CC-176/177/178/180	150**
CC-187/188/190	150**
CC-250/260/275	EPP-104
CC-280/285/286	EPP-124-2
CC-300	EPP-104
CC-305/310/311/320	EPP-124-2
CC-350	EPP-104
CC-360/390/391	EPP-124-2
CC-400/405/407/412	EPP-142S
CC-413/414/415/416/417	EPP-142S
CC-420/421/422/423/424	EPP-142S
CC-425	143**
CC-428/431/432/433	EPP-142S
CC-434/436/437/439	EPP-142S
CC-445	EPP-142S

CC-507/509/510/512/517	EPP-142S
CC-520/525	EPP-142
CC-540/542	EPP-142S
CC-543	EPP-142
CC-547	EPP-142S
CC-560	EPP-142
CC-600/604/612/614	150**
CC-615/616/617	150**
CC-620/621/631/632/633A	150**
CC-636/639	150**
CC-641/643/645/648	150**
CC-740/800/820	150**
CC-800	150**
CC-850	EPP-142S
CC-900D	BLI-160
CC-1000/1650	150**
CC-4251/4271	EPP-142S
CC-4352/4371	EPP-142S
CC-4391/4392/4393	EPP-142S
CC-6251/6262/6263	150**
CC-6271/6272/6291	150**
CC-6371/6372/6373/6374	150**
CC-6383/6384	150**
CC-6391/6392/6393/6394	150**
CC-8251	BLI-166-*
CC-9360/9370/9373	BLI-192-*
CC-9381/9390	BLI-176-*
CCD-FX210/FX230	109**
CCR-265/300/305	EPP-124-2
CLC-021	111
CLR-200	EPP-104
CMR-200/300	EPP-104
CPR-100/150	EPP-106
CPR-175	EPP-104
CPR-250/275	EPP-104
CPR-300/350	EPP-104
CPR-S350	EPP-104
CVR-475	EPP-154-2
QVC-F477/F479	EPP-154-2
PRO 8	143**
PRO 598	BLI-166-*
PRO 660	143**
PRO 698H	BLI-166-*
PRO 702C	150**
PRO 742	BLI-166-*
PRO 800/807/808	109**
PRO 810/815	143**
PRO 820/820A/825	143**
PRO 830/840	109**
PRO 842	143**
PRO 843	109**
PRO 844	143**
PRO 845	109**
PRO 846	143**

**RCA**

Equipment Model	Battery #
PRO 847	109**
PRO 850	143**
PRO 852/854	143**
PRO 860/865/867/870	143**
PRO 880/880HB	143**
PRO 881HB/883HB/884HB	143**
PRO 898LH	BLI-166*
PRO 930/932	143**
PRO 942/943/943S	143**
PRO 998LH	BLI-166*
PRO B712	164**
PRO EDIT	EPP-124-2
PRO V600	143**
PRO V712/V714	BNH-158-3.5
PRO V730/V741/V742	BLI-166*
PRO V801C	150**
PRO V949HB	143**
PRO V950HB	BLI-156*
PRO V2000D	BLI-156*
PSC10	143**
PSC15C	150**
PSC20HB	143**
VDP-150N	EPP-102
VJ & OLDER, VH	EPP-102
VJ & OLDER, VI	EPP-102
VJP-170	EPP-102
VTR-100	EPP-106

**BATTERY MODEL TO BATTERY MODEL**

149-722	EPP-102
AV-096	EPP-124-2
AV-8M3W	109**
AV-8MLED	150**
AV-8MM	109**
AV-8MSW	150**
AV-55	109**
AV-120	EPP-104
AV-158C	109**
AV-608/609	109**
AV-622	EPP-103-2
AV-650	110**
AV-800	143**
BB-060	143**
BB-44/45/50	BNH-158-3.5
BB-65L	BLI-166*
BB-75	BLI-156*
BB-90	BLI-156*
BB-120/150	143**
BB-700	150**
BC-40	BLI-160
BDC-40	BLI-160
BP-96FL/96FS	EPP-124-2

BV-060	143**
CB-060	EPP-104
CB-096FL	EPP-142
CB-096FS	EPP-142S
CB-120	EPP-104
CBC-060/120	EPP-106
CPS-01	EPP-102
EP-096FL/096FS	EPP-142S
FB-096FS	150**
FB-120/1260	150**
RV-013	EPP-102
VFP-170	EPP-102
VGP-170	EPP-102

**REALISTIC**

Equipment Model	Battery #
16-801	EPP-104
16-802/803/825	EPP-124-2
16-826	EPP-115
16-830	EPP-142S
16-851	EPP-106
16-852/853	109**
MODEL 100	EPP-104
MODEL 101	EPP-124-2
MODEL 102	EPP-142
MODEL 103	EPP-142S
MODEL 125	EPP-124-2
MODEL 126	EPP-115
MODEL 150	EPP-106
MODEL 151/152/153/154	109**
MODEL 155	150**
MODEL 157	143**

**BATTERY MODEL TO BATTERY MODEL**

16-804	EPP-142S
16-BP65	EPP-142S
23-183	EPP-104
23-184	109**
23-186	EPP-124-2
23-187	EPP-100C / EPP-100
BT-22RS	EPP-115
P16-BP63	EPP-124-2
P16-BT-22	EPP-115
T16-BP64	EPP-142
VM-BP21ARS	EPP-104
VM-BP61RS	EPP-106
VM-BP66RS	EPP-142S
VM-BP82	143**
VM-PB21ARS	EPP-104

**RICOH**

Equipment Model	Battery #
R-16/17/17C/18H	109**
R-66/67	109**
R-86S	109**

R-87H	BLI-153*
R-88/88H	109**
R-105/108H	109**
R-200	109**
R-250	EPP-103-2
R-260	109**
R-500/600	EPP-103-2
R-600S/610/612/615	109**
R-620/630/680	109**
R-800/808H/810	109**
R-830/831/850	109**
R-860/861	109**
TF-200	109**

**BATTERY MODEL TO BATTERY MODEL**

DB-20	BLI-183
DB-30	BLI-174
DRP-2	109**
NP-22	EPP-103-2
NP-55/77/99	109**
NP-500	153

**SABA**

Equipment Model	Battery #
CVK-2600	EPP-105
VM-6800/6930/6940CD	110**
VM-6990CD/6995CD	110**
VMK-6700	EPP-105

**SAMSUNG**

Equipment Model	Battery #
SC-A12/14	109**
SC-A20/A23/A25	109**
SC-A30/A33/A35	109**
SC-A80/A85	109**
SC-D55/60/67/70/75/77	BLI-200*
SC-D130/190	BLI-200*
SC-F30/32/34/35	130C
SC-F500/501	EPP-104
SC-F700/702	EPP-152
SC-F703/704	130C
SC-F710/712	EPP-152
SC-F754/755/756/765	130C
SC-H985/H996	109**
SC-K60/K70/K75/K80/K85	109**
SC-L100/L300	109**
SC-L320	BLI-195*
SC-L330/350	109**
SC-L520/L530/L540/L550	BLI-195*
SC-L600/L610/L630/L650	BLI-195*
SC-L800	109**
SC-M51/M52/M53	BLI-195*
SC-W61/W62	1950
SC-X704	130C
SC-X800X/803/X804/X854	109**

**SAMSUNG**

Equipment Model	Battery #
SC-X904X/915/X953	109**
SV-C3/C8	EPP-103-2
SV-C9	EPP-105
SV-E27	EPP-100C / EPP-100
SV-H30/H33	109**
VC-E27N/H15N/H815	109**
VP-A20/A22	109**
VP-A30/A31/A33/A34	109**
VP-A50/A55/A57	109**
VP-A800/A850	109**
VP-D55	BLI-200-*
VP-D70/D73/D75/D76/D77	BLI-200-*
VP-L100	109**
VP-L150	150**
VP-L300/L330/L350	109**
VP-L980	109**

**BATTERY MODEL TO BATTERY MODEL**

AC-43-1001R	109**
CAB-05/06	EPP-152
FB-1260	150**
NB-E60A/E70A	109**
NC-120N	109**
SB-L70/L110	BLI-200-*
SB-L110A	BLI-195-*
SB-L160	BLI-195-*
SB-L220	BLI-200-*
SB-L320/L480	BLI-195-*
SC-W62	BLI-195-*
SV-LB5	EPP-152
SV-LB6	130C
SV-NB3/NB4	EPP-104

**SANYO**

Equipment Model	Battery #
VC-8/10	EPP-103-2
VCR-88	EPP-103-2
VEM-8/800	EPP-103-2
VEM-D3	EPP-103-2
VEM-H100	109**
VEM-S1/S2	109**
VISION 8	EPP-103-2
VM-8/10	EPP-103-2
VM-66	109**
VM-800P	EPP-103-2
VM-D1	109**
VM-D1P	EPP-103-2
VM-D3	109**
VM-D5/D5P/D6/D6P/D8P	109**
VM-D66/D66P	109**
VM-ES77/ES99	109**
VM-H100P	109**

VM-P5P	109**
VM-PS12	109**
VM-RZ1/RZ1A	109**
VME-S88/S88P	109**
VRC-200	112C
VRC-7300	114**
VTC-5800	114**

**BATTERY MODEL TO BATTERY MODEL**

BNP-22	EPP-103-2
NP-1/1A	114**

**SEARS**

Equipment Model	Battery #
934	EPP-142S
5368, 5369, 5370	EPP-100C / EPP-100
5372, 5374, 5376, 5377	EPP-104
5379	EPP-124-2
5524, 5526	EPP-142S
53601, 53612	150**
53661, 53662, 53671, 53672	130C
53683	EPP-100C / EPP-100
53684, 53685	130C
53691, 53703	EPP-100C / EPP-100
53704, 53705, 53706	109**
53708, 53709	109**
53721	EPP-104
53722, 53725	143**
53729, 53730, 53732	EPP-104
53733, 53734, 53735	EPP-142S
53740, 53741, 53742	EPP-104
53743, 53744	EPP-104
53745	EPP-124-2
53746	EPP-142S
53749, 53761	EPP-104
53762, 53763, 53764	EPP-142S
53781, 53782	EPP-142
53783	EPP-142S
53790	EPP-124-2
53791	EPP-104
53792, 53793	EPP-142S
53794	EPP-124-2
53795, 53796, 53801	EPP-142S
53832	EPP-104
53833	EPP-124-2
53834, 53843	EPP-154-2
53851	109**
53882	EPP-124-2
53884	109**
55514	150**
55534	143**
55624, 55625, 55634	150**
55635	109**
55814, 55824, 55844	109**

55914	EPP-154-2
55428	164**
58428, 58457, 58458	164**
58537, 58538	EPP-142S
58628, 58657, 58658	150**
58667, 58668	150**
58827	109**
58828	153
58847	109**
58848	153
58857	109**
58878	153
58917, 58937, 58968	150**

Battery Model	Battery #
5399	EPP-100C / EPP-100
52061	109**
52074	150**
53834	EPP-142S
53981	EPP-124-2
53982	EPP-142
53983	EPP-142S
53988	109**
53991	130C
53994, 53995	EPP-104
VMBP61AS	EPP-124-2

**SHARP**

Equipment Model	Battery #
AC-2000	EPP-105
AD-M20BT	BLI-187
AD-MS10BT	BLI-191
AD-S30BT/S31BT	BLI-190
AD-T50BT/T51BT	BLI-190
MD-MS702MK	BLI-190
MD-MS722	BLI-190
MD-MT702S	BLI-190
MD-MT821GL	BLI-190
MS-S10BK	BLI-187
QC-50	EPP-105
SLIMCAM	EPP-146-3.5
VC-20/250	EPP-105
VC-C10U	112C
VC-C20UA	EPP-115
VC-C50/C50UA/C500A	EPP-105
VL-50/60/62U/63U/64U	EPP-146-3.5
VL-73/74UA	EPP-108
VL-100UP	109**
VL-780H/780S/780X	110**
VL-A10U	164**
VL-A110U/111U/150U	164**
VL-A160U/260U	164**
VL-AD260U	BLI-176-*
VL-AH30U/AH50U/AH60U	164**

**SHARP**

Equipment Model	Battery #
VL-AH130U/AH131U	164**
VL-AH150U/AH151U	164**
VL-AH160U/AH161U	164**
VL-C2	EPP-108
VL-C65	EPP-108
VL-C72UA	110**
VL-C73U/C74UA/C77UA	EPP-108
VL-C80	EPP-104
VL-C650U/C670	EPP-108
VL-C690HC/690S/C690X	110**
VL-C750U/C770/C780	EPP-108
VL-C855UA/C860	EPP-108
VL-C6100	EPP-108
VL-C7500/7950S	110**
VL-D5000U	BLI-156-*
VL-DC1U	BLI-156-*
VL-DX10U	BLI-167
VL-E7E/E8E	109**
VL-E30U/E32/E32U	109**
VL-E33/E34	BNH-158-3.5
VL-E35U/E36	109**
VL-E37/E37U/E39/E39U	BNH-158-3.5
VL-E40U/E42	109**
VL-E43/E46/E47/E49	BNH-158-3.5
VL-E60/E62DU	164**
VL-E65DU/E66/E66U	164**
VL-E77/E77U/E78/E78U/E79	164**
VL-E89/E96/E98	164**
VL-E42U	BNH-158-3.5
VL-E450	BLI-156-*
VL-E500U	BNH-158-3.5
VL-E550	BLI-156-*
VL-E600/E610U/E620/E620U	164**
VL-E630U/E650	164**
VL-E650U	BNH-164-2.5
VL-E660U/E665U	164**
VL-E680U/E685U	164**
VL-E700/E700U/E720/E720U	164**
VL-E750/E750U	164**
VL-E760/E760U/E765/E765U	164**
VL-E780U/E785U	164**
VL-E850	164**
VL-E980U	164**
VL-EDX10	BLI-167
VL-FD1/FD1U	BLI-196
VL-400	109**
VL-H9E	109**
VL-H80DU/H95	164**
VL-H410/H410U/H420	BLI-156-*
VL-H420	164**

VL-H450/H450U	BLI-156-*
VL-H500/H520/H550	BLI-156-*
VL-H700/H800	164**
VL-H850/H850U	164**
VL-H860/H860U	BLI-176-*
VL-H870/H870U/H875/H875U	BLI-176-*
VL-H880/H890/H890U/H950U	BLI-176-*
VL-HL100U	109**
VL-L10	EPP-115
VL-L30U	EPP-146-3.5
VL-L40U	109**
VL-L50	EPP-146-3.5
VL-L60U/L62U/L63U/L65U	EPP-146-3.5
VL-L72U	EPP-146-3.5
VL-L80UA	EPP-115
VL-L94U/L95U	EPP-146-3.5
VL-L133	BNH-158-3.5
VL-L150U/L170U/L175	EPP-115
VL-L210U	EPP-115
VL-L240U	EPP-146-3.5
VL-L250U	EPP-115
VL-L270/L280/L285U	EPP-115
VL-L290	EPP-146-3.5
VL-L310U/L330U	EPP-115
VL-L340U/L380U/L390U	EPP-146-3.5
VL-L490	EPP-146-3.5
VL-L510U	EPP-115
VL-L630/L634	EPP-146-3.5
VL-L4100U/L4300U	EPP-115
VL-LXXU	EPP-146-3.5
VL-M6GY/M6SL/M6U	109**
VL-MS7SL	109**
VL-MX6/MX7GY/MX7U	109**
VL-MX70	109**
VL-N1U	109**
VL-NZ8U/NZ10U	BLI-205
VL-NZ50U	BLI-205
VL-NZ100U/NZ150U	BLI-205
VL-PD1U	BLI-179
VL-PD3U	BLI-177
VL-RD1U	BLI-178
VL-S1/S1U/S5/S5U	164**
VL-S860	EPP-108
VL-SD20U	BLI-176-*
VL-SE10/SE15/SE20/SE20U	164**
VL-SW50U	164**
VL-WD200U	BLI-176-*
VL-WD250U/WD255U	BLI-176-*
VL-WD450U/WD650U	BLI-176-*
VLE-DX10	BLI-167
WD-250U/450U/650U	164**

**BATTERY MODEL TO BATTERY MODEL**

AD-S30BT/S31BT	BLI-207
----------------	---------

AD-T50BT/T51BT	BLI-207
BT-5C	EPP-108
BT-20	112C
BT-21/22	EPP-115
BT-30N	EPP-146-3.5
BT-51/52	EPP-105
BT-70	109**
BT-71/72	110**
BT-73	EPP-108
BT-75/76	110**
BT-77	109**
BT-80/80BKP	109**
BT-BH70U/BH85U	109**
BT-C4	EPP-108
BT-H11U	BNH-158-3.5
BT-H21U/H22U/H32U/H42U	164**
BT-L1U/L2U	BLI-156-*
BT-L1U/L2U/L11U/L12U	BLI-156-*
BT-L31U	BLI-167
BT-L43U	BLI-179
BT-L44U	BLI-178
BT-L221	BLI-177
BT-L223U	BLI-196
BT-L225U	BLI-205
BT-L241/L241U/L441/L441U	BLI-176-*
BT-L445U	BLI-205
BT-N1U/N11U	BNH-158-3.5
VB-BL5	BLI-156-*
VR-BL71	BLI-156-*
VR-BL72	BLI-167
VR-BL74	BLI-196
VR-BL75/BL81	BLI-156-*
VR-MS1U	BLI-167

**SONY**

Equipment Model	Battery #
BETA-CAM	114**
CCD-20061	109**
CCD-CR1	BLI-173-*
CCD-F30/F33/F34/F35	109**
CCD-F36/F38	109**
CCD-F40/F45/F46	109**
CCD-F50/F55/F56	109**
CCD-F70/F77	109**
CCD-F150	109**
CCD-F201/F250/F280	109**
CCD-F301/F302/F330/F335	109**
CCD-F340/F350/F355E	109**
CCD-F370/F375E/F380	109**
CCD-F401/F402/F450/F455E	109**
CCD-F500/F501/F550/F555E	109**
CCD-FX3	109**
CCD-FX228/FX230/FX280E	109**

<b>SONY</b>					
<b>Equipment Model</b>	<b>Battery #</b>				
CCD-FX310/FX311/FX330	109**	CCD-TR805E/TR814	109**	CCD-V600/V700E/V701	109**
CCD-FX400/FX410/FX420	109**	CCD-TR818	BLI-153-*	CCD-V800/V800E	109**
CCD-FX500/FX510/FX511	109**	CCD-TR880E	109**	CCD-V801/V801E	109**
CCD-FX520/FX530	109**	CCD-TR900	109**	CCD-V900	109**
CCD-FX620/FX630	109**	CCD-TR910	BLI-153-*	CCD-V5000/V5000E	109**
CCD-FX710/FX730V	109**	CCD-TR916	109**	CCD-VX3	109**
CCD-FX810/FX830VE	109**	CCD-TR917/TR930/TR940	BLI-153-*	DCM-M1	153-1.5C*
CCD-G100ST	109**	CCD-TR3000	BLI-153-*	DCR-IP5/IP7	209
CCD-GV200/GV500	109**	CCD-TR3000E	109**	DCR-PC1/PC2/PC3/PC5	173C
CCD-M7U	109**	CCD-TR3300	BLI-153-*	DCR-PC7	BLI-163-1.5C
CCD-M8E/M8EK/M8U	EPP-103-2	CCD-TR3300	109**	DCR-PC9	180C
CCD-M9U/M10	EPP-103-2	CCD-TRV11/TRV12	109**	DCR-PC10	BLI-163-1.5C
CCD-SC5	BLI-153-*	CCD-TRV15/TRV16	BLI-153-*	DCR-PC100/PC110/PC120BT	180C
CCD-SC6E/SC8E	109**	CCD-TRV19/TRV21/TRV22	109**	DCR-SC100	153-1.5C
CCD-SP5/SP5G/SP5Y	109**	CCD-TRV20	180C	DCR-TR7000	BLI-153-*
CCD-SP7/SP9	109**	CCD-TRV25	BLI-153-*	DCR-TRV6	180C
CCD-TR1/TR3	BLI-153-*	CCD-TRV29	109**	DCR-TRV7	BLI-153-*
CCD-TR4/TR5/TR6	109**	CCD-TRV30	180C	DCR-TRV8	180C
CCD-TR7/TR8/TR9	109**	CCD-TRV32	109**	DCR-TRV9	BLI-153-*
CCD-TR21/TR23	109**	CCD-TRV35/TRV36/TRV37	BLI-153-*	DCR-TRV10/TRV11	180C
CCD-TR30/TR31/TR33/TR36	109**	CCD-TRV41/TRV43/TRV46	BLI-153-*	DCR-TRV17/TRV20/TRV30	180C
CCD-TR40/TR45/TR44	109**	CCD-TRV51	BLI-153-*	DCR-TRV103/TRV110	BLI-153-*
CCD-TR50/TR50E	109**	CCD-TRV52	109**	DCR-TRV120/TRV130	BLI-153-*
CCD-TR54/TR55/TR56	109**	CCD-TRV57/TRV58	BLI-153-*	DCR-TRV140	180C
CCD-TR57	BLI-153-*	CCD-TRV62/TRV65	BLI-153-*	DCR-TRV230/TRV240	180C
CCD-TR61/TR64/TR65/TR66	109**	CCD-TRV66/TRV67/TRV68	BLI-153-*	DCR-TRV310/TRV315	BLI-153-*
CCD-TR67	BLI-153-*	CCD-TRV72/TRV75/TRV78E	BLI-153-*	DCR-TRV320	BLI-153-*
CCD-TR70/TR74	109**	CCD-TRV81/TRV82	BLI-153-*	DCR-TRV330/TRV340	180C
CCD-TR75/TR75BR	109**	CCD-TRV85/TRV87/TRV88	BLI-153-*	DCR-TRV510	BLI-153-*
CCD-TR81/TR82/TR83/TR86	109**	CCD-TRV93/TRV95	BLI-153-*	DCR-TRV520/TRV525	BLI-153-*
CCD-TR87	BLI-153-*	CCD-TRV98/TRV99	BLI-153-*	DCR-TRV530	180C
CCD-TR91/TR93/TR94/TR96	109**	CCD-TRV107/TRB108	180C	DCR-TRV720	BLI-153-*
CCD-TRT97	BLI-153-*	CCD-TRV112/TRV119	109**	DCR-TRV730/TRV740	180C
CCD-TR99	109**	CCD-TRV212	109**	DCR-TRV820	BLI-153-*
CCD-TR100/TR101C	109**	CCD-TRV215/TRV315	BLI-153-*	DCR-TRV830/TRV840	180C
CCD-TR105/TR105E	109**	CCD-TRV308/TRV408	180C	DCR-TRV900	BLI-153-*
CCD-TR112/TR150	109**	CCD-TRV512	109**	DCR-VX700	BLI-153-*
CCD-TR200	BLI-153-**	CCD-TRV517	BLI-153-*	DCR-VX1000/VX2000	BLI-153-*
CCD-TR205	109**	CCD-TRV608	180C	DSC-CD250/CD400	153-1.5C*
CCD-TR215	BLI-153-*	CCD-TRV615	BLI-153-*	DSC-D700/D770	BLI-153-*
CCD-TR300	BLI-153-*	CCD-TRV715/TRV716	BLI-153-*	DSC-F1	BLI-185
CCD-TR380/TR385E	109**	CCD-TRV720	BLI-153-*	DSC-F55	173C
CCD-TR400	109**	CCD-TRV815	BLI-153-*	DSC-F505/F505V	173C*
CCD-TR416	BLI-153-*	CCD-TRV911	109**	DSC-FV505	173C*
CCD-TR500	BLI-153-*	CCD-V1/V3	EPP-103-2	DSC-F707	180C*
CCD-TR505K	109**	CCD-V4	109**	DSC-P3/P5	206*
CCD-TR516	BLI-153-*	CCD-V5/V7F	EPP-103-2	DSC-P20/P30/50/70	173C*
CCD-TR600/TR614	109**	CCD-V8AFU	EPP-103-2	DSC-S30/S50/S70/S75/S85	180C*
CCD-TR700/TR705/TR705E	109**	CCD-V9/V11/V22	109**	DSP-P1	173C*
CCD-TR714	109**	CCD-V30/V35/V50E	EPP-103-2	DSR-1	114**
		CCD-V88/V90/V95E/V99	109**	DSR-130/130P	114**
		CCD-V100	EPP-103-2	DSR-200/300	BLI-153-*
		CCD-V101	109**	DSR-PD1	BLI-163-1.5C
		CCD-V110	EPP-103-2	DSR-PD100A	BLI-153-*
		CCD-V200/V220	EPP-103-2		

**SONY**

Equipment Model	Battery #
DXC-3000	114**
DXC-D30	114**
DXC-M2A	114**
DXC-M3A	114**
ED-CAM	114**
EDC-50	114**
EV-P10	EPP-103-2
EVC-8	EPP-103-2
EVC-X7	109**
EVO-9100	109**
EVW-300L	114**
GV-8/9/9E	109**
GV-100/300/500	109**
GV-A500/A500E	BLI-153-*
GV-U5/U5K	109**
KV-5300	114**
MPK-M8	EPP-103-2
MVC-5000	109**
MVC-CD200/CD300	180C*
MVC-CD1000	153-1.5C*
MVC-FD5/FD7	153-1.5C*
MVC-FD51	153-1.5C*
MVC-FD71/FD73/FD75	153-1.5C*
MVC-FD81/FD83	153-1.5C*
MVC-FD85/FD87/FD88	153-1.5C*
MVC-FD90/FD91/FD92	153-1.5C*
MVC-FD95/FD97	153-1.5C*
MVC-FD100/FD200	153-1.5C*
PAK-7	EPP-103-2
PLM-100	BLI-153-*
PVV-3	114**
PVW-637	114**
SL-2000/2005	114**
SLF-1	114**
SLO-340	114**
TR-670E	109**
TR-V70E	109**
VO-6800	114**
WATCHMAN	109**
XV-M30/MH30	109**

**BATTERY MODEL TO BATTERY MODEL**

EB-55	109**
LIP-8	BLI-184
LIP-10	BLI-185
LIP-12/12H	BLI-186
NP-1/1A/1B/1H/1SB	114**

NP-22/22H	EPP-103-2
NP-33	109**
NP-55/55H	109**
NP-60D/66/66H/68	109**
NP-77/77H	109**
NP-80/80D/88	109**
NP-90/98/98D/99	109**
NP-500/510/520	BLI-153-*
NP-720/730	BLI-153-*
NP-F10/F20/F30	BLI-173-*
NP-F100/F200/F300	BLI-163-1.5C
NP-F330	BLI-153-*
NP-F500H/F530/F550	BLI-153-*
NP-F730/F730H	153-3.2C
NP-F750	BLI-153-*
NP-F930/F950/F960	BLI-153-*
NP-FC10	206
NP-FF50/FF70	209
NP-FM30/FM50/FM70	180C
NP-FM90/FM91	180C
NP-FS11/FS21/FS31	BLI-173-*
NPA-55	EPP-103-2
NPE-BP36	EPP-103-2

**SYLVANIA**

Equipment Model	Battery #
VC45(12-20) SL Series	EPP-100C / EPP-100
VC4514SL	EPP-100C / EPP-100
VC4515	EPP-102
VC4520	EPP-100C / EPP-100
VC4526	EPP-100C / EPP-100
VC4530	EPP-100C / EPP-100
VC4530BK01	EPP-101C
VC4545	EPP-100C / EPP-100
VC4546	EPP-100C / EPP-100
VCC140SL01	EPP-112C
VCC145	110**
VCC150	EPP-112C
VCC151 / 151AV01	EPP-100C / EPP-100
VCC152	EPP-100C / EPP-100
VCC155	110**
VCC157 / VCC159	EPP-100C / EPP-100
VCC161	EPP-100C / EPP-100
VCC165	110**
VKC210 / 221 / 242	EPP-130C / EPP-130
VLC218 / VLC225	EPP-130C / EPP-130
VMC226	EPP-130C / EPP-130
VMC260	150**

**BATTERY MODEL TO BATTERY MODEL**

AR8378BK01	EPP-100C / EPP-100
AR8390BK01	EPP-102
AR8395BK01	EPP-100C / EPP-100
SC2124	EPP-102
SC2154	EPP-101C
V80039BK01	EPP-100C / EPP-100
V80076BK01 / 85BK01	110**
V80086BK01	EPP-100C / EPP-100
V80096BK01	EPP-130C / EPP-130
V80115BK01, V80016BK01	150**
VE550UE	EPP-101C
VSBS0016	EPP-130C / EPP-130

**TOSHIBA**

Equipment Model	Battery #
3D-CAM	110**
151	EPP-100C / EPP-100
AI-33AFK/420P	110**
IK1850	EPP-102
IK-2200	EPP-105
PDR-M3	BLI-174
PDR-M4/M5	BLI-183
PDR-M60/M70	BLI-183
SK-3D7	110**
SK-40/50P	110**
SK-57/60	EPP-105
SK-70/80	110**
SK-F100/F200	EPP-141
SK-S80U/S90U	110**
V-8030T/9035	114**

**BATTERY MODEL TO BATTERY MODEL**

NP-100	BLI-174
PDR-BT1/BT1A/BT2	BLI-183
TBP-7U	EPP-105
TBP-8U/9U	110**
TBP-100	114**
TBP-120	EPP-105
TBP-F1/F2	EPP-141

**VIVITAR**

Equipment Model	Battery #
MAGIC 8	EPP-103-2
MAGIC VHS	EPP-104
VM-8350	EPP-103-2
VM-9350	EPP-104

**BATTERY MODEL TO BATTERY MODEL**

NP-22/22H	EPP-103-2
-----------	-----------

\*Available in varying amp hour output. See next page for available models.

\*\*Batteries available in Ni-Cad, Lead Acid or Nickel Metal Hydride & several different amp hour outputs. See next page to cross reference your brand.

Order#	Model#	Volts	Output	Chemistry*	Reg.	Our Price
EPP-100C	PANASONIC PV-BP80/88	12	2.3Ah	L	\$69.95	\$55.95
EPP-101C	PANASONIC LCS-2012VBNC	12	2.3Ah	L	\$69.95	\$55.95
EPP-102	PANASONIC LCS-1812	12	2.3Ah	L	\$74.95	\$59.95
EPP-103-2	SONY NP-22H HIGH OUTPUT	6	2.0Ah	N	\$69.95	\$55.95
EPP-104	RCA CB-120	12	1.5Ah	N	\$84.95	\$67.95
EPP-105	JVC NB-P7U	9.6	1.5Ah	N	\$69.95	\$55.95
EPP-106	HITACHI VMP-51, 52	12	1.5Ah	N	\$89.95	\$71.95
EPP-107	OLYMPUS VFBP-81	7.2	1.2Ah	N	\$64.95	\$51.95
EPP-107-2	OLYMPUS 8mm 2HR	7.2	1.5Ah	N	\$84.95	\$67.95
EPP-108	SHARP VL-C73UA	9.6	1.2Ah	N	\$89.95	\$71.95
EPP-109-1.5	SONY NP-66	6	1.5Ah	N	\$59.95	\$47.95
EPP-109-2.4	SONY NP-77H	6	2.4Ah	N	\$89.95	\$71.95
BNH-109-2.1	SONY NP-66, 77, 98	6	2.1Ah	NMH	\$79.95	\$63.95
BNH-109-3	SONY NP-66, 77, 98	6	3.0Ah	NMH	\$89.95	\$71.95
BNH-109-4	SONY NP-66, 77, 98	6	4.0Ah	NMH	\$99.95	\$79.95
EPP-110	JVC GR-C9, 11 (GRIP TYPE)	9.6	1.2Ah	N	\$54.95	\$43.95
BNH-110-2	JVC BN-V7GV (GRIP TYPE)	9.6	2.0Ah	NMH	\$84.95	\$67.95
EPP-112C	PANASONIC PV-BP20M	12	2.0Ah	L	\$84.95	\$67.95
EPP-113	MINOLTA/PENTAX 8mm	7.2	1.5Ah	N	\$74.95	\$59.95
EPP-114	SONY/SANYO NP-1	12	1.8Ah	N	\$139.95	\$111.95
EPP-114-2.3	SONY/SANYO NP-15B	13.2	2.3Ah	N	\$159.95	\$127.95
BNH-114-4	SONY/SANYO NP-1	12	4.0Ah	NMH	\$189.95	\$151.95
EPP-115	SHARP BT-21, 22	12	2.0Ah	L	\$89.95	\$71.95
EPP-116	CANON BP-E22	6	1.7Ah	N	\$64.95	\$51.95
EPP-118-1.5	CANON BP-E722	6	1.5Ah	N	\$54.95	\$43.95
BNH-118-2.1	CANON BP-E722	6	2.1Ah	NMH	\$79.95	\$63.95
BNH-118-3	CANON BP-E722	6	3.0Ah	NMH	\$89.95	\$71.95
BNH-118-4	CANON BP-E722	6	4.0Ah	NMH	\$99.95	\$79.95
EPP-124-2	HITACHI VMBP63A/RCA BP-96FL	9.6	2.0Ah	N	\$99.95	\$79.95
EPP-128	MINOLTA BP-3301	9.6	1.2Ah	N	\$89.95	\$71.95
EPP-130C	PANASONIC PV-BP50	12	2.0Ah	L	\$69.95	\$55.95
EPP-132	CANON BP-E718	6	1.8Ah	N	\$89.95	\$71.95
EPP-141	TOSHIBA TBP-F1	12	2.0Ah	N	\$119.95	\$95.95
EPP-142	RCA CB-096 FS/MINOLTA VBP-160	10	2.0Ah	L	\$99.95	\$79.95
EPP-142S(Short)	RCA EP-096FL/MINOLTA VBP-166	10	2.0Ah	L	\$99.95	\$79.95
EPP-143-1.5	RCA BB-060/HITACHI VM-BP82	6	1.5Ah	N	\$64.95	\$51.95
BNH-143-2.1	RCA BB-060/HITACHI VM-BP82	6	2.1Ah	NMH	\$79.95	\$63.95
BNH-143-3	RCA BB-120/HITACHI VM-BP83	6	3.0Ah	NMH	\$89.95	\$71.95
BNH-143-4	RCA BB-120/HITACHI VM-BP83	6	4.0Ah	NMH	\$99.95	\$79.95
EPP-145-1.4	HITACHI TWIST & SHOOT	6	1.4Ah	N	\$89.95	\$71.95
EPP-146-3.5	SHARP BT-30N	6	3.5Ah	L	\$89.95	\$71.95
EPP-150-1.5	PANASONIC PV-BP15, 17	6	1.5Ah	N	\$64.95	\$51.95
BNH-150-2.1	PANASONIC PV-BP15	6	2.1Ah	NMH	\$79.95	\$63.95
BNH-150-3	PANASONIC PV-BP15, 17	6	3.0Ah	NMH	\$89.95	\$71.95
BNH-150-4	PANASONIC PV-BP15, 17	6	4.0Ah	NMH	\$99.95	\$79.95
EPP-151	MAGNAVOX V801398K01	6	1.2Ah	N	\$69.95	\$55.95
EPP-152	SAMSUNG SV-LB5/GE 1CVA190	12	2.0Ah	L	\$89.95	\$71.95
BLI-153-1.5C	SONY NP-F330, F550, FITS MAVICA	7.2	1.6Ah	LI	\$99.95	\$79.95
BLI-153-3C	SONY NP-F750	7.2	3.0Ah	LI	\$149.95	\$119.95
BLI-153-3.2C	SONY NP-F730 (INTERNAL FIT)	7.2	3.2Ah	LI	\$169.95	\$135.95
BLI-153-4.8C	SONY NP-F950	7.2	4.8Ah	LI	\$189.95	\$151.95
EPP-154-2	GOLDSTAR GVC-A425, C425	9.6	2.0Ah	N	\$99.95	\$79.95
EPP-155	PANASONIC VV-VBS10E, NV-CSI	4.8	1.2Ah	N	\$54.95	\$43.95
EPP-155-2.4	PANASONIC VV-VBS10E, NV-CSI	4.8	2.4Ah	N	\$89.95	\$71.95
BLI-156-2.7	SHARP VL-H410U, BT-L1, L2U	3.6	2.7Ah	LI	\$119.95	\$95.95
BLI-156-4.1	SHARP VL-H410U, BT-L11, L12U	3.6	4.1Ah	LI	\$159.95	\$127.95
BNH-158-3.5	SHARP BT-H11U	3.6	3.5Ah	NMH	\$89.95	\$71.95
EPP-159-1.5	UNIVERSAL SONY/PANASONIC	6	1.5Ah	N	\$59.95	\$47.95
BNH-159-2.1	UNIVERSAL SONY/PANASONIC	6	2.1Ah	NMH	\$79.95	\$63.95
BNH-159-4	UNIVERSAL SONY/PANASONIC	6	4.0Ah	NMH	\$99.95	\$79.95
BLI-160	JVC BN-V712U, RCA BDC-40	3.6	1.4Ah	LI	\$79.95	\$63.95
BLI-161	CANON BP-911,914,915	7.2	1.5Ah	LI	\$99.95	\$79.95
BLI-161-2.9	CANON BP-924,927	7.2	2.9Ah	LI	\$159.95	\$127.95
BLI-161-4.4	CANON BP-941,945	7.2	4.4Ah	LI	\$199.95	\$159.95
BLI-162	PANASONIC AG-BP15 JVC BN-V812U, 814U	7.2	1.4Ah	LI	\$99.95	\$79.95
BLI-162-3	EXTENDED PLAY EXTERNAL	7.2	3.0Ah	LI	\$139.95	\$111.95
BLI-163-1.5C	SONY NP-F200	7.2	1.5Ah	LI	\$199.95	\$159.95
EPP-164-1.7	SHARP BT-H21U	3.6	1.7Ah	N	\$49.95	\$39.95
BNH-164-2.5	SHARP BT-H21U, BT-H22U	3.6	2.5Ah	NMH	\$99.95	\$79.95
BNH-164-5.4	SHARP BT-H32U	3.6	5.4Ah	NMH	\$159.95	\$127.95
BLI-166	RCA, PROSCAN, HITACHI VM-BPL13	7.2	1.4Ah	LI	\$89.95	\$71.95
BLI-166-2.8	RCA, PROSCAN, HITACHI VM-BPL27A	7.2	2.8Ah	LI	\$149.95	\$119.95
BLI-167	SHARP BT-L31U	3.6	2.8Ah	LI	\$109.95	\$87.95
BLI-168	JVC BN-V907U	7.2	750mAh	LI	\$114.95	\$91.95



Order#	Model#	Volts	Output	Chemistry*	Reg.	Our Price
BLI-169	CANON BP-608 FOR ZR DIGITAL	7.2	750mAh	LI	\$89.95	\$71.95
BLI-169-1.7	CANON BP-617 FOR ELURA DIGITAL	7.2	1.7Ah	LI	\$114.95	\$91.95
BLI-170	JVC BN-V607	7.2	800mAh	LI	\$99.95	\$79.95
BLI-170-1.6	JVC BN-V615	7.2	1.6Ah	LI	\$139.95	\$111.95
BLI-172	PANASONIC PV BP8, CGR-D120	7.2	800mAh	LI	\$99.95	\$79.95
BLI-172-1.6	PANASONIC CGP-D210, CGR-D220	7.2	1.6Ah	LI	129.95	\$103.95
BLI-172-2.8	PANASONIC CGR-320	7.2	2.8Ah	LI	\$149.95	\$119.95
BLI-173C	SONY NP-F10/11 "S" SIZE	3.6	1.1Ah	LI	\$99.95	\$79.95
BLI-173-2.3C	SONY NP-F20	3.6	2.3Ah	LI	\$139.95	\$111.95
BLI-174	FUJI NP-100	3.6	1350mAh	LI	\$114.95	\$91.95
BLI-175	JVC BN-V507U	7.2	700mAh	LI	\$99.95	\$79.95
BLI-175-1.4	JVC BN-V514U	7.2	1.4Ah	LI	\$139.95	\$111.95
BLI-176	SHARP BT-L241U	7.2	1.1Ah	LI	\$89.95	\$71.95
BLI-176-2.2	SHARP BT-L441U	7.2	2.2Ah	LI	\$149.95	\$119.95
BLI-177	SHARP BT-L221U	7.2	1.1Ah	LI	\$99.95	\$79.95
BLI-178	SHARP BT-L44U	7.2	1.2Ah	LI	\$139.95	\$111.95
BLI-179	SHARP BT-L43U	7.2	2.2Ah	LI	\$139.95	\$111.95
BLI-180C	SONY NP-FM50	7.2	1.2Ah	LI	\$99.95	\$79.95
BLI-180-2.5C	SONY NP-FM70	7.2	2.5Ah	LI	\$149.95	\$119.95
BLI-180-4C	SONY NP-FM90	7.2	4.0Ah	LI	\$189.95	\$151.95
BLI-181	PANASONIC CGR-V610	7.2	1.5Ah	LI	\$119.95	\$95.95
BLI-181-3	PANASONIC CGR-V620	7.2	3.0Ah	LI	\$149.95	\$119.95
BLI-182-1.5	JVC BN-V214U	7.2	1.5Ah	LI	\$99.95	\$79.95
BLI-183	FUJI NP-80	3.7	1.1Ah	LI	\$94.95	\$75.95
BLI-184	SONY LIP-8 DIGITAL MINI DISC	3.6	800mAh	LI	\$79.95	\$63.95
BLI-185	SONY LIP-10 DIGITAL MINI DISC	3.6	800mAh	LI	\$69.95	\$55.95
BLI-186	SONY LIP-12 DIGITAL MINI DISC	3.6	800mAh	LI	\$79.95	\$63.95
BLI-187	SHARP AD-M20BT DIGITAL MINI DISC	3.6	1.6Ah	LI	\$79.95	\$63.95
BLI-190	SHARP AD-S30BT,S31BT,T50BT,T51BT	3.6	800mAh	LI	\$79.95	\$63.95
BLI-191	SHARP AD-M510BT DIGITAL MINI DISC	3.6	1.6Ah	LI	\$79.95	\$63.95
BLI-192	JVC BN-V408	7.2	850mAh	LI	\$74.95	\$59.95
BLI-192-1.6	JVC BN-V416	7.2	1.7Ah	LI	\$99.95	\$79.95
BLI-192-2.8	JVC BN-V428	7.2	2.4Ah	LI	\$129.95	\$103.95
BLI-193	CANON BP-511	7.2	1.2Ah	LI	\$89.95	\$71.95
BLI-193-2.4	CANON BP-522	7.2	2.4Ah	LI	\$149.95	\$119.95
BLI-193-3.8	CANON BP-535	7.4	3.8Ah	LI	\$149.95	\$119.95
BNH-194	CANON NB-5H	6	650mAh	NMH	\$79.95	\$63.95
BLI-195	SAMSUNG SB-L160	7.2	1.8Ah	LI	\$94.95	\$75.95
BLI-195-3.6	SAMSUNG SB-L320	7.2	3.6Ah	LI	\$149.95	\$119.95
BLI-195-5.4	SAMSUNG SB-L480	7.2	5.4Ah	LI	\$169.95	\$135.96
BLI-196	SHARP BT-L223U	7.4	1.8Ah	LI	\$79.95	\$63.95
BLI-197	JVC BN-V37	3.6	880mAh	LI	\$79.95	\$63.95
BLI-198	CANON NB-1L	3.7	680mAh	LI	\$79.95	\$63.95
BLI-199	CANON BP-406	7.4	700mAh	LI	\$79.95	\$63.95
BLI-199-1.2	CANON BP-412	7.4	1.2Ah	LI	\$99.95	\$79.95
BLI-199-2.4	CANON BP-422	7.4	2.4Ah	LI	129.95	\$103.95
BLI-200	SAMSUNG SB-L110	7.4	1.2Ah	LI	\$84.95	\$67.95
BLI-200-2.4	SAMSUNG SB-L220	7.4	2.4Ah	LI	129.95	\$103.95
BLI-201	NIKON EN-EL1 COOLPIX 880, 995	7.2	650mAh	LI	\$79.95	\$63.95
BLI-202	JVC BN-V107	7.2	800mAh	LI	\$89.95	\$71.95
BLI-202-1.5	JVC BN-V114	7.2	1.5Ah	LI	\$114.95	\$91.95
BLI-203	FUJI NP-60, PENTAX D-Li2	3.7	900mAh	LI	\$59.95	\$47.95
BLI-204	CANON NB-2L	7.4	570mAh	LI	\$99.95	\$79.95
BLI-205	SHARP BT-L225	7.4	950mAh	LI	\$89.95	\$71.95
BLI-207	YASHICA, KYOCERA BP800S, BP880S	3.7	800mAh	LI	\$69.95	\$55.95
BLI-208	PENTAX D-Li1	7.6	1.85Ah	LI	\$89.95	\$71.95
BLI-215	SONY BP-2X/2EX DIGITAL MINI DISC	3.6	600mAh	LI	\$69.95	\$55.95

### OEM Original Batteries

EPP-100	ORIGINAL PANASONIC PV-BP80/88	12	2.3Ah	L	\$69.95	\$55.95
EPP-130	ORIGINAL PANASONIC PV-BP50	12	2.0Ah	L	\$84.95	\$67.9

**LI = Lithium Ion**  
**NMH = Nickel Metal Hydride**

**N = Nickel Cadmium**  
**L = Lead Acid**