

U.S. ATR SERIES LIFETIME LIMITED END-USER WARRANTY

Select Audio-Technica ATR series microphones purchased in the U.S.A. from an authorized Audio-Technica (A.T.U.S.) dealer are warranted for the lifetime of the original purchaser by A.T.U.S. to be free of defects in materials and workmanship. In event of a defect, End-User's exclusive remedy is at A.T.U.S.' election, the cost of repair, refund of the purchase price in the form of credit or cash, or replacement of the product. A.T.U.S. reserves the right to replace any product with one of equal value. The product must be delivered to A.T.U.S., prepaid to the address below, together with the sales slip or other proof of original purchase and \$8.00 for handling and return to a U.S. address. Check or money order required; no cash or stamps.

This warranty excludes defects due to normal wear, abuse, shipping damage, or failure to use product in accordance with instructions. This warranty is void in the event of unauthorized repair or modification, or removal or defacing of the product labeling.

A.T.U.S.' warranty is to the End User only. Except for A.T.U.S.' said express warranty, A.T.U.S. MAKES NO WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCTS. A.T.U.S. SPECIFICALLY MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Except to the extent precluded by applicable state law, A.T.U.S. IS NOT LIABLE FOR CONSEQUENTIAL, INCIDENTAL, DIRECT OR SPECIAL DAMAGES ARISING, DIRECTLY OR INDIRECTLY, IN RESPECT OF SUCH PRODUCTS OR USE OR FAILURE THEREOF, WHETHER BASED ON BREACH OF WARRANTY, NEGLIGENCE, STRICT LIABILITY, TORT OR OTHERWISE.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.


Outside the U.S.A., please contact your local dealer for warranty details.



Audio-Technica U.S., Inc., 1221 Commerce Drive, Stow, Ohio 44224
www.audio-technica.com

P52496

Omnidirectional Condenser Boundary Microphone



To turn on, slide switch into the ON position. Slide to OFF position to turn microphone off.

- Power switch is located on the bottom of the microphone. To turn on, slide switch into the ON position. Slide to OFF position to turn microphone off.
- Plug the cable's mini-plug (or ¼" adapter) into the mic jack on your computer, phone with an external mic input, or recording device.
- Replace battery if sound becomes weak or mic stops working. Remove battery if you do not plan to use mic for a long period of time. Dispose of dead batteries properly.
- Remove the battery compartment cover on the bottom of the microphone. Insert the battery, matching the polarity marked on the cover. Replace battery compartment cover.

Inserting/Replacing Battery

User Instructions

- Perfect for teleconferencing, meetings and desktop computer use
- Omni pickup pattern offers full coverage
- Rugged construction for long-lasting performance
- On/off switch on bottom of microphone

Features

Thank you for purchasing this Audio-Technica omnidirectional condenser boundary microphone. Please read the instructions in this manual before using.

English

Specifications

Element: Condenser; **Polar Pattern:** Omnidirectional;
Frequency Response: 50 – 15,000 Hz; **Sensitivity:** -46 dB;
Impedance: 1,000 ohms; **Battery Type:** LR44;
Weight: 48 g (1.7 oz); **Cable:** 1.5 m (4.9') terminated with 3.5 mm (7/8") mini-plug; **Accessories Included:** 6.3 mm (¼") adapter; LR44 battery

Specifications and product details are subject to change without notice.

Français

Merci d'avoir acheté ce microphone de surface à condensateur omnidirectionnel Audio-Technica. Lisez les instructions du présent manuel avant de l'utiliser.

Caractéristiques :

- Parfait pour les téléconférences, les réunions et en utilisation sur un ordinateur de bureau
- Directivité omnidirectionnelle assurant une couverture complète
- Construction robuste garantissant des performances de longue durée
- Interrupteur marche/arrêt sur le pied du microphone

Instructions d'utilisation

Insertion et remplacement de la pile :

- Retirez le couvercle du compartiment à pile au bas du microphone. Insérez la pile en la faisant correspondre avec les repères de polarité sur le couvercle. Remplacez le couvercle du compartiment à pile.
- Remplacez la pile si le son devient faible ou si le micro cesse de fonctionner. Retirez la pile si le micro n'est pas utilisé pendant une période prolongée. Jetez les piles usagées de façon appropriée.

Branchement et mise sous tension du microphone :

- Branchez le mini-jack du câble (ou l'adaptateur de 6,3 mm (¼ po)) dans le jack micro de votre ordinateur, téléphone équipé d'une entrée micro externe, ou appareil d'enregistrement.
- L'interrupteur marche/arrêt se trouve au bas du microphone. Pour le mettre sous tension, poussez l'interrupteur en position ON. Poussez en position OFF pour éteindre le microphone.

Caractéristiques :

Élément : condensateur ; **Directivité :** omnidirectionnelle ; **Réponse en fréquence :** 50 à 15 000 Hz ; **Sensibilité :** -46 dB ; **Impédance :** 1 000 ohms ; **Type de pile :** LR44 ; **Poids :** 48 g ; **Câble :** 1,5 m (4,9 pi) muni d'un mini-jack de 3,5 mm (⅛ po) ; **Accessoires inclus :** adaptateur de 6,3 mm (¼ po) ; pile LR44

Les caractéristiques des produits sont susceptibles d'être modifiées sans préavis.

Español

Gracias por adquirir este micrófono de superficie de condensador omnidireccional de Audio-Technica. Lea las instrucciones de este manual antes de utilizar el micrófono.

Características:

- Perfecto para teleconferencias, reuniones y computadoras de sobremesa
- Patrón de captación omnidireccional que ofrece cobertura total
- Construcción robusta para un rendimiento duradero
- Interruptor de encendido/apagado en la parte inferior del micrófono

Instrucciones de usuario

Inserción y sustitución de la pila:

- Retire la cubierta del compartimento de la pila situado en la parte inferior del micrófono. Inserte la pila, respetando la polaridad indicada en la cubierta. Vuelva a colocar la tapa del compartimento de la pila.
- Sustituya la pila si el sonido se debilita o el micro deja de funcionar. Retire la pila si no va a utilizar el micro durante un largo período de tiempo. Deseche las pilas agotadas adecuadamente.

Conexión y encendido del micrófono:

- Enchufe el miniconector del cable (o el adaptador de ¼") en el conector para micro de su computadora, teléfono con entrada para micro externo o dispositivo de grabación.
- El interruptor de alimentación está situado en la parte inferior del micrófono. Para encenderlo, sitúe el interruptor en la posición de encendido (ON). Para apagar el micrófono, colóquelo en la posición de apagado (OFF).

Especificaciones:

Elemento: condensador; **Patrón polar:** omnidireccional; **Respuesta de frecuencia:** 50-15 000 Hz; **Sensibilidad:** -46 dB; **Impedancia:** 1000 ohmios; **Tipo de pila:** LR44; **Peso:** 48 g (1,7 g); **Cable:** 1,5 m (4,9'), terminado con miniconector de 3,5 mm (⅛"); **Accesorios incluidos:** adaptador de 6,3 mm (¼"); pila LR44

Las especificaciones y los detalles del producto están sujetos a cambios sin previo aviso.