

## E112/G

**CAUTION!** Please read and understand these instructions before installing or operating this unit.

## SPECIFICATIONS:

**Model:** *E* 112

**Lamp**: LL-64514 120V/300W

Weight: 16 lbs.

**Size:** 16" H x 12" W x 12" D

Fuse: 5 Amp Supply Voltage: 120V

Working Position: Any Safe position

Duty Cycle: 10 min. on,10 min. off

Colors: Clear Lenses

Warranty: 1 Year Limited Warranty

## Operating Instructions:

The E 112/C has been tested and the lamp has been installed at the factory, there no assembly required. The unit is ready to be plugged in to a power outlet. After the unit has been plugged in, the unit will immediately begin to rotate slowly at 6 r.p.m The unit will create multiple white beams rotating in 360°. To enhance the beams use this effect with a fog machine. This unit also looks great in pairs. For optimum performance of your E112/C, please follow its prescribed Duty Cycle.

Lamp Replacement: Disconnect the units main power supply. Unscrew and remove the thumb screws from the outer half of the dome. Remove the upper half of the dome. Remove and replace the bulb. Reassemble and reconnect the power supply. Be sure to follow all the handling instruction that are included with your new lamp.

1 Year Limited Warranty: Eliminator Lighting warranty is valid from the date of purchase. Our 1 year limited warranty covers manufacturing defects only. Serial number, place of purchase with dated valid receipt must be submitted at time of service. Eliminator Lighting warranty does not cover items or

parts prone to wear and tear: lamps, fuses, brushes and belts. Eliminator Lighting warranty is only valid with-in the United States.

**Caution!** Never open unit when in use. Always disconnect main power before serving or replacing lamp. Remember to always replace with the exact same type lamp and fuse.

## HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.