

# **Eliminator<sup>®</sup>** **LIGHTING**

## **E 118 MKII**

450 WATT FOG MACHINE AND  
MOONFLOWER

**CAUTION!** Please read and understand these instructions before installing or operating this unit.

### **SPECIFICATIONS:**

Model:	E 118 MKII
Voltage:	120v
Weight:	8Lbs./3.8Kgs.
Size:	9.5"(L) x 11.5"(W) x 8.5"(H)
Fuse:	7 Amp
Lamp:	EL-BRL 12v 50w
Fluid Type:	Eliminator Brand Water Based Fog Juice
Heater:	450 Watts
Output:	2,000 cubic ft. per minute
Ventilation:	Fan Cooled
Duty Cycle:	Not to exceed 6 hours
Warranty:	1 Year Limited Warranty

### **Description:**

The E 118 MKII is a 450 watt fog machine and moonflower in one. With this new combination you can enhance the moonflower light with the combined fog machine.

### **Operating Instructions:**

#### **Fog Machine:**

Begin by removing all of the packing material, especially around the nozzle area. Set the E 118 MKII on a flat, dry surface. Fill the fog juice reservoir, using Eliminator brand Water Based Fog Juice, only. Attach the included remote control to the unit. Plug the unit into a matching power outlet. To operate the fog machine just "flip" the top power switch to the "On" position. When you switch on the power for the fog machine, a red L.E.D. will glow on the remote control indicating that the unit is receiving power. Wait for about 5 minutes for the unit to heat up. After the unit has heated up, the red L.E.D. will turn off on the remote control, indicating that the unit is ready. Push the button on the remote control to emit fog.

#### **Moonflower:**

The moonflower effect has (3) three operating modes. When the operating switch is in the "II" position the internal dichoric dish will rotate only in the presence of sound. When the switch is in the "0" the internal dichoric dish will remain static. When the switch is in the "I" the internal dichoric dish continuously rotate. To operate the moonflower effect, just "flip" the bottom power switch to the "On" position, and choose your desired operating mode.

**Lamp Replacement:** Loosen the two thumb screws located on the top of the unit. Carefully remove the socket assembly access cover. Remove and replace the bad lamp, then replace and tighten the cover.

#### **HALOGEN LAMP WARNING!**

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

**SAFETY ISSUES:**

**NEVER POINT OR AIM A FOG MACHINE TOWARDS PEOPLE OR THEIR CLOTHING. THIS UNIT EMITS HOT VAPOR AND SHOULD BE USED WITH THE SAME CARE THAT YOU WOULD OBSERVE WHEN USING AN ELECTRIC IRON.**

***1 Year Limited Warranty:*** Eliminator Lighting warranty is valid from the date of purchase. Our 1 year limited warranty covers manufacturing defects only. Serial number, place of purchase with dated valid receipt must be submitted at time of service. Eliminator Lighting warranty does not cover items or parts prone to wear and tear: lamps, fuses, brushes and belts. Eliminator Lighting warranty is only valid with-in the United States.