



Keyboard Cross Reference: GKPE-61-TSA

January 3rd, 2013

* Note This Page Not Formatted For Printing

Use Ctrl-F to search by Manufacturer, Model Number, or UPC

Manufacturer	Model	UPC	Type	Fits (1)
Access	VIRUS TI 61	889406177802	Keyboard	GKPE-61-TSA
Alesis	A6		Keyboard	GKPE-61-TSA
Alesis	ANDROMEDA		Keyboard	GKPE-61-TSA
Casio	AT3	079767313838	Keyboard	GKPE-61-TSA
Casio	CTK-2000	079767313517	Keyboard	GKPE-61-TSA
Casio	CTK-2100	079767313654	Keyboard	GKPE-61-TSA
Casio	CTK-2100		Keyboard	GKPE-61-TSA
Casio	CTK-3000	079767313531	Keyboard	GKPE-61-TSA
Casio	CTK-3200	079767314071	Keyboard	GKPE-61-TSA
Casio	CTK4000	079767313548	Keyboard	GKPE-61-TSA
Casio	CTK-4200	079767314002	Keyboard	GKPE-61-TSA
Casio	CTK-496		Keyboard	GKPE-61-TSA
Casio	CTK5000		Keyboard	GKPE-61-TSA
Casio	CTK6000	079767313814	Keyboard	GKPE-61-TSA
Casio	CTK-691		Keyboard	GKPE-61-TSA
Casio	CTK7000	079767313821	Keyboard	GKPE-61-TSA
Casio	CTK710		Keyboard	GKPE-61-TSA
Casio	CTK800		Keyboard	GKPE-61-TSA
Casio	CTK810		Keyboard	GKPE-61-TSA
Casio	CTK900		Keyboard	GKPE-61-TSA
Casio	LK100		Keyboard	GKPE-61-TSA
Casio	LK-165	874171004248	Keyboard	GKPE-61-TSA
Casio	LK-2005		Keyboard	GKPE-61-TSA
Casio	LK-220		Keyboard	GKPE-61-TSA
Casio	LK-230	079767313661	Keyboard	GKPE-61-TSA
Casio	LK-270		Keyboard	GKPE-61-TSA
Casio	LK-280	079767314026	Keyboard	GKPE-61-TSA
Casio	LK-300TV		Keyboard	GKPE-61-TSA
Casio	LK94		Keyboard	GKPE-61-TSA
Casio	XW-G1	079767314163	Keyboard	GKPE-61-TSA
Casio	XW-P1	079767314156	Keyboard	GKPE-61-TSA
Clavia	G2X		Keyboard	GKPE-61-TSA
Clavia	NORD ELECTRO 2 73		Keyboard	GKPE-61-TSA
Clavia	NORD ELECTRO 73		Keyboard	GKPE-61-TSA
Clavia	NORD MODULAR G2X		Keyboard	GKPE-61-TSA
CME	UF6		Keyboard	GKPE-61-TSA
CME	UF60	877295000585	Keyboard	GKPE-61-TSA
CME	VX 6		Keyboard	GKPE-61-TSA
Dave Smith	POLY EVOLVER KEYBOARD	855346000869	Keyboard	GKPE-61-TSA
E-MU	LONGboard 61		Keyboard	GKPE-61-TSA
Ketron	Audya 5		Keyboard	GKPE-61-TSA
Korg	CX3		Keyboard	GKPE-61-TSA
Korg	i30		Keyboard	GKPE-61-TSA
Korg	KARMA		Keyboard	GKPE-61-TSA
Korg	KORG M1		Keyboard	GKPE-61-TSA
Korg	Kronos 61	4959112081000	Keyboard	GKPE-61-TSA
Korg	M3-61	4959112053922	Keyboard	GKPE-61-TSA
Korg	M50-61	4959112066755	Keyboard	GKPE-61-TSA
Korg	O1WFD 61		Keyboard	GKPE-61-TSA
Korg	Pa3X 61	4959112081826	Keyboard	GKPE-61-TSA
Korg	PA50SD	4959112071803	Keyboard	GKPE-61-TSA
Korg	TR61		Keyboard	GKPE-61-TSA
Korg	TRITON EXTREME 61		Keyboard	GKPE-61-TSA
Korg	TRITON LE 61		Keyboard	GKPE-61-TSA
Korg	TRITON STUDIO 61		Keyboard	GKPE-61-TSA
Korg	X3		Keyboard	GKPE-61-TSA
Korg	X-50	4959112046153	Keyboard	GKPE-61-TSA
Kurzweil	K2661		Keyboard	GKPE-61-TSA
Kurzweil	PC161		Keyboard	GKPE-61-TSA
Kurzweil	PC361		Keyboard	GKPE-61-TSA
Kurzweil	PC3K6	883793202918	Keyboard	GKPE-61-TSA
Kurzweil	PC3LE6	883793202420	Keyboard	GKPE-61-TSA
Kurzweil	SP4-7	883793302403	Keyboard	GKPE-61-TSA
M-Audio	AXIOM 61	612391700836	Keyboard	GKPE-61-TSA
M-Audio	Axiom Pro61		Keyboard	GKPE-61-TSA
M-Audio	KEYSTATION 61ES		Keyboard	GKPE-61-TSA
Nord	ELECTRO 2 73		Keyboard	GKPE-61-TSA
Nord	Stage 2 SW73	834035001004	Keyboard	GKPE-61-TSA
Novation	61 SL Mk II	815301001027	Keyboard	GKPE-61-TSA
Novation	Impulse61	815301000426	Keyboard	GKPE-61-TSA
Novation	REMOTE61	815301001027	Keyboard	GKPE-61-TSA
Novation	XSTATION 61		Keyboard	GKPE-61-TSA

Roland	BK5	761294502037	Keyboard	GKPE-61-TSA
Roland	E09	761294400340	Keyboard	GKPE-61-TSA
Roland	EXR-3		Keyboard	GKPE-61-TSA
Roland	EXR46-OR		Keyboard	GKPE-61-TSA
Roland	EXR-5		Keyboard	GKPE-61-TSA
Roland	FANTOM G6	761294089682	Keyboard	GKPE-61-TSA
Roland	FANTOM X6		Keyboard	GKPE-61-TSA
Roland	FANTOM XA 61		Keyboard	GKPE-61-TSA
Roland	GW-7		Keyboard	GKPE-61-TSA
Roland	GW-8	761294408179	Keyboard	GKPE-61-TSA
Roland	JUNO D 61		Keyboard	GKPE-61-TSA
Roland	Juno Di	761294403099	Keyboard	GKPE-61-TSA
Roland	Juno Gi	761294412718	Keyboard	GKPE-61-TSA
Roland	JUNO-D		Keyboard	GKPE-61-TSA
Roland	JUNO-G		Keyboard	GKPE-61-TSA
Roland	JV30		Keyboard	GKPE-61-TSA
Roland	Prelude	761294409473	Keyboard	GKPE-61-TSA
Roland	RS-50		Keyboard	GKPE-61-TSA
Roland	RS-70		Keyboard	GKPE-61-TSA
Roland	V SYNTH		Keyboard	GKPE-61-TSA
Roland	V SYNTH GT	761294403051	Keyboard	GKPE-61-TSA
Roland	XP30		Keyboard	GKPE-61-TSA
Roland	XP-50		Keyboard	GKPE-61-TSA
StudioLogic	Numa Organ	8034141640124	Keyboard	GKPE-61-TSA
StudioLogic	Sledge		Keyboard	GKPE-61-TSA
StudioLogic	VMK-161+	093018822009	Keyboard	GKPE-61-TSA
StudioLogic	VMK-161+ORGAN		Keyboard	GKPE-61-TSA
Suzuki	SP-37		Keyboard	GKPE-61-TSA
Suzuki	SP-67		Keyboard	GKPE-61-TSA
Yamaha	CSX1		Keyboard	GKPE-61-TSA
Yamaha	EZ150		Keyboard	GKPE-61-TSA
Yamaha	EZ200	086792304458	Keyboard	GKPE-61-TSA
Yamaha	EZ220	086792963136	Keyboard	GKPE-61-TSA
Yamaha	EZ250I		Keyboard	GKPE-61-TSA
Yamaha	KX61		Keyboard	GKPE-61-TSA
Yamaha	MM6	086792858098	Keyboard	GKPE-61-TSA
Yamaha	MO6		Keyboard	GKPE-61-TSA
Yamaha	MOTIF ES6		Keyboard	GKPE-61-TSA
Yamaha	MOTIF XF6	086792941806	Keyboard	GKPE-61-TSA
Yamaha	MOTIF XS6		Keyboard	GKPE-61-TSA
Yamaha	MOTIF6		Keyboard	GKPE-61-TSA
Yamaha	MOX6	086792950884	Keyboard	GKPE-61-TSA
Yamaha	NP-11	086792952611	Keyboard	GKPE-61-TSA
Yamaha	PSR 175		Keyboard	GKPE-61-TSA
Yamaha	PSR E423	086792939506	Keyboard	GKPE-61-TSA
Yamaha	PSR-172		Keyboard	GKPE-61-TSA
Yamaha	PSR-293		Keyboard	GKPE-61-TSA
Yamaha	PSR-A2000	086792958019	Keyboard	GKPE-61-TSA
Yamaha	PSR-E203		Keyboard	GKPE-61-TSA
Yamaha	PSR-E213		Keyboard	GKPE-61-TSA
Yamaha	PSR-E223		Keyboard	GKPE-61-TSA
Yamaha	PSR-E233	086792944654	Keyboard	GKPE-61-TSA
Yamaha	PSR-E233	086792944654	Keyboard	GKPE-61-TSA
Yamaha	PSR-E303		Keyboard	GKPE-61-TSA
Yamaha	PSR-E323		Keyboard	GKPE-61-TSA
Yamaha	PSR-E333	086792944777	Keyboard	GKPE-61-TSA
Yamaha	PSR-E333	086792944777	Keyboard	GKPE-61-TSA
Yamaha	PSR-E403		Keyboard	GKPE-61-TSA
Yamaha	PSR-E413		Keyboard	GKPE-61-TSA
Yamaha	PSR-E423	086792939506	Keyboard	GKPE-61-TSA
Yamaha	PSR-E433	086792964706	Keyboard	GKPE-61-TSA
Yamaha	PSR-OR700		Keyboard	GKPE-61-TSA
Yamaha	PSR-S500		Keyboard	GKPE-61-TSA
Yamaha	PSR-S550BK		Keyboard	GKPE-61-TSA
Yamaha	PSR-S650	086792944586	Keyboard	GKPE-61-TSA
Yamaha	PSR-S700		Keyboard	GKPE-61-TSA
Yamaha	PSR-S710	086792931784	Keyboard	GKPE-61-TSA
Yamaha	PSR-S900		Keyboard	GKPE-61-TSA
Yamaha	PSR-S910	086792931753	Keyboard	GKPE-61-TSA
Yamaha	S03		Keyboard	GKPE-61-TSA
Yamaha	SY77		Keyboard	GKPE-61-TSA
Yamaha	YPT-200		Keyboard	GKPE-61-TSA
Yamaha	YPT-220	086792899558	Keyboard	GKPE-61-TSA
Yamaha	YPT-310		Keyboard	GKPE-61-TSA
Yamaha	YPT-400		Keyboard	GKPE-61-TSA

This list is intended as a guide; not a substitute for testing the actual fit. All product information referenced above is based on the manufacturer's published specifications. These specifications may change over time and without notice. If you have questions on a specific case or product, or see that a correction is needed, please contact

