



RDL[®]
Radio Design Labs

SPECIALISTS IN PRACTICAL PRECISION ENGINEERING™

ACCESSORIES

Model RC-HPS1


Power Supply Chassis

Installation/Operation



EN55103-1 E1-E5; EN55103-2 E1-E4

Typical Performance reflects product at publication time exclusive of EMC data, if any, supplied with product. Specifications are subject to change without notice.



Step 1

Step 2

Slide the Power Supply into the RC-HPS1 Bracket.

With the mounting screws partially installed, slide them into the tabs on the rear of the RC-HPS1.

Step 3

Secure the module by tightening the mounting screws with a suitable driver.

TYPICAL PERFORMANCE

Capacity:

Compatible with all RDL desktop power supplies and with any desktop power supply with maximum dimensions:

5.8" (14.7 cm) x 3" (7.6 cm) x 1.7" (4.3 cm)

Material:

18-gauge

Finish:

RDL Black

Radio Design Labs Technical Support Centers

U.S.A. (800) 933-1780, (928) 778-3554; Fax: (928) 778-3506

Europe [NH Amsterdam] (++31) 20-6238 983; Fax: (++31) 20-6225-287