

ACCESSORIES

Models STR-H6A

Installation/Operation





EN55103-1 E1-E5; EN55103-2 E1-E4

Typical Performance reflects product at publication time exclusive of EMC data, if any, supplied with product. Specifications are subject to change without notice.

Step 1
Slide STICK-ON Modules into the STR-H6A.

Step 2
Use Cable Ties to Secure Wiring.

Step 3
Connect Shields to Ground Terminal.
(normal for inputs, optional for outputs)



STICK-ON Module Terminal Block