

ACCESSORIES

REAR RACK ADAPTER

FP-RRB1, ST-RRB1 & TX-RRB1

Installation/Operation



EN55103-1 E1-E5; EN55103-2 E1-E4

Typical Performance reflects product at publication time exclusive of EMC data, if any, supplied with product. Specifications are subject to change without notice.

Step 1
Attach TX
module to the
TX-RRB1
with screws.

Step 1
Attach FLAT-
PAK module to
the
FP-RRB1 with
screws.

Step 2
Attach
RRB1 with
appropriate
module on
to rear rack
rail with
supplied
screws.

Step 1
Slide the STICK-ON
onto the ST-RRB1.
Once it is fully
seated bend the
locking tab up
slightly to secure
the module to the
ST-RRB1.

