RANE 5L2



CONNECT TWO TURNTRABLES OR DO DECKS TO SEZ NIVUTS. S'SET THE CD / PHOND SWITCH ON THE SL2 LINE-LEVEL INPUT? LINE-LEVEL INPUT?

The standard for professional DJs

The Rane SL series of interfaces with Serato Scratch Live set the standard for vinyl emulation, and now ship with the improved Serato DJ software. Rane and Serato give you advanced features that add extra creativity to your DJing. This intuitive system replicates the traditional DJing experience for "real feel" usability. Low latency means the response time from touching the decks to hearing an audio signal is extremely fast. The SL series of interfaces work with computers running Serato DJ, Scratch Live, or third-party audio programs with ASIO and Core Audio support.

The Rane SL2 interface connects one or two standard vinyl turntables or CD decks to your computer using a single USB cable and audio connections to line inputs on any DJ mixer of your choice. This system includes Serato DJ software with two 12" Serato Control Vinyl records, two Serato Control CDs, USB cable, and RCA audio cables to your mixer. Galvanic isolation guarantees audio is actively isolated from USB and power. Several MIDI controllers are supported, and a current list is at serato.com.

The SL2 advances the technology from the original SL1 with these improvements:

- CD / Phono input switch on the box.
- Superior sounding 24-bit converters.
- Hotter 3 Vrms input and output.
- 44.1 or 48 kHz selectable sample rate.
- Smaller and more compact cast design.
- ASIO / Core Audio drivers for 3rd-party software.











The SL2 includes Serato DJ with 2 Serato Control Vinyl and 2 Serato Control CDs.

SL2 Specifications

All specifications typical unless otherwise stated

CODEC

44.1 kHz Sample Rate Frequency Response 48 kHz Sample Rate Frequency Response

Sample Rate Selection

Deck Inputs

.....Phono Maximum Input

.....Phono Gain

.....Line Level (CD) Maximum Input

Line Outputs:

.....THD+N

..... Maximum Output

.....Dynamic Range

Dynamic Range DAC

Device Latency

USB 2.0 High Speed Port Required

Blue Indicator

Yellow Indicator

Optional RS5 External Universal Power Pack

Power: Turn On/Off Muting

24-bit PCM

-0.5 dB @ 20 Hz, -1.22 dB @ 20 kHz

-0.5 dB @ 20 Hz, -0.40 dB @ 20 kHz

44.1 / 48 kHz selected in software control panel

Unbalanced RCA with CD / Phono switch

70 mV rms @ 1 kHz

33 dB at 1.0 kHz

3 Vrms

Unbalanced RCA

0.007% @ 1 kHz

3 Vrms

101 dB A-weighted analog in to analog out

104.5 dB A-weighted

1.4 ms @ 44.1 kHz and 1.3 ms @ 48 kHz

3-unit load (300 mA max)

Flashing while device is booting

Lit when USB 2.0 connection is detected

Lit when the analog section is powered on

7.5 Volts DC, P6 barrel plug

Yes

......Galvanic Isolation: Audio I/O is actively isolated from USB port and external power

.....Auto-selects USB or external power without interruption

Kensington Security Slot

Unit: Conformity

.....Size

Shipping: Size

.....Weight

Both sides of unit

CE, FCC

5.5" x 5" x 1.3" (14.1 x 12.5 x 3.3 cm)

14" x 14" x 4" (36 x 36 x 10 cm)

5 pounds (2 kg)

ASIO & Core Audio Drivers

These included drivers allow the SL2 to act as a 4-in 4-out USB external sound card for use with multiple third-party software clients supporting Core Audio (Mac) or ASIO (Windows).

Serato DJ

Rane is pleased to announce that the SL2 which previously included Serato Scratch Live software is now fully supported by Serato DJ software. DJs currently using Serato Scratch Live have the option to migrate to the new and improved Serato DJ free of charge. If you're familiar with Scratch Live, the transition to Serato DJ is easy and intuitive.

Computer Requirements

Before purchasing a Mac or PC, please check serato.com for best results with the latest version of Serato DJ.

Serato Control

Mix files from your computer hard drive using Serato Control Vinyl, Serato Control CD or approved USB Controllers. The Serato Control Vinyl and Control CDs each contain the Serato NoiseMap[™] Control Tone, a unique control signal which allows Serato DJ or Scratch Live to track the motion of the record, simulating the same movement with digital audio.

Included in the Box

The Rane SL2 is only sold as part of a complete package. This box includes:

- SL2 hardware interface
- USB cable
- 4 stereo RCA cables
- Printed color manuals
- 2 Control Vinvl Records
- 2 Control CDs
- Serato DJ software install disc



serato.com

Features are being added and improved, and the latest version of Serato DJ or Scratch Live is a free download. The Forum at serato.com is the best place for technical support and performance tips from thousands of other DJs.

whitelabel.net

The Serato Whitelabel Delivery Network is a unique system that allows record labels to digitally deliver promotional releases directly to Serato DJs. To download Whitelabel audio files and sign up for updates on the latest promotional releases, visit whitelabel.net.

dj.rane.com

Visit the Rane DJ website for the most up-to-date information on all Rane hardware, manuals, accessories, support, community, newsletter and the blog.

© 2014 Rane Corporation. Accelerated-Slope, FlexFX and Active Crossfader are trademarks of Rane Corporation. All rights reserved. Windows XP, Vista, and 7 are either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries. Apple, Mac, Macintosh and iTunes are trademarks of Apple Computer, Inc., registered in the US and/or other countries. Serato DJ and Scratch Live are trademarks of Serato. Lexan is a registered trademark of General Electric. iZotope is a trademark of iZotope, Inc. in the United States and other countries.

1-2014