


## Powerbase 70-S Instruction Manual

1. Using conversion box GP-DV-S the Powerbase 70 can supply 7.2V for Sony cameras with a faux battery. It can also supply 12V for accessories through the conversion box PT socket.




2. Included conversion box/cable applicable camera models:


-Sony L-Series Camcorders



1. Can be used as normal V type brick battery
2. Built-in PT port can supply power for accessories or charging.





3. Quick release plate can be used to install wireless receiver, hard drive or other equipment or to connect two batteries.



### Specifications

Rated Voltage: 14.8V  
Rated Capacity: 70Wh  
Charge Time: 3~5 hrs  
Dimensions: 6.25in x 3.4in x 2in  
Weight: 1.5lbs  
Four step LED power indication

4. Both sides have a 1/4" 20 insert for installing other equipment



| Remaining Capacity (%) | LED1  | LED2 | LED3 | LED4 |
|------------------------|-------|------|------|------|
| 0%                     | OFF   | OFF  | OFF  | OFF  |
| <10%                   | FLASH | OFF  | OFF  | OFF  |
| 10%-25%                | ON    | OFF  | OFF  | OFF  |
| 25%-50%                | ON    | ON   | OFF  | OFF  |
| 50%-75%                | ON    | ON   | ON   | OFF  |
| ≥75%                   | ON    | ON   | ON   | ON   |