



©JERRY GHIONS

## WARRANTY

One year against manufacturer defect.

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Register this product at [FJWESTCOTT.COM/WARRANTY](http://FJWESTCOTT.COM/WARRANTY)

Repair Dept.: 800-886-1689 / 419-243-7311 (International)

E-Mail: [INFO@FJWESTCOTT.COM](mailto:INFO@FJWESTCOTT.COM) SUBJECT: ATTN: REPAIR DEPT.

Shipping: Westcott, 1425 Holland Rd-B, Maumee, OH 43537

©F.J. WESTCOTT CO. ALL RIGHTS RESERVED.

# ICELIGHT POWERPACK

---

QUICK START GUIDE

---

 **westcott.**

# SETUP & USAGE

## SETUP

1. **IMPORTANT!** Fully charge PowerPack prior to initial use. **ONLY** utilize the charger that came with the IceLight to charge the PowerPack.
2. **IMPORTANT!** When using the PowerPack battery to charge a fully depleted IceLight™, wait 3 minutes before disconnecting the charger to ensure the best performance of both units.
3. Align the power plug receptacle on the PowerPack to the receptacle on the IceLight. Once aligned, place the base of the IceLight onto the screw which is located on the top of the PowerPack.
4. Rotate dial to affix the IceLight to the PowerPack. Continue rotating dial until rotations are no longer possible.
5. Once affixed, locate the AC/DC Connector Cord that came with the PowerPack. Insert one end of the connector cord into the PowerPack. Insert the opposite end of the cord into the IceLight.
6. Use UP arrow button to power on IceLight.
7. To remove the PowerPack from the IceLight, unplug the cord from each device. While holding onto both devices, rotate dial on PowerPack until unit separates from the IceLight.

# CARE & SPECS

## CAUTION

1. The IceLight charger is restricted to use with the IceLight and PowerPack.
2. Never use any power cable or transformer other than the one supplied by Westcott. During charging and/or operation, the terminal and/or IceLight may become warm. This is normal. Take extra care when handling.
3. Do not use near or in water. Do not get wet or expose to extreme weather conditions.
4. Never insert the IceLight into a travel case while in the ON position.
5. **AVOID** electric shock. Never disassemble IceLight or PowerPack for any reason.
6. Unplug power when not in use. Store safely.

## WARNING

1. Federal Regulations Prohibit Li-Ion Batteries as Check Luggage during aviation travel. Changes to these regulations may occur without notification. Please consult with government and/or travel officials for the most up-to-date information.
2. Do not attempt to disassemble, open or service.
3. Only use with the IceLight charger.
4. Do not crush, puncture or dispose of in fire or water.
5. Must be recycled or disposed of properly.
6. Do not store in temperature above 45°C or below -20°C.

## SPECIFICATIONS

<b>BATTERY</b>	Lithium Ion	<b>MAXIMUM DISCHARGE</b>	3000mA
<b>NOMINAL VOLTAGE</b>	7.2V	<b>RUN TIME MAX POWER</b>	2.5 hours
<b>CHARGE TIME</b>	4 hrs	<b>DIMENSIONS</b>	49 x 49 x 112mm
<b>CAPACITY</b>	5200mAh	<b>TERMINALS</b>	DC Cable/OD5.5