American DJ®

User Instructions

FS- 1000

PRO FOLLOWSPOT

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Caution! Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

Model: FS-1000TM

SPECIFICATIONS:

Lamp: ZB-HX600 120V 575W

Power: 110V/60Hz Fuse : 5 A GMA

Ventilation: Fan Cooling Working Position: Any

Weight: 17 lbs.

23 lbs. w/ tripod stand

Size: 7 1/2" x 7 1/2" x 22"

Beam Spread:

From 30 ft. : 5 1/2 ft. From 60 ft. : 10 3/4 ft



Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

Operating Instructions:

Unit is made of extruded aluminum casing, and is ready to be hung or set on a Tripod. The FS1000[™] features a bright HX-600 575 watt lamp, dual focusing knobs for precise, full focusing, iris control knob at top of unit can also blackout, dimmer knob at back of un it, handle, gel frame, and a hanging bracket. Optional LTS-5 tripod stand comes w system. Color gels not included. The ADJ FS-6C, color changer adapter, which fits on the front of the FS-1000[™], gives the user convenient access to 4 color gels or to mix colors between the four(FS-6C sold separately).

To replace lamp; unscrew screws on the back of the unit, pull out module, replace bulb and reassemble. Do not forget to unplug unit before replacing bulb!

Fuse is located underneath mains input For service, contact your *American* $DJ^{\mathbb{M}}$ dealer.