

1/4" LONGFRAME 489 SERIES

PROGRAMMING INSTRUCTIONS

HOW TO IDENTIFY A PROGRAMMABLE PATCHBAY

489 Series programmable patchbays can be identified by the Programmable Icon in the upper left corner of the patchbay.



HOW TO CHANGE THE PROGRAMMING FOR A CIRCUIT

1: Remove the top designation strip, as shown in the photo on the right.

2: Find your desired configuration in the diagram.

3: Arrange the programming shunts to match the appropriate diagram. Note: Each circuit can be programmed independently.

4: Ample shunts are provided with every patchbay. Red shunts are placed horizontally and are used for normaling. White shunts are placed vertically and are used for grounding.

5: The circuits are numbered 1-24 and correspond to vertical jack pairs reading left to right.

6: Replace the designation strip.

SHUNT SCHEMATICS

