

SM-BSSPT

Shockmount Base



USER GUIDE



The SM-BSSPT ON/OFF button has 3 configurations:

1. Latching On/Off
2. Momentary Push to Talk
3. Momentary Push to Mute

There are 2 switches used for the configurations.

The switch on the bottom is to select between latching and momentary.


When in the "Push to talk" position, the ON/OFF button is momentary, it must be held for operation.

When in the "Push to Lock" position the ON/Off is latching.

The second switch is internal, under the cover plate on the bottom of the unit.

When in the ON/OFF position, the normal state of the SM-BSSPT is ON

When in the OFF/ON position, the normal state of the SM-BSSPT is OFF.



Scan for Info



MAKERS OF THE ORIGINAL
HOT POT PERSONAL MONITOR



www.galaxyaudio.com

ONE YEAR LIMITED WARRANTY

WARRANTY Information can be viewed online at
<https://www.galaxyaudio.com/support/warranty>



www.galaxyaudio.com/support/warranty

SM-BSSPT

1-800-369-7768 www.galaxyaudio.com

Specifications in this manual are subject to change without notice.

© Copyright Galaxy Audio 2017

V20171013