KickStand[™] kick drum mic isolator

USER GUIDE


Congratulations on purchasing the KickStand! The KickStand is an isolated base for a mic boom, designed to eliminate resonance from the stage, drum riser or studio floor from entering the microphone. Please take a few minutes to read through this manual. It includes a list of parts as well as step by step mounting instructions. Please refer to www.primacoustic.com for various placement options, benefits, and general acoustic information. Should you have any questions or comments, we invite you to send us an email at: info@primacoustic.com.



BOX CONTENTS AND ASSEMBLY


Unpack the KickStand and take a moment to confirm the box contents. It should include the following parts:

- Threaded mic adapter
- 2 Lock washer
- 3 Tightening Knob
- 4 KickStand



MAKING ADJUSTMENTS

Assemble the tightening knob and lock washer through the KickStand mounting hole and onto the threaded microphone boom mount adapter. Attach the boom and gently tighten.



APPLICATIONS

The KickStand is designed for the kick drum yet it is equally effective with other instruments and amplifiers.







LIMITED WARRANTY

Primacoustic products are guaranteed to be free of manufacturing defects for a period of thirty (30) days after purchase. In the unlikely event that a defect is uncovered, please email info@primacoustic.com or call 604-942-1001 to obtain a return authorization number (RA#) from Primacoustic before the thirty (30) day warranty period expires. Once you have obtained an RA number return the product, freight prepaid, within fifteen (15) days after the date the RA number is issued. In the original packaging (or another, affording an equal degree of protection) include all of the following: (1) RA number clearly marked on the returned package; (2) a copy of the original bill of sale showing proof of purchase from an authorized retail seller; and (3) a written note describing the defect including your name, address, telephone number, email address and the applicable RA number. You are solely responsible for all shipping and insurance costs for returning the product to Primacoustic, and you will not be reimbursed or compensated for any loss or damage incurred. Primacoustic will at its discretion repair or replace the product. Should the product be no longer available, Primacoustic reserves the right to exchange this with a product of similar performance and value. Due to different dye lots, Primacoustic cannot guarantee exact color match. This Warranty shall solely extend to the original owner and is limited to manufacturing defects only and excludes damage due to improper installation, freight handling, wear and tear, abuse, misapplication, color fading or deterioration due to prolonged exposure to ultra violet light, smoke, humidity or other environmental factors. It is understood that the use and suitability of the product is entirely the responsibility of the buyer or specifying engineer and as such, these parties agree to hold Primacoustic, or its associated company, and/or officers, harmless from any responsibility whatsoever other than what is clearly outlined in this warranty gives you specific legal rights, an

Primacoustic is a division of Radial Engineering Ltd. 1588 Kebet Way, Port Coquitlam, BC Canada V3C 5M5 Tel: (604) 942-1001 • Fax (604) 942-1010 • info@primacoustic.com

