





1

REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# A-FRAME 12 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# A-FRAME 120 VOLT INCANDESCENT LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE. REMOVE THE LIGHT BULB AND IT'S PACKAGING FROM THE SOCKET AND SET IT IN A SAFE PLACE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.




3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.




4

CAREFULLY REINSTALL THE BAYONET TYPE LIGHT BULB INTO THE SPRING LOADED SOCKET. TURN IT SO THAT THE PEGS LOCK INTO THE SLOTS AND HOLD THE BULB IN PLACE.



5

REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# A-FRAME 120-220 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*


# MEGA 12 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




- 1** REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP AND BOTTOM OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




- 2** PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.



- 3** ATTACH THE BACK PLATE UTILIZING THE 2 KEYHOLE SLOTS ON THE LEFT AND RIGHT OF THE LENS. TO MOUNT THE HOUSING USING THE CENTER J-BOX OR VESA 75/100 HOLES YOU MIGHT NEED TO REMOVE THE FRONT LENSES.




- 4** REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*




- 1 REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP AND BOTTOM OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.





- 2 PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.



- 3 ATTACH THE BACK PLATE UTILIZING THE 2 KEYHOLE SLOTS ON THE LEFT AND RIGHT OF THE LENS. TO MOUNT THE HOUSING USING THE CENTER J-BOX OR VESA 75/100 HOLES YOU MIGHT NEED TO REMOVE THE FRONT LENSES.



- 4 REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.



*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*




# RETRO 12 VOLT DOUBLE LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# RETRO 12 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*







**1** REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.





**2** PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.



**3** ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



**4** REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*




1

REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE. REMOVE THE LIGHT BULB AND IT'S PACKAGING FROM THE SOCKET AND SET IT IN A SAFE PLACE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.




3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.




4

CAREFULLY REINSTALL THE BAYONET TYPE LIGHT BULB INTO THE SPRING LOADED SOCKET. TURN IT SO THAT THE PEGS LOCK INTO THE SLOTS AND HOLD THE BULB IN PLACE.



5

REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# RETRO 120-220 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# SIMPLE 12 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.





3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



4

REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*


# SIMPLE 12, 24, 220 VOLT INCANDESCENT LIGHT INSTALLATION INSTRUCTIONS




**1** REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




**2** PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.



**3** ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



**4** REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*

# SIMPLE 120 VOLT INCANDESCENT LIGHT INSTALLATION INSTRUCTIONS




1

REMOVE THE 2 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE. REMOVE THE LIGHT BULB AND IT'S PACKAGING FROM THE SOCKET AND SET IT IN A SAFE PLACE.




2

PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.




3

ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.




4

CAREFULLY REINSTALL THE BAYONET TYPE LIGHT BULB INTO THE SPRING LOADED SOCKET. TURN IT SO THAT THE PEGS LOCK INTO THE SLOTS AND HOLD THE BULB IN PLACE.



5

REATTACH THE ALUMINUM HOUSING WITH THE 2 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.




*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*




# SIMPLE 120-220 VOLT LED LIGHT INSTALLATION INSTRUCTIONS




**1** REMOVE THE 4 FLAT HEAD PHILLIPS SCREWS FROM THE TOP OF THE HOUSING AND SET THEM ASIDE. SEPARATE THE HOUSING FROM THE BACK PLATE AND REMOVE THE WIRE NUTS AND SCREWS THAT ARE INSIDE.




**2** PRIOR TO DOING ANY ELECTRICAL WORK MAKE SURE THAT THE CIRCUIT IS SHUT OFF AT THE BREAKER PANEL. CONNECT THE WIRES WITH THE SUPPLIED WIRE NUTS. MAKE SURE THAT THE GROUND WIRE (GREEN) IS PROPERLY SECURED TO THE J-BOX OR THE COMMON GROUND.



**3** ATTACH THE BACK PLATE TO THE ELECTRICAL J-BOX WITH THE SUPPLIED PHILLIPS SCREWS. MAKE SURE THAT THE WIRES ARE TUCKED AWAY SECURELY. THE BACK PLATE ALSO HAS HOLES FOR A VESA 75 MOUNT.



**4** REATTACH THE ALUMINUM HOUSING WITH THE 4 PHILLIPS FLAT HEAD SCREWS THAT WERE REMOVED IN STEP 1. CLEAN OFF ALL THE FINGERPRINTS AND ENJOY.



*This sign is intended to be installed in accordance with the requirements of Article 600 of the National Electrical Code and/or other applicable local codes. This includes proper grounding and bonding of the sign.*