

OWNERS MANUAL

AS-40M COMPACT DMX/MANUAL DIMMER

Version 2.0 02/14/2005

Page 1 of 5



Please take a moment to read this manual before you operate the AS - 40M dimmer.



DESCRIPTION

The AS-40M is a compact 4 channel light dimmer. It has a maximum capacity of 600 Watts per channel and a maximum TOTAL load capacity of 2400 Watts. It is supplied with an input power cord which may be connected to a 120 VAC, 20 Amp power circuit. The AS-40M is intended for INDOOR USE ONLY. The unit operates using the USITT DMX-512 protocol. The AS-40M may be operated in a relay (non-dim) mode. The unit will also function as a stand alone chaser and has eight primary preset chase patterns which may be used. An additional manual operating mode is available which enables the unit to function as a stand alone dimmer with manual control of each channel.

INSTALLATION

LOCATION: Locate the unit in a well ventilated area away from moisture and heat. Two ½" holes are provided on one end of the dimmer to install a lighting bar pipe clamp and suitable safety cables.

POWER CONNECTIONS: Extending from the chassis is a 20 amp line cord for connection to a 120 VAC, 20 Amp, grounded service. Total capacity of the AS-40M is 2400 watts.

LOAD CONNECTIONS: There is one Edison Plug connector provided for each AS-40M output channel. They are located along the left and right edges of the unit. The markings on the cover indicate the channel numbers for each connection. The maximum capacity of each channel is 600 watts.

CONTROL SIGNAL CONNECTIONS:

The male five pin XLR connector on the unit end panel connects to the control console. The female connector is for connection to additional dimmers. The AS-40M dimmer is compatible with the USITT DMX-512 protocol.

Note that the DMX standard does not provide for console power via the dimmer chain. Therefore the DMX console used with AS-40M dimmers must be powered by other means.

Wiring information for the DMX control signal connectors is shown on the unit top cover.




Revision 2.0

AS - 40M COMPACT DMX/MANUAL DIMMER OWNERS MANUAL

Page 2 of 5

02/14/2005

AS-40M END VIEW




OPERATION

NORMAL MODE (non-chaser)

A green LED in the end panel will indicate that a valid control signal (DMX) is applied to the unit. A DIP switch block on the end panel selects the starting channel number of the dimmer. The 7 right hand switches control this function. For example, if all switch positions are down - the dimmer will respond to console channels 1-4. Moving the switch position on the far right to up will set the dimmer to respond to channels 5-8. A complete table of channel assignments is provided at the end of this manual. You can address up to 512 channels using DMX control.

RELAY MODE: Pairs of channels (1/2 and/or 3/4) may be switched into the relay mode. In this mode the output of these channels will be either off or full on depending on the control console channel setting. The trip point for turn on is aprox. 50%. The 2 left hand switches on the DIP switch block control relay mode channel selection.

NORMAL MODE SWITCH FUNCTIONS



When operating in the chaser mode the AS-40M becomes independent of the control console and other dimmers. The green LED indicator is OUT when in the chaser mode. Chaser mode is turned on and off by one of the DIP switches on the end of the unit. A diagram on the unit cover shows the switch settings for controlling chaser operation.

Eight different chaser patterns are available. A "bounce" condition may be imposed on several of the chase patterns by setting one of the DIP switches. The bounce condition causes the chase pattern to run in alternating directions.

The chase step time may be controlled for up to 64 seconds per step. Step fade time is proportional to the step time. If a channel is in the relay mode during chaser operation - it will "snap" on and off (zero fade time). The tables below show the details of chaser settings.




Revision 2.0

AS - 40M COMPACT DMX/MANUAL DIMMER OWNERS MANUAL

Page 3 of 5

02/14/2005



MANUAL OPERATION

The AS-40M can be operated by itself as a manually controlled dimmer. If there is no DMX signal present and the unit is not in the chaser mode then each channel can be controlled by one of the four rotary faders on the unit top cover. The faders are marked as to channel number. Rotating any fader clockwise will increase the intensity of the channel.

MAINTENANCE AND REPAIR

TROUBLESHOOTING

- Check that you have power applied to the dimmer.
- Check that all light fixtures are functional.
- Check the fuses.

- Check the DMX control cable.
- Check the settings of the dimmer DIP switches.
- Check the console setup for correct patching.

REPAIR

The only user serviceable parts are externally accessible fuses. Replace fuses ONLY with 5 Amp, 250VAC, fast blow fuses. Internal service on the unit by other than Lightronics authorized agents will void the warranty. If service is required, contact the dealer from whom you purchased the dimmer, or Lightronics, Service Department, 509 Central Drive, Virginia Beach, VA 23454. Tel: 757 486 3588.

Revision 2.0

Page 4 of 5

AS - 40M COMPACT DMX/MANUAL DIMMER OWNERS MANUAL

02/14/2005

CHANNEL ASSIGNMENT SETTINGS

The DIP Switch Setting column shows the positions of the DIP switches on the dimmer. The Start Channel column shows the resulting channel assignment for the first channel of the dimmer

All Lightronics products using DIP switches for address assignments conform to this table. Some dimmers cannot be set to all 512 channels and will have fewer switches than are shown in the table. If this is the case then match the right end switches in the table to your dimmer switches. NOTE: Some control consoles can be programmed or "patched" to alter their channel order. You may get unexpected results if you are not aware of the console patch condition when you assign channels at a dimmer.

DIP Switch	Start	DIP Switch	Start	DIP Switch	Start	DIP Switch	Start
Setting	Channel	Setting	Channel	Setting	Channel	Setting	Channel
0.00000	1	ប្ ប ប្បល្ប្	129	\mathbf{U} \mathbf{U} \mathbf{U} \mathbf{U} \mathbf{U} \mathbf{U} \mathbf{U} \mathbf{U}	257	00 0 0 0 0 0	385
$\Omega\Omega\Omega\Omega\Omega\Omega\Omega$	5	0.000000	133	0 0 0 0 0 0	261	00000000	389
ាំប្រាប្បាប្រាប្រាក្សា	9	0.00000	137	\mathbf{O} $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$	265	00 00	393
↑ ↑↑↓↓ 0 0	13	0.00000	141	0 0 0 0 0 0	269	00 0000	397
ប្រាប្បាប្ប	17	0.00000	145	\mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O}	273	\mathbf{OO} \mathbf{OO} \mathbf{OO}	401
<u> </u>	21	0.00000	149	0 0 0 0 0 0	277	0000000	405
Դ ԳԴԳ ՍՕ ֆ	25	0.00000	153	0 0 0 0 0 0	281	00 00000	409
↑ ↑↑↓000	29	000000	157	0 0 0 0 0 0 0	285	0000000	413
<u> </u>	33	ԴՍ ԴՍԴԴԴ	161	\mathbf{O} $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$	289	00	417
ψψψψψψ	37	ԴՍԴՍԴԴ	165	\mathbf{O} $\mathbf{\hat{U}}$ $\mathbf{\hat{U}}$ $\mathbf{\hat{U}}$ $\mathbf{\hat{U}}$ $\mathbf{\hat{U}}$ $\mathbf{\hat{U}}$	293	0000000	421
ԴԴԴՍԴՍ Դ	41	$\hat{1}0\hat{1}0\hat{1}0\hat{1}$	169	\mathbf{O} $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$ $\hat{\mathbf{O}}$	297	000000	425
$\hat{\mathbf{T}}\hat{\mathbf{T}}\hat{\mathbf{U}}\hat{\mathbf{U}}\hat{\mathbf{U}}\hat{\mathbf{U}}\hat{\mathbf{U}}$	45	000000	173	0 0 0 0 0	301	0000000	429
ԴԴԴՍՍ ԴԴ	49	ԴՕ ԴՕՕԴ Դ	177	0 0 0 0 0 0	305	00 0000₽₽	433
↑ ↑ 00 00	53	Ω	181	0 1 1 0 1 0 1 0 0 0 0	309	0000000	437
$\hat{T}\hat{T}\hat{T}$	57	Ω	185	0 0 0 0 0	313	000000	441
$\hat{T}\hat{T}\hat{T}$	61	000000	189	O \$\$0000	317	000000	445
ាំប្ ប ាំប្រាំប្	65	ԴՍՍ ԳԴԳ	193	\mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O}	321	000 0 0	449
<u> </u>	69	Դ ՍՍ Դ Դ Դ Մ	197	0 0 0 0 0 0	325	000ûûûû	453
Դ ՂՍ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ Դ	73	Դ ՍՍ Դ Դ Ս Դ	201	\mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O}	329	000 0 0	457
0.00000	77	0000000	205	0 0 0 0 0 0	333	0000000	461
Դ ԴՍԴՍԴ	81	Դ ՍՍ Դ Ս Դ Դ	209	\mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O} \mathbf{O}	337	000 ⊕0⊕₽	465
$\hat{\mathbf{T}}\hat{\mathbf{T}}\mathbf{U}\hat{\mathbf{T}}\mathbf{U}\hat{\mathbf{T}}\mathbf{U}$	85	000000	213	0 0 0 0 0 0	341	00000000	469
Դ Դ Ս Դ ՍՕ ֆ	89	000000	217	0 0 0 0 0 0	345	0000000	473
$^{\uparrow\uparrow}000000$	93	000000	221	0000000	349	0000000	477
<u> </u>	97	ԴՕՕՕ ԳԵՐ	225	0000 0 0 0 0	353	0000ûûû	481
0.0000	101	000000	229	0 0 0 0 0 0	357	00000000	485
$\Omega \Omega \Omega \Omega \Omega \Omega \Omega$	105	000000	233	000000	361	0000û0û	489
000000	109	000000	237	0000000	365	0000000	493
ŶŶ 000ŶŶ	113	00000	241	00000 0 0	369	000000	497
\$\$000\$0	117	₽0000₽0	245	0000000	373	0000000	501
\$\$0000 \$	121	₽00000₽	249	000000₽	377	000000	505
\$\$00000	125	000000	253	000000	381	0000000	509

All Lightronics products are warranted for a period of TWO/FIVE YEARS from the date of purchase against defects in materials and workmanship.

This warranty is subject to the following restrictions and conditions:

- A) If service is required, you may be asked to provide proof of purchase from an authorized Lightronics dealer.
- B) The FIVE YEAR WARRANTY is only valid if the warranty card is returned to Lightronics accompanied with a copy of the original receipt of purchase within 30 DAYS of the purchase date, if not then the TWO YEAR WARRANTY applies. Warranty is valid only for the original purchaser of the unit.
- C) This warranty does not apply to damage resulting from abuse, misuse, accidents, shipping, and repairs or modifications by anyone other than an authorized Lightronics service representative.
- D) This warranty is void if the serial number is removed, altered or defaced.
- E) This warranty does not cover loss or damage, direct or indirect arising from the use or inability to use this product.
- F) Lightronics reserves the right to make any changes, modifications, or updates as deemed appropriate by Lightronics to products returned for service. Such changes may be made without prior notification to the user and without incurring any responsibility or liability for modifications or changes to equipment previously supplied. Lightronics is not responsible for supplying new equipment in accordance with any earlier specifications.
- G) This warranty is the only warranty either expressed, implied, or statutory, upon which the equipment is purchased. No representatives, dealers or any of their agents are authorized to make any warranties, guarantees, or representations other than expressly stated herein.
- H) This warranty does not cover the cost of shipping products to or from Lightronics for service.
- I) Lightronics Inc. reserves the right to make changes as deemed necessary to this warranty without prior notification.