

WARRANTY

Thank You

for purchasing Westcott gear!

Register your new gear.

We have a simple form for registering your Westcott purchase that provides you with added assurance for your gear: fjwestcott.com/warranty

Visit fjwestcott.com

- Video TIPS
- Product Support
- Knowledge Base
- Product Reviews
- Contests & More!

Our promise to you is supported by a commitment to offer the most innovative solutions, exceptional product quality and first class service and support.



One year against manufacturer defect.

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Register this product at FJWESTCOTT.COM/WARRANTY

Repair Dept.: **800-886-1689** / 419-243-7311 (International)

E-Mail: INFO@FJWESTCOTT.COM SUBJECT: ATTN: REPAIR DEPT.

Shipping: F.J. Westcott Co, 1425 Holland Rd Suite B, Maumee, OH 43537

©F.J. WESTCOTT CO. ALL RIGHTS RESERVED.

ULite
with Octagonal or Square Softbox

QUICK START GUIDE



SETUP & USAGE

Setting up the uLite

- 1 Locate one 6.5' light stand. Loosen the knob

located directly at the base of the light stand legs. Apply pressure by pushing downwards to the base of the light stand legs. The legs will extend outward. When the center of the light stand is approximately 1" off of the floor, tighten down the knob. Using the three remaining knobs located on your light stand, adjust the height accordingly.



- 2 Locate the uLite and the softbox. Attach the softbox to the uLite by inserting the uLite rods into the softbox pockets.

CAUTION: Make sure the heat vent is located towards the top of the uLite. This will prevent overheating of the softbox and uLite. Once attached, open the softbox by pushing the round center runner towards and around the lamp socket until it's seated flush. Once completely open, the softbox will take shape.



Shown using square softbox

- 3 Once the round black runner is seated flat at the base of the light socket, install the supplied silver metal locking ring by rotating clockwise on socket.



Shown using square softbox

- 4 Loosen the tightening knob on the uLite's tilting bracket. Then place the bracket onto the top stud of the light stand. Tighten knob to lock into place.
- 5 **Ensure the unit is not plugged into any power receptacle.** Locate the lamp and screw it into the uLite light socket.



- 6 Locate the white front diffusion panel for the softbox. Secure this panel to the front of the softbox using the hook and loop tape.
- 7 Connect the power cord to a grounded electrical 120v outlet. Turn the light ON/OFF using the switch located on the power cord.



- 8 Repeat all steps above for any remaining uLite.

Collapsing the uLite Softbox

- 1 Power OFF and unplug your uLite.
- 2 Cooling your lamps: Allow 20 minutes for Photoflood. Allow 5-7 minutes for Fluorescents.

- 3 Unscrew the metal locking ring. Locate the round center runner and pull towards you, allowing the softbox to naturally collapse.

Removing the uLite Softbox

- 1 Complete all steps for "Collapsing your Softbox".
- 2 Locate the thumb screws and turn counterclockwise until the softbox is released from the main light fixture.
- 3 To re-attach, simply line up the screw holes with the thumb screws and tighten until securely fastened.



CAUTION

Failure to read & follow the bullet points below may potentially void Westcott's 1-year Limited Warranty.

- Failure to use the supplied silver metal locking ring could result in permanent damage to the uLite bulb and softbox. **DO NOT** use the uLite Softbox without the installation of the locking ring.
- Manufacturer service only. Do not alter fixture or power cord.
- Please use extreme caution around children and pets until all lamps are cool.
- Always use the supplied front diffusion panel during use.
- Always make sure power is off and the power cord is unplugged before removing or inserting a lamp.
- Always disconnect uLite when not in use and allow to cool before collapsing, storing and/or changing lamps.
- Avoid Electrical Shock: Never insert any metal objects into the uLite socket. Never use near water.
- Always use grounded power outlets. 120 volt/maximum wattage is 500-watts.
- Fluorescent lamps contain mercury. Manage in accordance with disposal laws. See: www.lamprecycle.org