

RKM-572 Holder



Instruction Manual

Included Accessories:

- Hex Screws (24 pcs)
10-32 x 5/8"
Hex drive
- Nylon Washers (24 pcs)
- Nylock Nuts (8 pcs)
10-32 thread insert size
- Tinnerman Clips (16 pcs)
10-32 thread insert size

Required Tools:

- Crescent wrench or 3/8 wrench
- 1/8 Hex Key (1 pc) (included)

Holder Assembly	
	Step 1: Lay the base flat on a hard surface.
	Step 2: Place the side bar vertically on top of the base (outer placement).
	Step 3: Place the washer onto the screw, and insert the screw through each of the 8 bottom holes. Secure the screws with nylock nuts.
	Step 4: Repeat steps 2 and 3 for the second side bar.
Mounting the Units	
	Step 5: Slide the Tinnerman clips onto the sidebar over the holes.
	Step 6: Starting from the top of the holder, place the TLM-702 monitor on top of the Tinnerman clips.
	Step 7: Place the washer onto the screw and insert the screw into Tinnerman clip to secure the monitor in its place.
	Step 8: Place the ITC-100 intercom on top of the Tinnerman clips right below the monitor.
	Step 9: Place the washer onto the screw and insert the screw into Tinnerman clip to secure the intercom in its place.
	Step 10: Place the DN-500 recorder on top of the Tinnerman clips below the intercom. NOTE: You may have to wiggle the unit a bit to slide it in the holder.
	Step 11: Place the washer onto the screw and insert the screw into Tinnerman clip to secure the recorder in its place.