

---

INSTRUCTION BOOK FOR  
Perm Wall Frame

---



## Perm Wall Installation

---

The Perm Wall frame should be fastened to a wall. The frame is not designed for "flying" installations.

1. Assemble frame sections together by inserting plastic corner brackets to tubes and securing the corners with #12 sheet metal screws. If you have a larger jointed frame, insert steel bracket on one section of frame into other section matching the color code. Insert 10-32 screw through tube and bracket and fasten with wing nut.

**NOTE:** If the viewing surface is attached to the frame before the frame is secured to the wall, the frame may bow.

2. Place bottom of frame at desired height on wall. Make sure bottom is level. Drill through aluminum tubing every 18" to 24" and fasten to wall with appropriate fastener (not supplied) for type of wall construction.

**NOTE:** Use appropriate fastener for wall construction, i.e. wood screws if wall behind frame is wood construction or other appropriate fastener if dry wall or plaster or cement block construction.

3. Make sure that sides are at 90 degrees or right angle to bottom and fasten to wall in like manner. Next fasten top of frame to wall in the same manner, making sure that the center is the same distance from the bottom as it is at the sides of frame. This is most important for proper surface fit.


**NOTE:** If a center spreader is shipped with frame, insert center spreader between the bottom and the top of frame as a guide. This is most important to insure that the top and bottom are equal distance apart across the entire top of frame. Lack of care in this regard will result in poor fit of surface. Center spreader can be removed once top of frame is fastened to the wall.

4. Carefully snap surface onto frame. This completes the installation.

# Cleaning

**Da-Mat®, High Contrast Da-Mat®, Pearlescent, Cinema Vision, High Contrast Cinema Vision, High Contrast Cinema Perf, Audio Vision, High Contrast Audio Vision, Da-Tex® (Rear) and Dual Vision** surfaces can be cleaned as follows:

Using a white clean cloth (100% cotton preferred) that is dampened with clear water, gently wipe the area in one direction. Do not use a circular motion. Using a dry 100% cotton cloth, wipe dry after each cleaning session. To clean a stubborn stain or a sticky surface, use denatured alcohol (methanol or methyl alcohol) following the same procedure as for water.



## LIMITED ONE YEAR WARRANTY ON DA-LITE PRESENTATION PRODUCTS

Milestone AV Technologies LLC warrants certain Da-Lite branded products to the original purchaser only, to be free from defects in materials and workmanship for a period of one (1) year from the date of purchase by the original purchaser; provided they are properly operated according to Da-Lite's instructions and are not damaged due to improper handling or treatment after shipment from the factory.

This warranty does not apply to equipment showing evidence of misuse, abuse or accidental damage, or which has been tampered with or repaired by a person other than authorized Da-Lite personnel.

Da-Lite's sole obligation under this warranty shall be to repair or to replace (at Da-Lite's option) the defective part of the merchandise. Returns for service should be made to your Da-Lite dealer. If it is necessary for the dealer to return the screen or part to Da-Lite, transportation expenses to and from Da-Lite are payable by the purchaser and Da-Lite is not responsible for damage in shipment. To protect yourself against damage or loss in transit, insure the product and prepay all transportation expenses.

**TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES AS TO FITNESS FOR USE AND MERCHANTABILITY.** Any implied warranties of fitness for use, or merchantability, that may be mandated by statute or rule of law are limited to the one (1) year warranty period. This warranty gives you specific legal rights, and you may also have other rights, which vary from state-to-state. **TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NO LIABILITY IS ASSUMED FOR EXPENSES OR DAMAGES RESULTING FROM INTERRUPTION IN OPERATION OF EQUIPMENT, OR FOR INCIDENTAL, DIRECT, OR CONSEQUENTIAL DAMAGES OF ANY NATURE.**

In the event that there is a defect in materials or workmanship of a Da-Lite product, you may contact our Sales Partners at PO Box 137, Warsaw, IN 46581-0137, (574) 267-8101, (800) 622-3737.

**IMPORTANT: THIS WARRANTY SHALL NOT BE VALID AND DA-LITE BRANDED PRODUCTS SHALL NOT BE BOUND BY THIS WARRANTY IF THE PRODUCT IS NOT OPERATED IN ACCORDANCE WITH THE DA-LITE WRITTEN INSTRUCTIONS.**

Keep your sales receipt to prove the date of purchase and your original ownership.



A Milestone AV Technologies Brand

3100 North Detroit Street  
Warsaw, Indiana 46582  
P: 574.267.8101 or 800.622.3737  
F: 574.267.7804 or 877.325.4832  
E: info@da-lite.com  
www.da-lite.com

DL-0265 01.14

© 2013 Milestone AV Technologies LLC. Printed in U.S.A.

76087