


Assembly Instructions

For SMP-WMC-12 & SMP WMC-16 Wire Measuring & Coiling Systems


Included items:

- | | |
|--------------------------------------|--|
| A 2 x yellow base frames | H 1 x bag of radius plates & hardware |
| B 4 x locking casters | J 1 x coiler handle |
| C 2 x long telespar uprights | K 2 x gravity lock pins |
| D 1 x short telespar crossbar | L 8 x hex bolts |
| E 1 x counter | M 8 x hex nuts |
| F 1 x cutter | N 16 x washers |
| G 1 x coiler | |




Step 1

- 2 x **A**
- 1 x **D**
- 4 x **L**
- 4 x **M**
- 8 x **N**





Make sure that holes are facing the ground



Phone: 310-822-6290 | Fax: 310-306-9343
 Email: info@spoolmaster.com
 Website: www.spoolmaster.com
 Address: P.O. Box 12017 Marina del Rey, CA 90292
 Hours: Monday - Friday 8:00am - 4:30pm Pacific Time

Step 2

4 x **B**





Step 3

2 x **C**

4 x **L**

4 x **M**

8 x **N**



Step 4

1 x **E**


1 x **F**

1 x **G**

1 x **H**

1 x **J**

2 x **K**



Phone: 310-822-6290 | Fax: 310-306-9343

Email: info@spoolmaster.com

Website: www.spoolmaster.com

Address: P.O. Box 12017 Marina del Rey, CA 90292

Hours: Monday - Friday 8:00am - 4:30pm Pacific Time