


## Multi-light Array

Multiple SL-200LXi units can be assembled into a multi-light array by connecting them together using our patent-pending interlocking design. There is no limit to the number of units that can be interlocked.

To connect two units, simply slide the shoe of one SL-200LXi into the mounting slot on the side or top of the other unit as shown below. Tighten the adjustable nut to secure the unit.

**Note:** Lights do not provide power to one another. Each light must be charged and switched ON/OFF individually.



## Video bracket

To use the video bracket (included):

1. Attach the video bracket to the bottom of your camcorder by screwing the nut into the threaded mounting hole. **Do not over-tighten.**
2. Position the bracket where desired. **Tip:** to avoid blocking the light with the camcorder's viewing screen, angle the bracket forward to a position where the light is across from the lens.
3. Attach the SL-200LXi to the shoe mount on the video bracket. Adjust as needed.



Camcorder not included

## 90 Day Limited Warranty

Sima Technologies, LLC warrants this product against defects in materials and workmanship for a period of 90 days from the date of retail purchase. During the warranty period, the product will be repaired or replaced, at Sima's option. You can register your product online at [www.simaproducts.com](http://www.simaproducts.com)

### Conditions

Ship your unit, freight pre-paid, including reasonable proof of date and place of purchase and description of problem to:

Attn: Customer Service  
c/o Sima Technologies, LLC  
125 Commerce Dr.

Hauppauge, NY 11788

[customerservice@simaproducts.com](mailto:customerservice@simaproducts.com)

This warranty is void if any defects are caused by abuse, misuse, negligence or unauthorized repairs. All liability for incidental or consequential damages is specifically excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal right and you may also have other rights which vary from state to state.

Visit us online at: [www.simaproducts.com](http://www.simaproducts.com)



Ultra Bright LED  
Video Light for  
Digital Cameras  
and Camcorders  
with Control of  
Brightness and  
Color Temperature



International  
Power  
Adapter!



**Model SL-200LXi**  
Dimmable Dual-Powered Video Light  
with Temperature Controls  
and International Plug

## Introduction

The Sima LED Universal Video Light Model SL-200LXi can be mounted on the universal accessory shoe of any camcorder or digital camera by sliding it into place and tightening the mounting wheel (if your camcorder does not have a shoe mount, the Sima Video Bracket included provides a mounting platform).

## Battery:

The SL-200LXi comes with a rechargeable, non-replaceable lithium ion battery (pre-installed from the manufacturer). Prior to use, the battery must be charged 3-4 hours.


**Note:** use only the supplied AC adapter/charger to power the light and charge the batteries.

## To charge the battery:

1. Connect the appropriate AC adapter to the charger for your country.
2. Insert the jack on the power cord into the power input jack on the rear of the SL-200LXi (Fig. 1). The **red** LED indicator light, located beside the power jack, will turn on when charging.

3. The battery must charge 3-4 hours before it is fully charged.
4. Fully charged batteries provide 45 to 60 minutes of use depending on battery usage.

**Note:** indicator light turns **green** when charging is complete.



## Special Notes:



- For maximum illumination, use the patent-pending interlocking design to construct a multi-light array. (For example 4 x 3 or 16 x 9.)
- When using multiple lights, each light must be charged individually.
- The lens has been frosted to diffuse light evenly and eliminate hot spots.
- Light Memory: the light will remember the last light level settings (Settings are stored 10 seconds after a change is made).

5. The light can be powered by the AC charger. While the light is powered by the AC adapter, the battery also recharges.

## Operation:

Turn light on or off by sliding the ON/OFF switch to the desired position shown in Fig. 2.

Adjust the light to the desired setting by touching the buttons on the rear of the SL-200LXi. To reset to factory settings, (50% brightness and centered on the temperature scale), hold the reset button for two seconds. See Fig. 3 for a diagram of the controls.



## Touch Panel Indicator

- Lights BRIGHT when changing light levels
- Lights DIM when maximum or minimum level reached
- Flashes once when accessing light memory setting

## Specifications:

This package includes:

- 1 - SL-200LXi video light
- 1 - AC adapter with international adapters
- 1 - video bracket
- 1 - user manual (this document)

**LEDs:** 36, user-controlled dimming and temperature

**Power:** Lithium ion or AC Adapter

**Battery Run Time:** 45 to 60 Minutes depending on battery usage.

**Charge Time:** 3hrs for a full charge

**Battery Type:** 3.7V 730mA Li-ion

**Charger:** 120-220V AC input; 5V DC output

**Weight:** 2.5oz (with battery).

**Size:** 2.35" x 2.3" x 1"

©2011 Sima Technologies, LLC

P/N 21806

Made in China