

INSTALLATION & SPECIFICATIONS


OMX-02MXSI0001

Multiformat to SDI Converter with Scaler

Upscales Composite, VGA, DVI, HDMI input signals to 3G-SDI or HD-SDI formats & outputs two SDI signals



Press RES buttons once to select resolution, press again to switch from 50Hz to 60Hz.



| Specifications | |
|-------------------------|--|
| SDI Output Distance | 3G-SDI up to 328 feet HD-SDI up to 656 feet Supports Black Screen Signal Output |
| HDMI Cable Distance | 33 feet, 8/12-bit |
| SDI Transmission Rates | 2.97Gbps, 2.97/1.001Gb/s |
| Video Bandwidth | 165 MHz |
| HDMI Input Timing Range | 480i/576i - 1080P@50/60Hz |
| VGA Input Timing Range | VGA@60-SXGA60Hz & 1920x1080@60Hz |
| VGA/DVI Input Timings | VGA@60Hz, SVGA@60Hz XGA@60Hz, SXGA@60Hz, WXGA@60Hz 1280x720@60Hz, 1920x1080@60Hz |

| Specifications | |
|-------------------|---------------------------------|
| Video Input | HDMI, DVI, VGA, Composite Video |
| Color Space | RGB, YCbCr 4:4:4, YCbCr 4:2:2 |
| Color Depth | 10-bit, 12-bit |
| Audio Formats | PCM 2CH with 48KHz sample rate |
| Power Input | AC100—240V 50/60Hz |
| Power Consumption | 5W |
| Dimensions | 11.34 x 4.30 x 1.3 in |
| Weight | 1.65 lb |
| Includes | 1– 12VDC/2.5A Power Adapter |



Troubleshooting

No image output

- Ensure power supply is firmly connected. Only use the 5VDC power adapter included with the unit.
- Check that the cables are securely connected.
- Check that the display/TV has been set to the proper channel or input.
- For PC connections via HDMI, set output mode to mirror or extend.

Display is unstable

- Check all connections.
- Connect the source directly to the display device to ensure there is a signal output. Change the signal source if necessary.
- Use only high-quality HDMI or appropriate cables.



SAFETY PRECAUTIONS



- To prevent fire or shock hazard, do not expose this equipment to high humidity and/or dust.
 Do not use in an unprotected outdoor installation nor any area classified as overly damp or wet.
- 2. The temperature for installation should be kept between 32°F to 140°F (0°C to 60°C). Avoid direct sunlight exposure or extreme changes of temperature over a short period of time.
- 3. Do not disassemble the unit or place it on an unstable base.
- 4. Do not drop the unit and avoid heavy impact.
- 5. This unit should not be permanently installed unless proper ventilation is provided. Any enclosure openings must not be blocked or covered as they protect the unit from overheating.
- 6. Before cleaning, turn off the power and unplug the unit from all connections. Use a damp cloth. Do not use liquid cleaners nor aerosol cleaners.
- 7. Do not overload outlets and extension cords as this may result in a risk of fire or electric shock.
- Enclosure entry is dangerous. Never push objects of any kind, including liquids, into this unit through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock.
- 9. Do not attempt to open or service this unit yourself as opening or removing covers may expose you to dangerous voltage and other hazards.
- 10. There are no user-serviceable parts inside the unit. If the unit requires service contact your authorized dealer, or an authorized repair service company.